FCC Safety Warning

You will see the FCC safety warning after you log into the web configurator. You can also see the FCC safety warning by going to http://x.x.x./leaalinfo.html. Where "x.x.x.x" is the Zyxel Device's IP address.

