



## USER'S MANUAL

### Model: AK008 BT SPEAKER W CLOCK



## PRODUCT STRUCTURE DESCRIPTION

### Key Areas Of Main Functions:



1. LED display screen;
2. FM mode;
3. Bluetooth mode;
4. TF card mode;
5. AUX mode;
6. Alarm clock 1 display;
7. Alarm clock 2 display;
8. Start key/play pause;
9. Mode conversion;
10. Volume -;
11. Volume +;
12. Lighting adjustment;
13. Setting;
14. Previous song;
15. Next track;
16. Microphone/charging indicator;
17. TF card;
18. Audio AUX;
19. USB charging.

1

## CLOCK TIME SETTING

1. Clock time setting and adjustment method: on the clock interface, long press the setting key, minute hand time indicator flash, long press or short press +/- to adjust minute hand time, then short press setting key, hour hand time indicator flash, long press or short press +/- to adjust hour hand time, and long press the setting key to confirm.
2. Alarm clock adjustable setting method 1: boot in clock interface, Short press the set key, Alarm clock 1 icon show bright lights, interface display the current alarm clock time, long press the set key, the minute hand time jump, the long or short time +/- button to adjust minute hand, short press set key again, same time jump, Long or short press +/- button to adjust same time, Adjust good set alarm clock time after long press set key to confirm;
3. Alarm clock 2: the setting method is the same as the setting method of alarm clock 1. When icon is on, Alarm clock is on; when icon is off, Alarm clock is off.

## THE ACTIVE

1. answer: when the bluetooth is on, press the play/pause button
2. Hang up the phone: in the bluetooth state, press the play/pause button

## MODE SWITCH

1. In the startup state, when no F card is inserted /AUX connection, Speaker will enter the bluetooth pairing mode after startup;
2. When TF card or AUX connection is inserted, Default mode is TF card or AUX mode upon startup.
3. In the corresponding mode, LED display screen will display corresponding mode table;
4. Enter FM mode, FM white mode marked long and bright, short press play button to automatically search the station save, after the search is completed, press the up/down curve button to select the station and press +/- button to adjust the volume. Radio frequency: 87.9MHz-107.9MHz

2

## BASIC FUNCTION

### SWITCH MACHINE

1. Power on: long press the power button to start up;
2. shutdown: divided into active shutdown and automatic shutdown;  
(1) long press the power button active shutdown;  
(2) after 10 minutes, Speaker has no connection and any operation, bluetooth automatically off.
3. After the active shutdown, all functions of the speaker are turned off;
4. After automatic shutdown, Main function of the speaker is turned off (BTTF card /AUX/FM mode, Secondary function is not affected (clock alarm1/alarm2). Short press the power button to wake up the main function of the speaker.

## PRODUCT PARAMETERS

Wireless range: 10M	Normal volume: 3H
Audio signal to noise ratio: >70dB	Distortion: 10%
Output power: 3W	Audio input: bluetooth /TF card /AUX
Built-in voltage: 3.7V	Speaker unit: 4 Ω
Charging voltage: DC 5V	Frequency response: 100Hz-20KHz
Clock: Yes	Adjustment mode: button
	Battery capacity: 1200 mAh

## USING RANGE

Computer, mobile phone, MP3 other multimedia audio source playback devices

## MATTERS NEEDING ATTENTION

1. Please follow the instructions in this manual;
2. Do not charge this product with a charger whose output specification exceeds 5V 1A, otherwise it will easily damage the battery of the speaker box;
3. Please use and store the product in normal temperature environment;
4. do not use in closer to the water products, not products will immersed in any liquid or any liquid splash, onto the products;
5. Do not use products near heat sources, such as radiators, hot air regulators, stoves or other devices that generate heat;
6. Do not block opening of the speaker, such as charging port, indicator light microphone;
7. Please avoid excessive volume or prolonged use of speaker to avoid damage to user's hearing;
8. No matter equipment is damaged for any reason, you must contact the after-sales staff of our brand in time to deal with it. Unauthorized dismantling modification will invalidate the warranty.
9. After receiving this product, please use it after fully charging.

3

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.