

## Block diagram of BWR101 and BWR102 system.




Figure 1. BWR101 and BWR102 load measurement