

WELCOME

Thank you for choosing our products. The Bravo-B1 wireless earphone has a fashionable design, powerful functions, and high compatibility, providing you with hands-free convenience in making calls and listening to music.

PACKAGE CONTENT

1 x Bravo-B1 Wireless Earphone
1 x USB Charging Cable
4 x Earbuds
4 x Ear Hooks
1 x User Manual

WIRELESS TECHNOLOGY

With the wireless technology, you can connect earphone to its compatible communication devices without using cables. The wireless connection allows you to use a cell phone without holding it against the earphone, but the maximum distance between them cannot exceed 10 meters (Distance between open areas can be increased). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices.

In some areas, use of the wireless technology may be subject to some constraints. Please consult your local authority or service provider for details.

HOW TO USE

1. Charging

1) Connect the charging port with any USB charging adapter or active computer USB port.

2) Charging will start automatically with LED indicate red.

3) The earphones are fully charged when LED indicate blue.

Note: Make sure the battery is fully charged before putting the earphones away for storage. Charge the earphones at least once every 3 months when not using for a long time.

2. Pairing

1) Make sure the earphones and your BT device are next to each other (within 10 meters).

2) The first time you use the earphone, press the multifunction button until the LED indicator flashes red and blue alternately. Now the earphones are in pairing mode.

3) Activate BT function on your phone and search for the nearby wireless connection: Find "TECNO-Bravo-B1" in the search results. Tap on the name to connect. Once connected, blue LED will flash.

4) If you have paired your device with the earphones before, remove "TECNO-Bravo-B1" from the BT device list and pair again.

Note:

1. The wireless earphones can remember previous paired devices.

2. If the earphone cannot pair with your BT device. Press and hold the multifunction button (when the earphone is off) for 10 seconds until the LED indicator flashes purple twice to clear the pairing history. Then restart the earphone to pair again.

OPERATION AND FUNCTIONS

Power On	Long press the multifunction button for 1-2 seconds
Power Off	Long press the multifunction button for 3 seconds
Pairing	Long press the multifunction button for 4-5 seconds to enter pairing mode
Volume +/-	Short press the volume +/- button
Next Track / Previous Track	Long press the volume +/- button
Play / Pause	Press the multifunction button once
Answer / Hang up a Call	Press the multifunction button once
Reject the Incoming Call	Long press the multifunction button for 1-2 seconds and then release
Phone Mute	1. In the calling state, press the volume plus key and volume minus key together to turn on the phone mute 2. Press the multifunction button and volume plus key together to turn off phone mute
Voice Dialing	Long press the multifunction button for 1 second in the connected state (BT device support is required)

Re-dial Last Call

Press the multifunction button twice

Restore to Factory Settings

When the earphones off, press and hold the multifunction button for 10 seconds until the LED flashes purple twice

Back to Connection


1. Automatically connect with the last connected device after starting up
2. The device that has been paired with the earphone and is not connected for the last time enters the BT setting of the device and connects to the earphone again

Multi-point Connection

After pairing with two BT devices, connect with the BT device that has been successfully connected for the last time, and then enter the BT setting menu of another BT device. Click this wireless earphone to connect (multiple devices can be connected back after multi-point connection)

PRODUCT OVERVIEW


① Volume + / Next Track
② Multifunction
③ LED Indicator / Microphone
④ Volume - / Previous Track
⑤ Micro USB Charging Port



1. Automatically connect with the last connected device after starting up
2. The device that has been paired with the earphone and is not connected for the last time enters the BT setting of the device and connects to the earphone again

HOW TO WEAR

Please wear the earphones as shown in the diagram:
1. Attach the ear hooks onto the earphones.
2. Wear the earphones and the hooks on your ears and adjust for the best fit.



CUSTOMER SERVICE

365 DAYS

TECNO WARRANTY

carcare

Carlcare provides service

WARRANTY CERTIFICATE

Name:	
Address:	
Tel. No.:	
Date of purchase: (dd/mm/yy)	
Store name:	
S/N:	

WARRANTY TERMS & CONDITIONS

365 DAYS WARRANTY

Please keep well your receipt, this warranty covers only original TECNO products. It is not applicable to normal wear and tear, or any effects or damage caused by misuse of the product.Warranty is for primary product only. Additional or free of cost products are not covered under warranty.


TECNO MOBILE LIMITED

TM and ©2019 TECNO Corporation. All rights reserved. Other product and company names mentioned herein may be trademarks or trade names of their respective owners. Specifications are subject to change without notice. Model names and the availability of particular products may vary by region.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.



www.tecno-mobile.com

Bravo B1

TECNO

BRILLIANT SOUND MAGNET

USER MANUAL

Bravo B1

KP-RD-003-00