

Safety Instructions

Read and follow all the safety instructions:

- The product is not water resistant, be cautious when installing and using.
- Use the product with the provided power adapter only.
- Be cautious of static electricity during installation and usage. Keep the product away from sharp objects or strong corrosive chemicals.
- When bending the strip lights during installation, avoid folding the LED components as it may affect the product's life span.
- Remove nails, metal, or other conductive objects from the installation surface before attaching the strip light, as it may cause short-circuiting.
- Do not install the strip light near any heat sources.
- Do not allow children to install the strip light alone.
- Avoid installing the strip light near potentially dangerous sources (e.g., candles, liquid-filled objects).




Introduction

Thanks for choosing the Govee RGBIC LED Strip Lights. This product is equipped with a 5m RGBIC strip light and supports app, voice (Alexa/Google Assistant), and IR remote control. RGBIC is Govee's latest lighting display technology. With its advanced IC chips (independent control), each strip light segment can be adjusted independently, creating vibrant rainbow effects.

What You Get


LED Strip Lights	1
Adapter	1
User Manual	1
Service Card	1

At a Glance



Using Your Remote Controller

* When using the remote controller, ensure it is aligned with the control box receiving port.



Button	Function
On/Off	Press to turn the light on/off.
Pause/Play	Press to pause/continue the Music Mode or dynamic Scene Modes.
Mode	MODE +/-: Press to cycle forward or backward through 12 scene modes.
Speed	SPEED +/-: For scene mode, press it to speed up or slow down the changing of lights; For music mode, press it to increase or decrease the sensitivity of the mic.
Adjust Brightness	Dim or brighten the light.

Color Changing	COLOR +/-: Press to cycle forward or backward through 32 colors.
Color Selecting	Press to change the color. R: Red, G: Green, B: Blue, W: White
Sleep	Change the light to warm white with 1% brightness.
RGBIC	Press to cycle through 7 preset RGBIC lighting effects.
AUTO	Press to switch lighting effects between 10 Scene Modes at random.
Music Mode	Energetic, Rhythm, Rolling, Spectrum (from left to right).



Installing Your Device

Before You Install

1. Unpack the box and check all items listed in the packing list.
2. Power on the strip light and check whether it lights up.

Installing Steps

1. Wipe the surface to make sure it's clean and dry.



Pairing Your Device with the Govee Home App

What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).

Pairing Instructions

1. Download the Govee Home app from the App Store (iOS devices) or Google Play (Android devices).
2. Turn on Bluetooth on your smartphone.
3. Open the app, tap the "+" icon in the top right corner and search for "H6143".
4. Tap the device icon and follow the on-screen instructions to complete pairing.



Controlling the Device with Your Voice

1. Open the app, then tap the device icon to enter detail page.
2. Tap the setting icon in the top right corner.
3. Select Using Guidance and follow on-screen instructions to control the device using your voice.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Make sure the installation surface is clean and dry.
 - Firmly press over the strip after sticking.
 - Reinforce the installation via more clips and tape.
2. Cannot connect to Bluetooth.
 - Do not skip Bluetooth connection in the app.
 - Ensure Bluetooth on your smartphone has been turned on.
3. Your smartphone may be incompatible with the Govee Home app. Try using a different smartphone then reconnect.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Make sure the installation surface is clean and dry.
 - Firmly press over the strip after sticking.
 - Reinforce the installation via more clips and tape.
2. Cannot connect to Bluetooth.
 - Do not skip Bluetooth connection in the app.
 - Ensure Bluetooth on your smartphone has been turned on.
3. Your smartphone may be incompatible with the Govee Home app. Try using a different smartphone then reconnect.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 - Do not skip the Wi-Fi connecting steps in the app.
 - Connect your phone to Wi-Fi and check whether the network works well.
 - Make sure you have entered the correct Wi-Fi name and password.
 - Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
 - Connect hotspot in your phone to the strip lights and check whether the router works with the strip lights.

Specifications

Length	5m/16.4ft
Light Color	RGBIC
Water Resistance	NO
Control Method	App, Control Box, IR Remote Controller, Voice Control
Power Supply	Adapter 12V

Troubleshooting

1. The adhesive tape is not strong enough.
 - Move the control box closer to the music source.
 - Clean the mic on the control box then try again.
2. Cannot sync the strip lights to the beat of my music.
 - Do not skip the Wi-Fi connecting steps in the app.
 - 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
3. Cannot connect to Wi-Fi.
 -


Introduction

Merci d'avoir choisi les bandes LED RGBIC de Govee. Ce produit est équipé d'une bande LED RGBIC de 5m et prend en charge l'app, la voix (Alexa/Google Assistant) et la télécommande IR. Le RGBIC est la toute dernière technologie d'affichage lumineux de Govee. Grâce à ses chips IC avancés (contrôle indépendant), chaque segment de bande LED peut être ajusté indépendamment, créant ainsi des effets d'arc-en-ciel vibrants.

Ce que vous obtenez

Kit de Ruban LED	1
Adaptateur	1
Manuel d'Emploi	1
Carte de Service	1


Schéma



11

Utilisez votre Télécommande

* Lorsque vous utilisez la télécommande, assurez-vous qu'elle est alignée avec le port de réception du boîtier de commande.



Bouton	Fonction
Allumer / Éteindre	Allumer / Éteindre la lumière.
Pause / Jouer	Appuyez sur cette touche pour mettre en pause / continuer le mode Musique ou les modes Scène dynamique.
Mode	MODE +/- : Appuyez sur cette touche pour avancer ou reculer dans les 12 modes de scène.

12

Speed	SPEED +/- : Pour le mode scène, appuyez sur cette touche pour accélérer ou ralentir le changement de lumière; Pour le mode musique, appuyez sur cette touche pour augmenter ou diminuer la sensibilité du micro.
Ajustement de la luminosité	Diminuer ou éclairer la lumière.
Changement de couleur	COLOR +/- : Appuyez sur cette touche pour avancer ou reculer dans 32 couleurs.
Sélection du couleur	Appuyez sur pour changer de couleur. R : Rouge, G : Vert, B : Bleu, W : Blanc
Repos	Changez la lumière en blanc chaud avec 1% de luminosité.
RGBIC	Appuyez pour faire défiler 7 effets lumineux RGBIC prédéfinis.
AUTO	Appuyez sur cette touche pour passer d'un mode de scène à l'autre de façon aléatoire.
Mode Musique	Énergique, Rythme, Roulant, Spectre (de gauche à droite).

13


Installez votre appareil

Avant l'installation

- 1 Déballer la boîte et vérifiez tous les éléments énumérés dans la liste d'emballage
- 2 Allumez la bande LED et vérifiez si elle s'allume.


Étapes d'installation

- 1 Essuyez la surface pour la garder propre et sèche;
- 2 Retirez le film protecteur de la bande, collez la bande et appuyez fermement dessus;
- 3 Renforcez le ruban par des clips autour des coins;
- 4 Enlevez le colle du boîtier de commande et le collez;



14

- 5 Allumez la bande LED et commencez à l'utiliser.



Appairage de Votre Appareil avec l'app Govee Home


Ce que vous avez besoin

- Un routeur Wi-Fi prenant en charge les bandes 2.4GHz et 802.11 b/g/n. La bande 5GHz n'est pas prise en charge.
- Un smartphone ou une tablette fonctionnant sous iOS 8.0 (ou supérieur) ou Android 4.3 (ou supérieur).

Instructions d'appariement

- 1 Téléchargez l'app Govee Home sur l'App Store (appareils iOS) ou Google Play (appareils Android).
- 2 Activez le Bluetooth dans votre smartphone.
- 3 Ouvrez l'app, appuyez sur l'icône "+" dans le coin supérieur droit et cherchez "H6143".
- 4 Appuyez sur l'icône de l'appareil et suivez les instructions à l'écran pour terminer le couplage.

15



Contrôler l'Appareil avec Votre Voix

- 1 Ouvrez l'app Govee Home, puis appuyez sur l'icône de l'appareil pour entrer dans la page de détails.
- 2 Appuyez sur l'icône de réglage dans le coin supérieur droit.
- 3 Sélectionnez "Utiliser le guidage" et suivez les instructions à l'écran pour commencer à utiliser la commande vocale.

Spécifications

Longueur	5m/16.4ft
Couleur	RGBIC
Étanche	Non
Méthode de Contrôle	App & Boîtier de Contrôle & Télécommande IR & Contrôle Vocal
Alimentation électrique	Adaptateur 12V

16

Dépannage

- 1 Le ruban adhésif n'est pas assez solide.
 - Assurez-vous que la surface d'installation est propre et sèche.
 - Appuyez fermement sur la bande après l'avoir collée.
 - Renforcez l'installation en utilisant plus de clips et de rubans adhésifs.
- 2 Ne peut pas se connecter au Bluetooth.
 - Ne sautez pas la connexion Bluetooth dans l'app.
 - Vérifiez que la fonction Bluetooth de votre portable est activée.
 - Téléphone pas compatible. Veuillez changer de téléphone et vous connecter à nouveau.
 - Rallumez la bande et réactivez le Bluetooth dans votre téléphone pour essayer à nouveau.
 - Maintenez la distance entre la bande et le téléphone à moins de 1m pendant la connexion.
 - Maintenez les obstacles entre la bande et le téléphone aussi peu que possible.
- 3 La bande ne correspond pas à la même couleur / certaines perles du ruban ne s'allument pas.
 - Veuillez contacter l'équipe de Govee à temps pour le retour.

17

- 4 Ne peut pas se synchroniser avec le rythme de la musique.
 - Veuillez garder le boîtier de contrôle près de la source sonore.
 - Nettoyez le trou de prise de son sur le boîtier de contrôle.
- 5 Ne peut pas se connecter au Wi-Fi.
 - Ne sautez pas l'étape de la connexion Wi-Fi dans l'app.
 - Ne supporte pas le réseau à 5 GHz. Veuillez régler le routeur sur 2.4GHz et le réinitialiser.
 - Connectez votre téléphone au Wi-Fi et vérifiez si le réseau est normal.
 - Assurez-vous d'avoir entré le nom et le mot de passe Wi-Fi corrects.
 - Changez votre mot de passe Wi-Fi pour un mot de passe court, 8 chiffres et lettres sont suggérés.
 - Connectez le hotspot de votre téléphone à la bande LED et vérifiez si le routeur fonctionne avec la bande.
- 6 Ne peut pas se connecter au Alexa.
 - Retirez toutes les parties connectives de la bande LED et reconnectez-les fermement.
 - Reconnectez votre téléphone au Wi-Fi.
 - Débranchez l'adaptateur et rebranchez-le.

18

Service Clientèle

- Garantie : Garantie limitée de 12 mois
- Support : Technique de support à vie
- Email : support@govee.com
- Site officiel : www.govee.com
- @Govee @govee_official @govee.official
- @Goveeofficial @Govee.smarthome

Non-replaceable light source.
Not intended for illumination. Only used for creating ambiance.

1. Do not connect the rope light to the supply while it is in the packing or wound onto a reel;
2. Do not use the rope light when covered or recessed into a surface;
3. Do not open or cut the rope light;

CAUTION:
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Govee is a trademark of Shenzhen Intellirocks Tech Co.Ltd.
Copyright ©2020 Shenzhen Intellirocks Tech Co.Ltd. All Rights Reserved.

	BLE	Wi-Fi
Frequency	2.4GHz	2.4GHz
Maximum Power	<10dBm	<20dBm

19

FCC Statement

This device complies with Part 15 of the FCC Rules . Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



User Manual

Model: H6143
Wi-Fi RGBIC LED Strip Lights

H6143说明书

版本:1.0

料号:807-0003-00001

折叠尺寸:75×105(mm)

展开尺寸:825×105(mm)

材质:80G书页纸

工艺:四色印刷

折叠方式:风琴页