







802.11ac-20 CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz

802.11ac-20 CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz



802.11ac-40 CHANNEL 3 CARRIER LEVEL


802.11ac-40 CHANNEL 3, SPURIOUS
30 MHz ~ 3 GHz

802.11ac-40 CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz



802.11ac-40 CHANNEL 4 CARRIER LEVEL




802.11ac-40 CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




802.11ac-40 CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




802.11ac-40 CHANNEL 6 CARRIER LEVEL




802.11ac-40 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11ac-40 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11ac-40 CHANNEL 7 CARRIER LEVEL




802.11ac-40 CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




802.11ac-40 CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




802.11ac-40 CHANNEL 8 CARRIER LEVEL




802.11ac-40 CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




802.11ac-40 CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




802.11ac-40 CHANNEL 9 CARRIER LEVEL




802.11ac-40 CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz




802.11ac-40 CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 1 CARRIER LEVEL




802.11ax-20 CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 2 CARRIER LEVEL




802.11ax-20 CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 6 CARRIER LEVEL




802.11ax-20 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 10 CARRIER LEVEL




802.11ax-20 CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 CHANNEL 11 CARRIER LEVEL




802.11ax-20 CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 3 CARRIER LEVEL




802.11ax-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 4 CARRIER LEVEL




802.11ax-40 CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 5 CARRIER LEVEL



802.11ax-40 CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz



802.11ax-40 CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz



802.11ax-40 CHANNEL 6 CARRIER LEVEL

