



RIG 800 PRO HS


1 FIT / AJUSTEMENT



2 CHARGE / CHARGER




CHARGE / CHARGER




OR


3 CHARGE INDICATION INDICATION DE CHARGE



4 CONNECT / CONNEXION







CONNECT / CONNEXION



OR

To adjust system audio settings,
check your console's user guide.



SOUND / SON

PS4™ PS5™ PC

Mic Monitor Level

Adjust mic monitoring

- 🔊 Mic monitor High
- 🔊 Mic monitor Medium
- 🔊 Mic monitor Off

🔊 master volume

©2021 NACON. NACON and RIG are trademarks of NACON. registered in the US and other countries. All trademarks are the property of their respective owners.
 "PlayStation", "PS5" and "PS4" are registered trademarks of Sony Interactive Entertainment Inc. All rights reserved. All other trademarks are the property of their respective owners.
 Patents: US D766,206; D800,092; CN ZL201630297792.3; EM 002814079; 003494897; TW D184698; patents pending.

Headset model: RIG800PRO-HS, Dongle model: RIG 800PRO-HS.
 100-1346-99 06.21



Recyclable where facilities exist

nacon | RIG

RIG 800 PRO HS

QUICK START GUIDE

GUIDE DE DÉMARRAGE RAPIDE