



NVNT	ax40	5270	Ant1	-3.454	10.99	Pass
NVNT	ax40	5270	Ant2	-1.664	10.99	Pass
NVNT	ax40	5270	Sum	0.543	10.99	Pass
NVNT	ax40	5310	Ant1	-2.557	10.99	Pass
NVNT	ax40	5310	Ant2	-3.453	10.99	Pass
NVNT	ax40	5310	Sum	0.028	10.99	Pass
NVNT	ax40	5510	Ant1	-5.48	10.99	Pass
NVNT	ax40	5510	Ant2	-1.985	10.99	Pass
NVNT	ax40	5510	Sum	-0.38	10.99	Pass
NVNT	ax40	5570	Ant1	-3.272	10.99	Pass
NVNT	ax40	5570	Ant2	-1.441	10.99	Pass
NVNT	ax40	5570	Sum	0.75	10.99	Pass
NVNT	ax40	5670	Ant1	-1.5	10.99	Pass
NVNT	ax40	5670	Ant2	-3.897	10.99	Pass
NVNT	ax40	5670	Sum	0.475	10.99	Pass
NVNT	ax40	5755	Ant1	-5.7	29.99	Pass
NVNT	ax40	5755	Ant2	-7.523	29.99	Pass
NVNT	ax40	5755	Sum	-3.506	29.99	Pass
NVNT	ax40	5795	Ant1	-5.664	29.99	Pass
NVNT	ax40	5795	Ant2	-6.35	29.99	Pass
NVNT	ax40	5795	Sum	-2.983	29.99	Pass
NVNT	ax80	5210	Ant1	-5.21	10.99	Pass
NVNT	ax80	5210	Ant2	-4.116	10.99	Pass
NVNT	ax80	5210	Sum	-1.618	10.99	Pass
NVNT	ax80	5290	Ant1	-6.502	10.99	Pass
NVNT	ax80	5290	Ant2	-5.205	10.99	Pass
NVNT	ax80	5290	Sum	-2.795	10.99	Pass
NVNT	ax80	5530	Ant1	-8.258	10.99	Pass
NVNT	ax80	5530	Ant2	-6.246	10.99	Pass
NVNT	ax80	5530	Sum	-4.126	10.99	Pass
NVNT	ax80	5610	Ant1	-3.694	10.99	Pass
NVNT	ax80	5610	Ant2	-6.55	10.99	Pass
NVNT	ax80	5610	Sum	-1.881	10.99	Pass
NVNT	ax80	5775	Ant1	-8.536	29.99	Pass
NVNT	ax80	5775	Ant2	-9.512	29.99	Pass
NVNT	ax80	5775	Sum	-5.986	29.99	Pass


PSD NVNT ax20 5180MHz Ant1




PSD NVNT ax20 5180MHz Ant2




PSD NVNT ax20 5200MHz Ant1




PSD NVNT ax20 5200MHz Ant2




PSD NVNT ax20 5240MHz Ant1




PSD NVNT ax20 5240MHz Ant2




PSD NVNT ax20 5260MHz Ant1




PSD NVNT ax20 5260MHz Ant2




PSD NVNT ax20 5280MHz Ant1




PSD NVNT ax20 5280MHz Ant2




PSD NVNT ax20 5320MHz Ant1




PSD NVNT ax20 5320MHz Ant2




PSD NVNT ax20 5500MHz Ant1




PSD NVNT ax20 5500MHz Ant2




PSD NVNT ax20 5600MHz Ant1




PSD NVNT ax20 5600MHz Ant2




PSD NVNT ax20 5700MHz Ant1




PSD NVNT ax20 5700MHz Ant2




PSD NVNT ax20 5745MHz Ant1




PSD NVNT ax20 5745MHz Ant2




PSD NVNT ax20 5785MHz Ant1




PSD NVNT ax20 5785MHz Ant2




PSD NVNT ax20 5825MHz Ant1




PSD NVNT ax20 5825MHz Ant2




PSD NVNT ax40 5190MHz Ant1




PSD NVNT ax40 5190MHz Ant2




PSD NVNT ax40 5230MHz Ant1




PSD NVNT ax40 5230MHz Ant2




PSD NVNT ax40 5270MHz Ant1




PSD NVNT ax40 5270MHz Ant2




PSD NVNT ax40 5310MHz Ant1




PSD NVNT ax40 5310MHz Ant2




PSD NVNT ax40 5510MHz Ant1




PSD NVNT ax40 5510MHz Ant2




PSD NVNT ax40 5570MHz Ant1




PSD NVNT ax40 5570MHz Ant2



PSD NVNT ax40 5670MHz Ant1



PSD NVNT ax40 5670MHz Ant2



PSD NVNT ax40 5755MHz Ant1