

# ARZOPA

## VistaPad

User Manual

ARZOPA

# Welcome

Thank you for choosing ARZOPA Vista Pad. Please take a moment to read this user manual carefully before using the tablet. Keep it for future reference to ensure a safe and optimal experience.

## Safety Information

**Vista Pad is designed with user safety as a top priority. However, improper usage may result in electric shock, fire, or damage to the device. To avoid such risks, please follow these guidelines during setup, operation, and maintenance:**

### General Safety Guidelines:

- Prevent Electric Shock or Fire: Do not expose the tablet to rain, liquids, or excessive moisture.
- Inspect Cables: Ensure all cables are securely connected and undamaged before use. If damaged, contact your retailer for assistance.
- Avoid Extreme Conditions: Keep the device away from excessive dust, humidity, or extreme temperatures. Do not place it in areas prone to moisture or direct sunlight.
- Prevent Intrusions: Avoid inserting foreign objects or letting liquids spill into the tablet.
- Use Certified Accessories: Always use accessories provided by ARZOPA or certified by the manufacturer to ensure compatibility and safety.
- Do Not Attempt Repairs: There are no user-serviceable parts inside the device. For any issues, contact ARZOPA customer support.

### To Avoid Injuries:


- Place the tablet on a stable, flat surface.
- Do not throw or drop objects on the screen, as this may cause damage.
- Turn off the tablet when not in use for extended periods.
- Keep out of reach of children to avoid potential harm or device damage.
- Use only accessories specifically designed for Vista Pad.
- Disconnect the power cord when the device will not be used for an extended period.
- During lightning storms, avoid contact with power cords or cables.

**To Protect the Device:**

- Do not press or scratch the screen with hard objects, as this may result in permanent damage.
- Use the recommended resolution for the best performance. Non-standard resolutions may lead to display issues.
- Avoid displaying static images for long durations to prevent screen retention.

For any technical problems, contact professional support or your retailer. Handle the device with care to prevent damage. Always lift the tablet using both hands, holding the edges securely.

# Operating Instructions



## Before First Use

- Inspect the device and ensure all accessories are included and undamaged. If there are any issues, contact your retailer immediately.
- To power on the Vista Pad, press and hold the power button located on the side of the device.
- Adjust the rear stand to your desired angle for a comfortable viewing experience, whether in landscape or portrait orientation.

# Maintenance and Cleaning

## Cleaning Guidelines

- Power off the Vista Pad and unplug any connected cables before cleaning.
- Use a soft, non-abrasive cloth for cleaning. For tougher stains, lightly dampen the cloth with a mild cleaning solution and wipe the surface gently.
- Avoid using cleaning agents containing alcohol, acetone, or other harsh chemicals.
- Do not spray liquid directly onto the screen to prevent seepage into internal components.

## Important Notes on Display Behavior

- Slight brightness variations may occur based on the displayed image—this is normal.
- Prolonged display of a static image may result in temporary screen retention. Use a screen saver or power off the device when not in use for extended periods.
- If the screen becomes unresponsive or displays unusual behavior, contact ARZOPA customer support for assistance.

# Warranty and After-Sales Service

## Warranty Coverage

Vista Pad includes a 1-year limited warranty.

- Within 7 Days of Purchase: You may request a refund, replacement, or repair for eligible defects.
- Within 15 Days of Purchase: You may request a replacement or repair for eligible defects.
- Within 1 Year of Purchase: You are entitled to free repairs for defects covered under warranty.

## Exclusions from Warranty

The warranty does not cover:

- Expired warranty period.
- Absence of valid proof of purchase.
- Screen issues with 3 or fewer dead or bright pixels.
- Damage caused by improper use, unauthorized repairs, or accidental drops.
- Damage due to natural disasters or external forces, such as power surges.

## Chargeable Repairs

For non-warranty repairs, fees will include labor and parts. Contact ARZOPA customer support for an estimate.

# Technical Specifications

Model	P1 Plus
Operating System	Android 14
Processor	Octa-core processor
RAM	8GB
Storage	128GB
Screen Size	16 inches
Resolution	2560 × 1600
Battery	44.6 Wh
Wireless Connectivity	Wi-Fi 802.11a/n/ac, 5GBand, Bluetooth 5.0

## Environmental Disposal

Dispose of Vista Pad in compliance with local electronic waste regulations. Improper disposal may harm the environment.

# Legal Disclaimer

ARZOPA reserves the right to modify product design and specifications without prior notice. Images and descriptions in this manual are for reference only; actual product details may vary.

Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2020 Dolby Laboratories. All rights reserved.

For assistance, contact:

Shenzhen G - world Technology Incorporated Company Support

Address: 1602, Xingtong Building, No. 88 Baoxing Road, Bao'an District, Shenzhen, China



**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.