



60 mm

60 mm

60 mm

60 mm

60 mm

60 mm

1

front

7

5

3

8

back

9

10

11

12

1

front

2

3

4

5

6

7

Contents in the box

PV-K01 1EA

Charging cable (Micro USB B-type, 5pin) 1EA

User manual 1EA

펀디언(주) / FUNDIAN INC.

서울 마포구 성암로 330, 325호 (DMC)펀디언창업센터

#02-530, Seongam-ro, Mapo-gu,

Seoul, Republic of Korea

contact@fundian.com

Designed by Fundian in Korea

Made in China

Installation (Bluetooth)

Android/ Windows PC/ Mac :

Turn on the keyboard, the keyboard will be found automatically at your device. To pair the keyboard, go to your device to open the Bluetooth and search, "PV-K01-a" will display on the Bluetooth searching list. Click and connect via Bluetooth. (If the keyboard is not found, proceed with the pairing manually as shown below.)

To disconnect from an existing connection and reconnect the keyboard to another device, hold down the BT button for 3 seconds, small dot LED will flash in white rapidly at 0.5 second intervals for one minute. (If the connection is not complete for one minute, the LED will extinguish and the pairing will also be terminated. Press the Bluetooth button again to connect.)

iPhone/ iPad/ Apple TV

Turn on the keyboard, hold down the Fn button and the BT button simultaneously for 3 seconds, small dot LED will flash in white rapidly at 0.5 second intervals for one minute. (If the connection is not complete for one minute, press the Fn button and the Bluetooth button again to connect.) To pair the keyboard, go to your device to open the Bluetooth and search, "PV-K01-a" will be displayed on the Bluetooth searching list. Click and connect via Bluetooth.

To disconnect from an existing connection and reconnect the keyboard to another device, hold down the Fn button and the BT button simultaneously for 3 seconds.

※Apple TV

If bluetooth connection error (infinite loop), you should reboot Apple TV and connect "PV-K01-a" again.

Connection for audio

Turn on the keyboard, the audio will be found automatically at your device. To pair "Audio", go to your device to open the Bluetooth and search, "PV-K01-audio" will display on the Bluetooth searching list. Click and connect via Bluetooth. If there is no "PV-K01-audio" or if the connection fails, you should reboot the keyboard.

LED indicator

Batt. LED

G

M.

M.

BT & Mode LED

Batt. LED

Solid blue

Charging (LED will be turned off if the battery is fully charged.)

Flashing blue

Low power (less than 25%)

When the battery is low, the blue LED light will blink to warn the user. The keyboard will be automatically turned off if the battery has been depleted.

Bluetooth & Mode Indicator LED

Solid white

Paired, Keyboard working

Slowly Flashing white

Auto Pairing

Rapidly Flashing white

Manual Pairing (by holding down the BT button for 3 seconds)

Features

※ The mouse and some keys may be different for each OS / IOS / iPadOS version.

※ Mouse cursor speed : 2-step, Fn + Space bar

Mode G

For PC games (e.g. Steam), Android mobile/ TV box games supporting the Bluetooth game controller

Mode 1

For Mac/ Windows/ Linux PC, Android

Jog → Mouse cursor controller

X/Y/A/B → Directional keys

L1/L, R1/R → "L", "R" button

R1/R → Mouse "R" button

Mode 2

For Mac/ Windows/ Linux PC, Android

Jog → Directional keys

X/Y/A/B → Home/Up/Down/End

L1/L, R1/R → Not supported

Apple iPhone/ iPad

Jog → Not supported

X/Y/A/B → Directional keys

L1/L, R1/R → Not supported

Apple TV

Jog → Not supported

X/Y/A/B → Directional keys

L1/L, R1/R → Enter key

A/S

1. Product failure or quality problem occurring within the first seven 77 days of purchase can be replaced with the same-specification product or refunded.

2. The following cases cannot be repaired free of charge even during the warranty period and are subject to paid repair only:

- Product has failed due to user error and/or user carelessness;
- User has disassembled or remodeled product at his/her discretion;
- While in use, product has received damage or has failed due to outside forces;
- Product failure due to use of peripherals/cables not provided during purchase;
- Product failures other than those mentioned above that are recognized as being attributable to user error.

3. For warranty, please contact the (sole) distributor or seller based in the region where you made the purchase.

FCC Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Wireless Keyboard

PV-K01

사용자 설명서

User Manual

POWER VESSEL

8 page

9 page

10 page

11 page

12 page

1 page

사 양

- Transmission mode : HID / Bluetooth 4.0-EDR / Audio / Bluetooth 4.2 CSR, up to 10 meters
- Transmission power : ±5db
- Power supply : Rechargeable 450mAh polymer Li-ion battery
- Charging voltage : 4.4 ~ 5.25V
- Charging current : < 300mA
- Working current : < 40mA
- Dimensions : 128x66x10 mm
- Weight : 67g

제품 구성

FRONT

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

TOP

연결하기 (블루투스)

Android/ Windows PC/ Mac :

키보드 연결을 하면, 연결하려는 기기에서 키보드가 자동으로 검색됩니다. 키보드를 제어할 연결하려면, 연결하려는 스마트폰이나 PC의 블루투스 설정에 들어가서 검색된 기기 중에 "PV-K01-a"를 찾아 선택하여 블루투스 연결을 시작합니다. (단! 1분동안 블루투스 연결을 완료하지 않으면, LED는 꺼지고 페어링 대기상태도 종료합니다.)

기존 연결된 기기와의 연결을 끊거나 다른 기기와의 연결하기 위해서는, Fn+Fn과 블루투스 버튼을 동시에 약 3초동안 누릅니다.

iPhone/ iPad/ Apple TV

키보드를 제어할 연결하려면, Fn+Fn과 블루투스 버튼을 동시에 약 3초동안 누릅니다. 현재의 LED가 0.5초 간격으로 빠르게 깜빡이며 1분간 블루투스 대기상태가 지속됩니다. (단! 1분동안 블루투스 연결을 완료하지 않으면, LED는 꺼지고 페어링 대기상태도 종료합니다.)

연결하려는 애플기기의 블루투스 설정에 들어가서, 검색된 기기 중에 "PV-K01-a"를 찾아 선택하여 블루투스 연결을 시작합니다.

기존 연결된 기기와의 연결을 끊거나 다른 기기와의 연결하기 위해서는, Fn+Fn과 블루투스 버튼을 동시에 약 3초 동안 누릅니다.

※Apple TV

연락 블루투스 연결 중 계속 연결대기 상태의 오류가 발생한다면, 애플TV에서의 연결을 기다린 후 "PV-K01-a"를 다시 연결해주세요.

오디오 연결

키보드 연결을 하면, 연결하려는 기기에서 오디오가 자동으로 검색됩니다. 오디오 기능을 제어할 연결하려면, 연결하려는 기기에서 블루투스 설정에 들어가서 검색된 기기 중에 "PV-K01-audio"를 찾아 선택하여 블루투스 연결을 시작합니다. 만약 "PV-K01-audio"가 검색되지 않거나 연결 오류가 발생하면, 키보드 연결을 기다린 후 "PV-K01-audio"가 검색되는지 다시 확인합니다.

LED동작 설명

Batt. LED

G

M.

M.

BT & Mode LED

Batt. LED

충전 중 (완충 시 LED 꺼짐)

파란색 점멸

배터리 충전 필요 (충전량 25%이하)

블루투스 & 모드 확인용 LED

원색 점등

블루투스 연결됨, 키보드 작동 중

원색 (느리게 점멸)

자동 페어링 대기상태

원색 (빠르게 점멸)

수동 페어링 대기상태 (3초동안 블루투스 버튼을 누를 때)

Features

※ 마우스와 일부 입력키들은 사용기기의 OS에 따라 다를 수 있습니다.

※ 마우스 커서 속도 조절 : 2단계, Fn + Space bar

Mode G

게임 컨트롤러를 지원하는 PC게임(스팀 등), 안드로이드 모바일/TV 박스 게임에서 사용

모드 1

맥/윈도우/리눅스 PC, 안드로이드

조그 → 마우스 커서 사용

X/Y/A/B → 방향키 사용

L1/L, R1/R → 방향키 사용

R1/R → 마우스 오른쪽 버튼

모드 2

맥/윈도우/리눅스 PC, 안드로이드

조그 → 방향키 사용

X/Y/A/B → Home/Up/Down/End

L1/L, R1/R → 지원안됨

맥용 이어볼/이어패드

조그 → 방향키 사용

X/Y/A/B → 지원안됨

L1/L, R1/R → 지원안됨

맥용 TV

조그 → 지원안됨

X/Y/A/B → 방향키 사용

L1/L, R1/R → Enter 키

제품 사용 시 주의사항

- 제품을 건조한 상태로 보관하시고, 제품의 손상을 방지하기 위하여 습기가 많은 장소에 보관하지 마세요.
- 제품을 직사광선이나 고온으로부터 떨어지지 보관하세요. 고온은 제품의 내부 회로 또는 배터리에 손상을 줄 수 있습니다.
- 제품을 극도로 추운곳에 보관하지 마세요. 내부 회로가 손상될 수 있습니다.
- 제품을 침수로 분해하려고 시도하지 마세요. 제품을 무단으로 분해 시켜 제품에 복구 불가능한 손상을 줄 수 있습니다.
- 지연이나 기타 단단한 바닥에 떨어뜨리지 마세요. 내부회로가 손상될 수 있습니다.
- 화학물질이나 세제를 사용하여 제품을 닦지 마세요. 제품 외부 또는 내부에 손상을 줄 수 있습니다.
- 불확정한 물체로 제품 외관을 긁지 마세요.
- 전자파나 기타 무선전계를 근처에서 사용하지 마세요. 블루투스통신에 방해가 될 수 있습니다.
- 본 키보드는 내용 리튬이온 배터리를 사용합니다. 안전을 위해 충전제(불꽃)와 충전기는 인공된 제품만 사용하세요.

A/S 안내

1. A/S 유요기간은 제품을 구매하신 날로부터 12개월이며 유요기간내 제품의 고장이 발생 시 무상으로 수리를 받으실 수 있습니다.

2. 판매후 7일 이내에 제품의 고장 또는 품질 이상이 발생 시 동일한 사양의 제품으로 교환 또는 환불이 가능합니다.

3. 다음과 같은 경우에는 A/S 유요기간 이내에도 무상 수리를 받으실 수 없으며 유상 수리가 적용됩니다.

- 사용자의 과실 및 부주의로 인하여 고장이 발생한 경우
- 제품을 임의의 물체 또는 개조한 경우
- 제품 중 외부의 충격으로 인한 제품의 손상 또는 고장의 경우
- 제품 구매 시 제공되지 않은 수리장치 또는 케이블 등의 사용으로 인한 고장의 경우
- 기타, 이용자의 과실로 인하여 제품의 고장으로 인정되는 경우

4. A/S 접수처 : 펀디언(주) / TEL. 1666-1611

Specification

- Transmission mode : HID / Bluetooth 4.0-EDR / Audio / Bluetooth 4.2 CSR, up to 10 meters
- Transmission power : ±5db
- Power supply : Rechargeable 450mAh polymer Li-ion battery
- Charging voltage : 4.4 ~ 5.25V
- Charging current : < 300mA
- Working current : < 40mA
- Dimensions : 128x66x10 mm
- Weight : 67g

Product Overview

FRONT

1

2

3

<