


PHOTOGRAPHS OF THE TEST CONFIGURATION


Radiated Emission Test (Frequency below 30MHz)

Mode A1~A4 (Adapter 1)




Radiated Emission Test (Frequency above 30MHz)

Mode A1~A4 (Adapter 1)




Radiated Emission Test (Frequency above 30MHz)

Mode B1~B4 (Adapter 2)




Radiated Emission Test (Frequency above 30MHz)

Mode C1~C4 (Adapter 3)





Radiated Emission Test (Frequency above 30MHz)

Mode D1~D4 (Adapter 4)




Radiated Emission Test (Frequency above 30MHz)

Mode E1~E4 (Adapter 5)




Radiated Emission Test (Frequency above 30MHz)

Mode F1~F4 (Adapter 6)




Radiated Emission Test (Frequency above 30MHz)

Mode G1~G4 (Adapter 7)




Radiated Emission Test (Frequency above 30MHz)

Mode H1~H4 (Adapter 8)




Radiated Emission Test (Frequency above 30MHz)

Mode I1~I4 (Adapter 9)




Radiated Emission Test (Frequency above 30MHz)

Mode J1~J4 (Adapter 10)



Radiated Emission Test (Frequency above 30MHz)

Mode K1~K4 (Adapter 11)



Conducted Emission Test

Mode A1~A4 (Adapter 1)



Conducted Emission Test

Mode B1~B4 (Adapter 2)



Conducted Emission Test

Mode C1~C4 (Adapter 3)



Conducted Emission Test

Mode D1~D4 (Adapter 4)



Conducted Emission Test

Mode E1~E4 (Adapter 5)



Conducted Emission Test
Mode F1~F4 (Adapter 6)



Conducted Emission Test

Mode G1~G4 (Adapter 7)




Conducted Emission Test

Mode H1~H4 (Adapter 8)




Conducted Emission Test

Mode I1~I4 (Adapter 9)



Conducted Emission Test
Mode J1~J4 (Adapter 10)



Conducted Emission Test
Mode K1~K4 (Adapter 11)

