

Safety Instructions

- 1. Heed all safety warnings and follow all instructions.
- 2. Only use a dry cloth to clean this product.
- 3. Do not block any interface of the product. Please use the product according to the instructions provided by the manufacturer.
- 4. Do not place this product near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 5. Protect the power cord to prevent it from being walked on or pinched, particularly at the plug, receptacle, and other points where it exits the product.
- 6. Please use attachments/accessories specified by the manufacturer. 7. In case of thunderstorm or if the product is not to be used for a long time, please unplug it.
- 8. All repairs should be performed by professional repair personnel designated by the manufacturer (or authorized dealer). Repairs are required if the product is damaged, such as liquid splashing or debris entering the product, or the product is exposed to rain or moisture, resulting in malfunction, or the product falls and is damaged.
- There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type. The battery must not be exposed to excessive heat such as sunlight, fire or similar environments
- 14. The product is not equipped with a power adapter when it is shipped. When using it, please choose a power adapter that has passed national certification. The output voltage of the adapter is 5V DC and the output current is not less than 1A.



Before using the product, please check the integrity of the internal accessories.


List of items:







4 - Button: short press to go to the



Interface and function buttons

- the light mode, long press to turn on/off the light
- ② + Button: Short press to play next 6 AUX input interface
- 3 M key: short press to play/pause, (8) Indicator Lights long press to switch modes; double-click to enter/exit TWS 9 TF-Card input interface pairing in BT mode and AUX mode when Bluetooth is not Rass Enhanced Diaphragm RGB Color Lights
- previous song, long press to reduce the volume



Power button

- Power switch: Press and hold the power button for 2 seconds to turn on the device, and press and hold it again to turn off the device.
- Reset function: If the device freezes during use, press and hold the power button for 8 seconds to reset it.
- * To protect the lithium battery, please charge the speaker before first use.





- The speaker will automatically enter BT pairing mode after it is turned on, or you can long press the "M" button in other modes to switch to BT pairing mode. The blue indicator light will flash. Turn on the BT of your phone or device, search for "M5" and click pairing. There will be a prompt tone after the BT connection is successful, and the blue indicator light will be on.
- When the speaker is turned on, it will automatically reconnect to the last Bluetooth device that was paired before it was turned off and that has not been cleared from the pairing list.
- If no device is connected to the speaker for 30 minutes, it will automatically shut down.

This device complies with Part 15 of the Fcc Rules. Operation is subject to the following two conditions: (1) this device may notcause hamful interference., and (2) this device must accept any interference received, induding interference that may causeundesired operation NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Pat 15 ofthe FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residenialinstallation. This equipment generates, uses and can radiate radio frequency energy and, if notinstalled and used in accordancewith the instructions, may cause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation.

- --Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Waming: changes or modifications not expressly approved by the party responsible for compliance could void the user'sauthority to operate the equipment The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposurecondition without restriction



Lighting mode switch

Long press the light button to turn on/off the light; short press to switch the light effects.


RGB Light 1. Colorful breathing gradient

- 2. Monochrome mutation
- 3. Music flashes

Indicators

- Bluetooth: The blue light flashes slowly in the search state, and the blue light is always on when the connection i successful/playing/pausing TWS: The blue light flashes quickly when
- entering/searching status, and flashes slowly when pairing is successful.
- Disconnect the current connection: restor to the BT disconnected state
- TF card/AUX mode: blue light flashes slowly
- Charging: Charging red light is always on, full red light is off Low power: RGB red light flashes

753 753




- When the device is powered on, insert a TF card, it will automatically switch to MP3 playback mode and play the audio files in the TF card.
- Short press the +/- button to switch to the next or previous song, and long press to increase or decrease the volume.
- •TF card support format: FAT32, maximum supported

Supported audio formats: MP3/WAV (sampling 8K~48K).



When the device is powered on, plug in the audio cable and the speaker will automatically switch to AUX mode. Connect the audio input plug to the playback device or the computer audio output interface (headphone jack), select "speaker output" or "headphone" on the device and click OK to confirm






TWS Mode

- Two M5s can form a stereo pair.
- •Turn on both speakers at the same time and neither is connected to any BT device. Double-click M button of any speaker to enter the TWS pairing mode, and they will automatically form a stereo pair. The double-clicked speaker is the main unit (left channel) and the other is the slave unit (right channel). In this mode, the main and slave units have synchronized functions, and the buttons on any speaker can be used to adjust the functions synchronously.
- Disconnect the mobile phone link and double-click the M button again to release the TWS state
- •The TWS function is only available in BT mode.





Charging&Low Battery Reminder

- When the battery level of the speaker is less than 20%.
- the RGB light on the top of the speaker will turn red. • When the speaker is low on power, there will be a voice prompt, and you should charge the speaker in time.
- The red indicator light is always on when charging, and goes out when fully charged.
- It takes about 3 hours for the battery to be fully charged from empty.

Precautions for use

Specifications

Signal-to-Noise Ratio ≥70dB

Speaker impedance 4Ω

Frequency Response 80Hz~20KHz

BT distance

Internal battery

Charging time

Product size

Charging voltage

· When the speaker is in low power or not in use for a long time, the battery should be fully charged and then turned off for storage to extend and protect the battery life.

10M

DC 5V

About 3hrs

76*76*118mm

Lithium battery 3.7V

• It is recommended that you avoid using the speaker while charging. Using the speaker while charging can easily cause overheating, and long-term discharge at high temperatures can increase battery loss.