

---


## Test Setup photographs (DSS & DTS)

---


**EUT Position: X-axis**



**EUT Position: Y-axis**



**EUT Position: Z-axis**



---

## Test Setup photographs (DSS & DTS)

---

### EUT with Dual Display: 0 degree



### EUT with Dual Display: 180 degree




### EUT with Dual Display: 360 degree



---

## Test Setup Photo of Radiated Measurement (0.009 ~ 30MHz)


---



---

## Test Setup Photo of Radiated Measurement (below 1000MHz)

---






---

## Test Setup Photo of Radiated Measurement (Above 1GHz)

---



---

## Test Setup photo of Conducted Emissions (DSS & DTS)

---

