


802.11ax-HE40 AVGPDS - Ant 0 / Ant 0 + 1 + 2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



802.11b AVGPSPD - Ant 1 / Ant 0 + 1 + 2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPDS - Ant 1 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AVGPDS - Ant 1 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 1 / Ant 0 + 1 +2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ac-VHT20 AVGPSPD - Ant 1 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ac-VHT40 AVGPSPD - Ant 1 / Ant 0 + 1 +2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE20 AVGPSPD - Ant 1 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)



802.11ax-HE40 AVGPDS - Ant 1 / Ant 0 + 1 + 2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



802.11b AVGPSPD - Ant 2 / Ant 0 + 1 +2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPSPD - Ant 2 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AVGPDS - Ant 2 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 2 / Ant 0 + 1 +2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ac-VHT20 AVGPSPD - Ant 2 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ac-VHT40 AVGPDS - Ant 2 / Ant 0 + 1 +2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE20 AVGPSPD - Ant 2 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE40 AVGPSPD - Ant 2 / Ant 0 + 1 + 2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)



802.11b AVGPSPD - Ant 3 / Ant 0 + 1 + 2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPSPD - Ant 3 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AVGPDS - Ant 3 / Ant 0 + 1 +2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 3 / Ant 0 + 1 +2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ac-VHT20 AVGPDS - Ant 3 / Ant 0 + 1 +2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)

