





Maintenance reminder: Wipe your earbuds regularly to keep them clean.	Depending on the operating system, you can check the battery status on the negative one screen interface or in the top notification bar of your phone.	"Sync function locations vary across systems. Here's how to find the sync toggle: iOS: Automatic system synchronization (no manual setup required) Android: Settings > Bluetooth > Headphone Settings > Enable Volume Sync Legacy Android: Settings > Search bar (type "Volume Sync") > Toggle ON Pro tip: For optimal volume control and enhanced audio quality, activate volume sync before using your earphones."	 Turn on earphones - Enable Bluetooth on both Device A & B - Connect via device interface (fast pairing within 20s). Open charging case (with earphones inside) Connect Device A, then triple-tap both earbuds' touch controls to enter pairing mode again for Device B. If already connected to two devices, disconnect one first. (Note: Bluetooth implementations vary across systems. If auto-reconnect fails, manually connect via device Bluetooth settings or toggle Bluetooth off/on.) 	Call Mode Press & hold: End/Reject call Normal Mode (Non-music, non-call mode) •••• Quadruple tap: Enter/Exit Gaming Mode	Simultaneously tap both earbuds' touch control areas 3 times: Manually activate/deactivate pairing mode Press and hold both earbuds' touch controls for 3 seconds: Restore factory settings	Factory Reset White/Red alternating flash Charging Case White: 80%+100% Battery Status Green: 50%+80% (Display when case Orage: 20%+50% opened) Red: 0%+20% Fully Charged White light on for 10s NTC Thermal Protection Red light flashing for 10s Earbud Detection (In/Out) Charging Case Battery Indicator Light Flashes Twice Quickly	in dry conditions. Charge case at least monthly. Battery Warning This product contains a built-in battery. Please note the following: 1. Charge promptly when the battery is low. If unused for extended periods, power on the device very 3 months until the battery is depleted, then fully recharge it to prevent damage. Use and store the product within recommended temperature ranges. 2. Do not disassemble, impact, crush, or expose to fire. Discontinue use if severe swelling occurs. Avoid high-temperature environments. If battery life significantly shortens, cease use and consult professionals	 Instructions, may cause narmul interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help 	conjunction with any other antenna or transmitter. 2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator and your body. FOC ID: 2AR3E-LNTW3
11	12	13	14	15	16	17	18	19	20









物料编码	: LNPI01030A			表面工艺: ①单黑印刷, ②骑马钉(双钉60p) , ③啤,	
物料名称	: LinkLike Halo2-入耳式TWS真无线降噪耳机(线 ⁻	下)说明书			
	材质: 银禾样合100克本白双胶纸	单 位: mm	平		
结	成型尺寸: 60*100mm	刀 线:	面	印刷颜色: K	
构	结构设计: 黄从峰	压线:	部	平面设计:潘莹	
部 分	结构修改:	针刀线:	一分	平面修改:	
	日 期:	刀线相交:		日 期: 2025.02.13	
	备注: 特别注意事项	坑 纹:		备 注:	
特别说明	 :所有物料需要符合蓝禾《有害物质限用管理程序	^雾 》LH-WI-0004(环保要求)			