1 제품사양

WEB - III OFFICIAL LIGHT STICK LIVE

771:83 x 83 x 229 (mm)

무게 : 약 167g

재질 : ABS, PC, STEEL

구성품 : 응원봉, 스트랩, 사용자설명서

거저지 : 안카라이 ΔΔΔ 거저지 3개

작동시간 : 약 4시간

모델명 : I-KF-V3

KC인증 : 隆 R-R-RTr-I-KF-V3

FCC ID: 2AS3Z-I-KE-V3

기획 및 판매 : EDAM ENTERTAINMENT

제조사 : 주식회사 비트로 제조구가 : 대하미구

2 주의사항 ⚠

- 강한 충격이나 물이 닿으면 고장의 원인이 됩니다.
- 임의로 분해 및 조립하지 마세요.
- 정품 알카라인 AAA 건전지를 사용하세요.
- 사용하지 않을 시에는 건전지를 제거해 주세요.
- 건전지는 영/유아의 손이 닿지 않는 곳에 보관하세요.
- 수명이 다 되 거저지는 지정되 폐기 장소에 폐기하세요
- 반드시 건전지의 +, 극성을 잘 확인하여 올바른 극성 방향으로 장착하세요.
- 건전지의 잘못된 장착은 제품 고장의 원인이 되며 화재 및 화상의 위험이 있습니다.
- 본 제품은 무선 운용 중 혼선의 가능성이 있습니다.

3 사용 모드 설명




모드설정

- · 전원 ON/OFF (버튼 롱클릭)
- 버튼을 3초 정도 길게 누르면 전원이 ON/OFF 됩니다.
- 일반 모드 (버튼 원클릭)
- 전원 ON 상태에서 버튼을 짧게 누르면 8가지 컬러 모드가 변경 됩니다.
- 애플리케이션 모드 (버튼 더블클릭)
- 버튼을 더블클릭하면 애플리케이셔 모드로 저화된니다 (파란북 깜빡) 다시 버튼을 더블클릭하면 일반 모드로 돌아옵니다.
- (애플리케이션 모드 시 컬러 변경 작동이 되지 않으며 불량이 아닙니다.)

애플리케이션 모드는 응원봉을 연동하여 콘서트에서 다양한 연출을 즐길 수 있습니다. 향후 애플리케이션을 사용하여 콘서트 및 다양한 콘텐츠를 응원봉과 함께 즐길 수 있습니다.

4 건전지 삽입 및 교체

※ 건전지가 저전압일 경우 전원이 자동으로 차단되오니 새건전지로 교체 바랍니다.



⚠ 건전지 주의사항

- (-) 극부터 (+) 극 순으로 바르게 넣으세요. 역 삽입 시 발열로 인한 파열 및 누액의 위험이 있습니다.
- 건전지 부분이 갑자기 뜨거워졌을 때에는 바로 건전지 부분을 부리해 주세요 '화상의 위험이 있으니 손으로 잡지 마세요.)
- 정품 알카라인 AAA 건전지를 사용해 주시기 바랍니다.
- (정품이 아닐 경우 제품에 손상이 있을 수 있습니다. 꼭 정품 건전지를 사용해 주세요.)
- 충전, 분해, 단락, 가열하지 마세요. 폭발 또는 누액으로 인해 상해를 입을 위험이 있습니다.
- 누액의 가능성이 있으니 사용이 끝난 건전지는 즉시 기기에서 꺼내세요.
- 매회 공연 시 새로운 건전지를 사용해 주시기 바랍니다.
- 새 건전지와 사용한 건전지, 그리고 서로 다른 건전지와 혼용하지 마세요.
- 전지의 포장을 벗긴 채로 주머니나 핸드백 등에 보관하지 마세요.

5 A/S 처리 규정

- 제품 구매 후 확인되는 불량/교화은 판매처에 무의 바랍니다.
- 무상 보증 기간은 구입한 날로부터 6개월이며, 보증 기간 이내라도 고객 과실 및 파손에 의한 유상 A/S 대상으로 판단되는 경우 별도 수리비가 청구되오니 이점 반드시 숙지해 주시기 바랍니다.
- 제품 A/S 접수비(왕복 배송비)는 제조사 부담 후 유상 수리 대상일 시 고객 부담입니다. - 메일근 서저스 및 사다되 H&에 하해서 A/S 서비스가 가능하니다
- 메일 발송 시, 구매 영수증(구매 날짜 포함 필수)과 자세한 불량 증빙 내역을 포함하여
- 글 등 하십니다. 상담 및 접수가 완료된 후에 택배 발송하여 주시기 바랍니다.
- 무상 보증 기간 : 무상 보증 기간(6개월) 이내에 이래의 현상이 발생할 시 제품 교환 서비스를 받을 수 있으나 제품 A/S 전수비(왕복 배송비)는 제조사 부담 호 유상 수리 대상일 시
- ※ 제품 교화 대산
- ^ 세움 표는 데이 LED 동작 불량 전원 버튼 오작동에 따른 동작 불량 동봉된 배터리 소켓 불량 - 패키지 손상은 불량 및 교환 사유가 되지 않습니다.
- 유상 A/S : 유상 A/S 기간은 구입 후 최대 1년 이내 입니다. 무상 보증 내용에 해당하지 않는 제품 이상의 경우 유상으로 A/S를 받을 수 있습니다.
- 제품 A/S 접수비(왕복 배송비)는 고객 부담입니다.

※ 으사 4/5 대사

- 사용 중 고객 과실에 의한 기구물 및 회로물의 파손 임의 개조를 위한 제품 조립을 강제 파손하는 경우
- 비인증 배터리 사용 등으로 인한 회로부의 파손
- 전원을 넣은 상태에서 침수, 우천 시 사용 등에 따라 회로부의 파손 및 내부 침수

6 A/S 신청 접수처

TEL: 02) 783-1945 WEB: www.beatro.co.kr/beatroas@beatro.co.kr 품질보증기간: 구매일로부터 6개월

A/S 전수방법

정상적으로 사용한 제품의 경우 전화/이메일을 통한 고객상담 후, 제품 수리 및 교환

고객 과실의 경우 고객 상담 시, 수리 비용과 택배 비용을 포함하여 안내드립니다.



IU OFFICIAL LIGHT STICK I-KE

1 Specification

Product : ILLOFFICIAL LIGHT STICK I-KE

Size: 83 x 83 x 229 (mm) Weight: About 167g

Materials : ABS. PC. STEEL

Components : Light stick, Strap, User manual

Battery : AAA BATTERY 3EA

Operating : About 4Hours

Certification Model : I-KE-V3 KC : KR-R-BTr-I-KE-V3

FCC ID: 2AS3Z-I-KE-V3

Planning : EDAM ENTERTAINMENT

Manufacture : BEATRO Co., Ltd. Country of manufacture : KORFA

2 Caution<u>∧</u>

- If a strong or exposure to water will cause damage.
- Do not disassemble or assemble on your own
- Please use a genuine alkaline AAA batteries.
- Please remove the batteries when not in use, - Keep batteries in a safe place, out of children reach.
- Do segregate your product and used batteries from household waste for recycling, where possible, according to local laws,
- Insert batteries correctly, following the symbols for positioning the positive (+) and negative (-) ends of each battery. If not, it may cause product malfunction and overheating which may result fire or burns.
- There's a possibility of radio frequency interference during wireless operation.

3 How to use




MODE

- · POWER ON/OFF (Button Long Click)
- Press and hold the button for about 3 seconds to turn the power on/off.
- Normal Mode (Button One Click)
- When the power is on, pressing the button briefly changes the 8 color modes.
- Application Mode (Button Double Click)
- Double-click the button to switch to Application mode (blue blinking), and double click the button again to return to color change mode. (The Application mode does not operate the color change and is not defective.)

4 Replacing Batteries

* If the battery is low voltage, the power is automatically power off, so please replace it with a new battery.



⚠ BATTERY CAUTION

- Add the correct order from (-) to (+) pole.

 There is a risk of ruptures and leaks due to heat in reverse injection.
- Remove the battery part immediately when the battery part suddenly heats up. (Don't hold it with your hands as there is a risk of burns.)
- Place use genuine alkaline AAA hatteries
- (If not genuine, there may be damage to the product, Be sure to use a genuine battery.)
- Do not charge disassemble short circuit heat. Risk of injury due to explosion or leakage.
- Remove the battery from the machine immediately after use as it may cause leakage. - Please use a new battery for each performance
- Do not mix new batteries with used batteries and other batteries, Do not store batteries in a pocket or bag with the battery unpackaged.

5 Warranty Period and Repair Service

- Any defect replacement or refund of the product please contact your dealer
- Free warranty period is 6 months from the date of purchase. Even within the free warranty period, if the defects of the product occurred by the customer's fault
- repair cost will be charged. - The product A/S application fee (round trip shipping fee) shall be paid by the
- customer if it is subject to paid repair after the manufacturer pays.

 Repair service is only provided after requesting the service through an email.
- Please send the product after application and consultation is completed. Replacement Service: If the following phenomenon occurs within the warranty period (6 months), the product exchange service can be provided, but the product A/S application fee (round trip shipping fee) will be paid by the manufacturer.

% Free A/S

- Defects of operation of LED and Wireless Malfunction of the power button - Bad battery socket. - Package damage isn't eligible for a refund or replacement.
- Paid Repair Service: The paid warranty period is up to 1 year after purchase. In case of products that are not covered by free warranty, you can get warranty at a cost, and the product A/S application fee (round trip shipping fee) is borne by the customer.

- After the free warranty, (6 months after the date of purchase
- Damages on the product or the circuit caused by customer's fault.
- Disassemble the product for any modification. Damages on the circuit by using non-certified battery.

If it's subject to paid repair it's a customer's burden.

- Damage to circuits and internal flooding due to inundation or rain.

6 Customer Service Center

Product inquiry and customer service

TEL: +82) 2-783-1945 WEB: www.beatro.co.kr/beatroas@beatro.co.kr Warranty: 6 months from date of Purchase

How to get customer service

In case of proper use, we will inform how to repair or replace the product after customer consultation via phone call or email. In case of improper use due to customer's fault, we will inform repair cost including logistic cost for customer service.

FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following

Into service company of the company

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

This sub-ment has been tested and found to comply with the limits for Class 8 dissillationies, packant to part 5 of the CDR also. These limits are designed to provide nearonal protection against harmful interference in a resident in statistical protection against harmful interference in a residential testalisation. This equipment persentes, uses and care radiate radial refective energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radia communications. However, there is no guarantee that interference with or to occur to radio communications. However, there is no guarantee that interference with or the occur to reduce communications in some control and used to the control that interference by one or more of the following measure.

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is co

- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter. Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposur





