

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. This product is compatible with all wireless audio devices, Bluetooth® and non-Bluetooth®.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

©2025 Prime Brands Group. SOAR is a trademark of Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufacturers listed. Made in China.
Prime Brands Group • Brooklyn, NY • www.shopsoar.com

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.




WIRELESS SPEAKER + BOTTLE OPENER

Model: BTX9

PRODUCT KEY

- A. Power Switch
- B. Charging Port
- C. Safety Lanyard
- D. Bottle Opener



SPECIFICATIONS

Bluetooth version: JL V5.3	Charging time: 1h
Working distance: 10M	Speaker size: 52mm 3Q5W
Battery: 3.7V 600Mah	Power rating: 5W
Charging port: TYPE C	Material: ABS
Playing time of 70% volume: 10Hours	

CHARGING

The Bottle Opener Speaker works on an internal rechargeable Lithium Battery. Please fully charge your speaker before initial use.

To charge the battery use the included USB-Type C cable. Insert the Type C Cable end into the charging port (B) on the bottom of the product. Then plug the USB end into a computer port or wall charging adapter.

The charging indicator light will glow red when connected and charging. When the battery is full the red light will turn off. Disconnect the speaker when fully charged.

PAIRING

Turn on your Wireless Speaker by pressing the circular power button next to charging port.

The blue indicator light will flash quickly. This shows the speaker is in pairing mode and searching for your bluetooth device.

Turn on the Bluetooth function on your device, then search for the list of available devices for "BTX9". Select it and your device will pair without password. If a password is required enter "0000". The blue indicator light will begin to flash slowly when a successful pair is completed.

Once successfully paired your device will automatically pair with the speaker when turned on.

OPERATION

The Wireless Speaker has a range of 32 feet (10 meters).

Use your wireless audio device to control the audio, volume, and play / pause functions.

Turn off the unit when not it use.

TRUE WIRELESS PAIRING

Before using TWS function make sure both speakers are not connected to devices.

Turn on both speakers and they will search for each other automatically. When successfully connected a tone will sound.

Once paired to each other, select "BTX9" from your audio devices Bluetooth® menu.

WARNING

This device is not a toy and should be kept away from children. The product must not be dropped or subjected to impact. Do not use the device in humid environments or in extremely hot / cold temperatures. Do not use chemicals or abrasive detergents to clean the product. Please return for repairs if the product is defective. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.