

SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Front	
2	Rear	
3	Bottom	
4	Left	
5	Right	
6	Top	
		

Phantom Position : Head	EUT side : Right Cheek
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Right Tilted
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Left Cheek
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Left Tilted
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Front
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat	EUT side : Rear
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Left
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat	EUT side : Right
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Top
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Bottom
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Bottom
Spacing to phantom : 0 mm	Accessory : N/A
	