




11B_Ant1_2462_0~Reference




11B_Ant1_2462_30~1000




11B_Ant1_2462_1000~26500




11G_Ant1_2412_0~Reference




11G_Ant1_2412_30~1000



11G_Ant1_2412_1000~26500




11G_Ant1_2437_0~Reference




11G_Ant1_2437_30~1000




11G_Ant1_2437_1000~26500






11G_Ant1_2462_0~Reference




11G_Ant1_2462_30~1000




11G_Ant1_2462_1000~26500







11N20SISO_Ant1_2437_0~Reference




11N20SISO_Ant1_2437_30~1000




11N20SISO_Ant1_2437_1000~26500



11N20SISO_Ant1_2462_0~Reference



11N20SISO_Ant1_2462_30~1000



11N20SISO_Ant1_2462_1000~26500



11.7. APPENDIX G: DUTY CYCLE

11.7.1. Test Result

Test Mode	On Time (msec)	Period (msec)	Duty Cycle x (Linear)	Duty Cycle (%)	Duty Cycle Correction Factor (dB)	1/T Minimum VBW (kHz)	Final setting For VBW (kHz)
11B	8.42	8.45	0.9964	99.64	0.02	N/A	0.01
11G	1.40	1.44	0.9722	97.22	0.12	0.71	1
11N20SISO	1.31	1.35	0.9704	97.04	0.13	0.76	1

Note:

Duty Cycle Correction Factor= $10\log(1/x)$.

Where: x is Duty Cycle (Linear)

Where: T is On Time

If that calculated VBW is not available on the analyzer then the next higher value should be used.

If the EUT is configured to transmit with duty cycle $\geq 98\%$, set VBW $\leq RBW/100$ (i.e., 10 kHz) but not less than 10 Hz.



11.7.2. Test Graphs



END OF REPORT