

### Using with a Wired Device

Insert the 3.5 mm connector of the supplied RCA cable into the 3.5 mm Auxiliary Input port on the side of the subwoofer. Connect the RCA connectors to the RCA ports on your TV or other media device, matching the connectors to the ports by color.

To connect to a headphone jack, plug one end of the included 3.5 mm auxiliary cable into the 3.5 mm Auxiliary Input port on the side of the subwoofer. Plug the other end into the headphone jack on your media-playing device.

While the audio system's aux port is in use, the LED Indicator will show **solid BLUE**, and Bluetooth connections will be disabled.

### Using the Lights

- Short press the [LED MODE] Button to turn ON/OFF the LED light and to cycle through the LED light modes.

## Compliance Information

### FCC Information

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Radiation Exposure Information

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

### Rating Label Definitions



Direct Current



This symbol indicates that information could be exchanged between wireless devices such as personal digital assistants (PDAs), mobile phones, laptops, computers, printers and digital cameras via a secure, low-cost, globally available short-range radio frequency band. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

## Warranty Information

### 90-Day Limited Warranty

Territory: United States

### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

### To obtain warranty service:

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com) and select "Support".
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China  
Designed in USA  
v1.04-2024

# ART+SOUND™

## 3.1 Surround Sound System



## User Manual

AR309224

## Before You Begin...

### Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

#### • READ CAREFULLY AND KEEP THIS MANUAL

- **THIS IS NOT A TOY**, please keep away from children and pets
- Do not disassemble, modify, or repair this device if broken or defective
- Keep away from water and extreme temperatures (hot or cold), open flames, and humid conditions
- Do NOT expose to or submerge in water
- Only use the supplied charging cable to recharge this device
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

### Questions & Customer Support


For questions, troubleshooting or any other assistance, please visit our website at [customersupport123.com](http://customersupport123.com).

### In the Box

- **Subwoofer** (x1)
- **Side Speakers** (x2)
- **Center Speaker** (x1)
- Adapter (x1)
- RCA-Aux Cable (x1)
- 3.5 mm Auxiliary Cable (x1)
- User Manual (x1)

## Location of Controls

1. Center Speaker
2. Subwoofer
3. Side Speakers
4. Volume Dial
5. Center Speaker Output
6. Side Speaker Speaker Output
7. [LED MODE] Button
8. Power Port
9. LED Indicator
10. 3.5 mm Auxiliary Input
11. [Power] Switch




## Getting Started

### Powering the Speaker System

Insert the pin of the supplied power adapter into the power port on the side of the subwoofer. Plug the other end into a wall socket.


### Setting Up the Speaker

Plug the single 3.5 mm connector of the two side speakers into the Side Speaker Output port on the side panel of the subwoofer. Plug the connector of the soundbar into the Center Speaker Output port on the side panel of the subwoofer.



### Powering ON/OFF

- Flip the [Power] switch on the side panel of the subwoofer to power ON/OFF.




### Playing Audio

To listen to audio on your speaker system, you must be paired to a Bluetooth-enabled device or connected to a device with the RCA cable. Once connected, playback can be controlled via your media-playing device.

### Bluetooth Pairing

1. Power the speaker ON. A tone will be heard and the Bluetooth LED indicator will **quickly flash BLUE**.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **AR309224** from the list of found devices.
3. After a successful pairing, a tone will be heard and the Bluetooth LED indicator will **slowly flash BLUE**.



### Adjusting Volume

Volume can be adjusted using the Volume Dial on the side of the subwoofer, or with your connected media-playing device.