

Wireless Portable **Thermal Printer Quick Start Guide**



Download the free app and start printing instantly! Scan this OR Code or visit www.coreinnovationsinc.com/printer

CTP500

Getting Started

Please read instruction card for proper setup before use.

PLEASE FOLLOW INSTRUCTIONS BELOW TO CORRECTLY LOAD PAPER ROLLS.

- 2. Place the paper roll as indicated on label.
- 3. Carefully close the lid.



Quick Start Guide

Warranty Card



In the Box 1 Thermal Printer

3 White Adhesive Rolls



USB-C® Charging Cable








Instruction Card




Device Overview









Solid Green Light:

Output tray is open



Status Light

Solid Red Light: Device is charging









Load Printer Paper



Pull 1" inch of the paper roll

and place outside of the

printer for optimal printing

Close the lid

Gently lift up release tabs to on paper roll and place open the printer



search for "CorePrint" on the available device list and tap to connect



Bluetooth® Setup

Fully charge before initial use and make sure to disconnect from other nearby paired devices.

seconds to power on



2. Download the free app by searching for InstaPrint on the App Store or Google Play.



 Connect to Bluetooth® via the app In the app, click on the profile tab. Then click on the "My Printer" icon



Product Specifications

Battery Capacity: 1200mAh Printing Type: Inkless Thermal Print Color: Black Bluetooth® Version: 5.3 Image Quality: 200 DPI Charging Input: USB-C®

Important Safety Warning

- Avoid using or storing in the following locations. Damage to the printer may be caused
- Do not leave in an exposed area with direct sunlight or near heat-generating equipment
- Do not leave in an area where temperature or humidit is excessively high or low, or changes radically. Do not leave in an area exposed to water or liquid
- Avoid dropping or harsh impact to the printer, as damage may be caused
- Avoid entry of foreign objects or materials, as damage
- When cleaning do not use volatile liquid (thinner benzin etc.) or wet cloth. Deterioration or discoloration may occur. Use a dry. soft cloth.
- Do not move the printer or place harsh impact on print while in printing or standby operation. Printer power may disconnect and print data may be lost.
- When charging your device, gently connect or disconnect charging cable to avoid damage.
- Improper charging can result in damaged printing
- Please mind the paper cutting teeth. This area is shar
- and can cause harm if not careful. This device contains small parts and is not recommen
- for kids under 3 years old.
- Adult supervision is recommended for kids under 13 years old. This equipment is not suitable for use in
- locations where children are likely to be present.
- Disassembly of printer will cause damage and void
- If severé bulging occurs to battery, please discontinue use

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

technician for help.

FCC Caution

This device complies with Part 15 of the FCC Rules.

this device must accept any interference received.

including interference that may cause undesired

Operation is subject to the following two conditions: (

operation. Any changes or modifications not expressly

approved by the party responsible for compliance co

comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This

accordance with the instructions, may cause harmful

interference to radio communications. However, there is

which can be determined by turning the equipment off

interference by one or more of the following measures:

-Increase the separation between the equipment and

- Connect the equipment into an outlet on a circuit

- Consult the dealer or an experienced radio/TV

different from that to which the receiver is connected.

equipment generates, uses and can radiate radio

frequency energy and, if not installed and used in

no guarantee that interference will not occur in a

particular installation. If this equipment does cause

harmful interference to radio or television reception

and on, the user is encouraged to try to correct the

- Reorient or relocate the receiving antenna.

void the user's authority to operate the equipment.

Note: This equipment has been tested and found to

This device may not cause harmful interference, and (2)

Need Help?

Email us at support@dpaudiovideo.zendesk.com or call us at 1-833-909-CORE (1-833-909-2673). We are available Monday - Friday, 9am-5pm PST except main

For information on recycling, please visit https://www.coreinnovationsinc.com/support

© 2023 Core Innovations. All rights reserved. Core Innovations is a trademark of DP Audio Video. © 2023 Bluetooth SIG, Inc. All rights reserved. The Bluetooth® trademarks including the BLUETOOTH word mark, the figure mark (the runic "B" and oval design), and the combination mark (Bluetooth word mark and design) are owned by the Bluetooth SIG. These and all third part trademarks are the property of their respective owners. Used with permission. © 2023 Google Inc. All rights reserved. Google, Android and Google Play are trademarks of Google LLC. © 2023 Apple Inc. All rights reserved. Apple and App Store are trademarks of Apple

▲ WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

