

Handheld Selfie Stick Head A6



User Manual

Operation interface



- ① Stabilizer power switch
- ② Stabilizer charging port
- ③ Light power/adjust button
- ④ Aluminum alloy tube
- ⑤ Wireless Remote
- ⑥ Tripod
- ⑦ Gimbal Unlock Key
- ⑧ Lamp
- ⑨ Lamp Charging Port
- ⑩ Manually tighten screws

Take out & Put in



How to replace the battery



Open the Tripod



How to connect

1. **Switch on and off:** press and hold the camera button for 2s to switch on and off.
2. **Wireless pairing:** Long press the photo button to enter the pairing state, the pairing state indicator 15 / time flashing, use the hand Machine search "Gimbal" to match, matching success, green light off. Once each button is triggered, the green light flashes immediately once.

3. **Camera button:** Long press: switch the machine; Click: take pictures or videos (start/stop)
4. **No pairing:** After starting up, for 10 minutes without operation under impaired connection automatically shut down.

5. **Pairing:** After turning on, when the selfie device is connected to the phone, 10 minutes without operation will enter dormancy state.

6. **Power off:** In the power-on and sleep state, press and hold the camera button for 2s to shut down, and the indicator light will flash and turn off.

7. **Battery:** When the button battery is below 2.0V (Low electricity), flash 0.5S / flash.

Fill light function

- Operation function of fill light:**
 Long press: on/off
 Single click: set lighting mode and brightness/off flash mode
 Double-click: activate flash mode
- White light:** soft light, medium light, strong light
Warm light: soft light, medium light, strong light
Mixed light: soft, medium, strong

Backlight charging method



Number of white lights: 12 Warm lights: 12
 White light color temperature: 11000K Lumen: 80LM Power: 1.5W
 Warm light color temperature: 3000K Lumen: 80LM Power: 1.5W
 Mixed light color temperature: 1000K Lumen: 80LM Power: 0.5W
 Battery capacity: 400mAh
 Operating voltage/output voltage: 3.7V
 Operating current/output current: 0.16A
 Charging voltage/input voltage: 5V
 Charging current/input current: 450mA

Removable fill light



Take out the backlight from the selfie stick and rotate it 180° horizontally. Rotate 180° vertically and move it to the front of the selfie stick. Align with the hollow concave and convex groove on the selfie stick and install it (Picture 1). Then move down and fix it.



Remote Control

- Note:** The phone's camera must be on the same side as the power button in order not to interfere with the shooting.
- Long Press:** long press 3S to switch the machine
Click: Photo or video recording (start / shutdown) Click: Photo or video recording (start / shutdown)
Click: 90, and the horizontal and vertical screen will switch & Portrait Mode
Three strikes: counterclockwise dream space
Double-click: Clockwise dream space
- Click:** POV half following mode
Double-click: Cancel the POV mode

DREAMSPACE MODE(UPSIDE-DOWN MODE)

Dreamspace Mode:
 When the phone is landscape mode, inclination 40° declination 130° inclination 130° declination 40°
 Back to the original position.
 When the phone is portrait mode, inclination 130° declination 125° and 145°, declination 145° back to its original position.


FUNCTION DISPLAY DIAGRAM



How to use the Gimbal

- Note:** The phone's camera must be on the same side as the power button in order not to interfere with the shooting.
- How to use the Gimbal:** Clamp the phone and keep the screen before long press the power button for 1 seconds to turn on, and long press 1 seconds to turn off.
- Click:** 90, and the horizontal and vertical screen will switch & Portrait Mode
Three strikes: counterclockwise dream space
Double-click: Clockwise dream space

How to charge the Gimbal



Specification

- Main Material: ABS+Aluminum Alloy
- Mount Holder: 158.7-156.4mm
- Folded Length: 180mm
- Extended Length: 790mm
- Product Size: 180x40.9x70.5mm
- Product Weight: 340g
- Remote Control Battery: CR1632(replaceable)
- Gimbal Battery: 400mAh
- Working voltage: 3.7V
- Charging voltage: DC5V
- Charging current: 500mA

(batteries must not be exposed to sunlight, fire or similar overheating)

REMIND

- Selfie Stick compatible with Android 4.4 and above & iOS 5.1 and above (if you change the system's "volume button function" under your phone's camera option, be sure to change it to default, or "take picture" to make the selfie stick work)
- The clip must be held tightly when the phone is clamped.
- 1. Gimbal Stabilizer Mode: the best use in the 3 rods
- 2. Selfie Stick Mode: 5 rods are recommended

Thank you for your support!

RE CE D R008 2

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.