
# 材质: 105G铜板纸,双面印刷,白底黑字,最终展开尺寸为:长71MM,宽105MM, 折叠1次,最终折叠尺寸71X52.5MM,说明书抬头在正面

## WIRELESS SPEAKER MANUAL



#### INSTRUCTIONS

- 1. Long press () for power on and off, short press it for pause/play or answer phone
- Short press to volume up, long press it to next song.
  Short press to volume down, long press it to previou
- to volume down, long press it to previous song.
- 4. Support twin speakers playing: Long press both speakers (1) to power on o If twin speakers connected before, they will automatically connect each other.
- $\circ$  If twin speakers NOT connected before, short press twice  $\bigcup$  on any speaker, two speakers will turn into pairing mode, after pairing successfully, the main speaker will have pairing voice prompt;
- Short press twice (1) on any of connected twin speakers to play as single speaker. • Switch off your device(eq. mobile) wireless connection setup before twin speakers connection, once twin speakers connected successfully, switch on your device's setup and search for the twin speaker name for wireless connection.
- 5. Insert 3.5mm audio plug/TF card/USB disk, the speaker will enter into AUX/TF card/USB disk playing mode automatically
- 6. Short press the "M" button to switch Wireless Connection/TE card/USB disk /AUX modes, Long press the "M" button to disconnect wireless connection.
- 7. Reset: When the speaker is on and stuck, push  $\bigcup$  for 10 seconds to reboot the speaker.
- 8. Low Battery: When the speaker is under low battery, it will have "beep" warning sound regularly, charge the speaker first then enjoy the speaker again.

#### BASIC FEATURES

- Support Wireless Connection/TF card/USB disk/AUX IN
- Support Twin speaker playing and Hand free call
- Water-proof IPX6

FM0209

### **TROUBLE SHOOTING**

- Cannot turn on the speaker: check if the speaker does not have power, if no power, charge it first.
- · Cannot connect with the devices: check if speaker connected with the third device, if yes, disconnect it first, if still can not connect, reboot it and try again.
- Unable to read TF card/USB disk: format TF card/USB disk or change song format to MP3.

#### CHARGING VIA USB CABLE

- Via USB cable, connect the speaker with the USB charger(output voltage 5V/output current no less than 1A, this accessory is not included) for charging;
- USB cable is for charging use only, not for data transferring;

#### SPECIFICATIONS

- Built-in Li-ion Battery: 1200mAh
- Type-C charging Voltage: 5V
- Speaker: 4Ω 5W
- Frequency Range: 100Hz-18KHz Distortion ≤ 3%

## INTERFACES

- Type-C Port: Power Charging
- TF card/USB disk/AUX slot: Insert TF card /USB disk/3.5mm audio plug into the slot and the speaker will enter into TF card/USB disk/AUX mode automatically. LED indicator
- - o Bule flash: Power on.
  - $\circ$  Red: charging status (red indicator off when fully charged).

#### CAUTIONS

- · Never knock the speaker
- Keep it away from fire, high and low temperature
- Never block speakers nets
- · Never open it by yourself
- . Don't charge it for too long time in case of damage to the battery, 3 hours is the best charging time

240622

### FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.