





MPOW H16 ANC WIRELESS HEADPHONES

MODEL: BH372A

① Packages



② Diagram



③ Operation Guide



DE a. Halten Sie die Bluetooth-Taste 6 Sekunden lang gedrückt, bis die rote und blaue Anzeigeleuchte abwechselnd und schnell blinkt. Nach der Verbindung ertönt die Sprachaufforderung.

b. Aktivieren Sie Bluetooth auf Ihrem Handy oder anderen Geräten, suchen Sie nach "MPOW H16" und klicken Sie, um eine Verbindung herzustellen.

FR a. Appuyez longuement sur le bouton Bluetooth pendant 6 secondes jusqu'à ce que les voyants rouges et bleus clignotent alternativement et rapidement et l'invite vocale sera entendue une fois le couplage terminé.

b. Activez Bluetooth sur votre téléphone ou d'autres appareils, recherchez "MPow H16" et cliquez pour vous connecter.

ES a. Mantenga presionado el botón Bluetooth durante 6 segundos hasta que las luces indicadoras de color rojo y azul parpadeen alternativamente y rápidamente y se

b. Active Bluetooth en su teléfono u otros dispositivos, busque "MPOW H16" y haga clic para conectarse.

IT a. Premere a lungo il tasto Bluetooth per 6 secondi finché le spie rosso e blu lampeggiano in modo alternato e rapido e il prompt vocale si sente dopo il completamento dell'accoppiamento.

b. Abilitare il Bluetooth sul telefono o su altri dispositivi, cercare "MPOW H16" e fare clic per connettersi.

JP a. 1 赤色と青色のライトがすばやく点滅するまで6秒間押し続けます。接続した後、ヘッドフォンに提示音を聞こえます。

b. スマホのBluetooth機能をオンにして、Bluetoothデバイスを検索し、“MPOW H16”をクリックしてください。

④ **Play/ Pause/ Siri / Answer a Call / Hang up Call / Reject a Call**


DE Abspielen / Anhalten / Siri /Anruf Annehmen /
Anrufauflegen / Anruf abweisen

ES Reproducir / Pausa / Siri / Responder Una Llamada / Colgar Una Llamada / Rechazar Una Llamada

IT Riproduci / Pausa / Siri / Rispondere a una chiamata / Terminare una chiamata / Rifiutare unachiamata

FR Lecture / Pause / Siri / Répondre à un Appel /
Raccrochez un Appel / Rejeter un Appel

JP 再生/一時停止/Siri/電話を受ける/電話を切る/電話を拒否する



⑤ Clearing Pairing Information


DE Löschen der Kopplungsinformationen

ES Borrar la Información de Emparejamiento

IT Cancellazione delle Informazioni di Accoppiamento

FR Supprimer des informations d'appariement

JP ペアリング情報を削除する



⑥ Volume Control / Music Control


DE Lautstärkeregelung / Musiksteuerung

ES Control de Volumen / Control de la Música


IT Controllo di Volume / controllo di Musica

FR Contrôle du Volume / Contrôle de la Musique

JP 音量調整/音樂調整



⑦ Charging



FCC Statement

Operation is subject to the following three conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



FOR MORE INFORMATION PLEASE VISIT
• <http://www.xmpow.com>