







BULGARIA

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application
- Programmable Task View button By default, press to display all virtual desktops in Windows 10. Programmable back button
- By default, press to display the previous page in your application history. Pairing button Press to switch between channels. Press and hold for 3 s to enter
- pairing mode for the selected channel Programmable right-click button
- **6** Programmable scroll wheel
 - Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.
- Hyperscroll button Press to turn hyperscroll on or off.
- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power

 Receiver light
 Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

CZECH

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth. To program the mouse buttons or change the DPI setting

(1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

• Programmable forward button By default, press to display the next page in your application history.

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

 Programmable back button By default, press to display the previous page in your application

history. Pairing button Press to switch between channels. Press and hold for 3 s to enter

pairing mode for the selected channel. Programmable right-click button

6 Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down

Hyperscroll button Press to turn hyperscroll on or off.

Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power

 Receiver light Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a

computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

INTERNATIONAL SPANISH

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description Programmable forward button

By default, press to display the next page in your application history. Programmable Task View button

By default, press to display all virtual desktops in Windows 10.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10. Programmable back button
- By default, press to display the previous page in your application history.

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

Programmable right-click button 6 Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button Press to turn hyperscroll on or off.

8 Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging.

Solid white: The mouse is fully charged and connected to power. Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. **Solid white (5 s):** The mouse is connected to the computer that is paired to the illuminated Bluetooth channel Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

Programmable forward button By default, press to display the next page in your application

history. Programmable Task View button

By default, press to display all virtual desktops in Windows 10.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

Programmable forward button By default, press to display the next page in your application history

Programmable Task View button

By default, press to display all virtual desktops in Windows 10. Programmable back button

By default, press to display the previous page in your application history.

Pairing button

Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

O Programmable right-click button

6 Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down

Hyperscroll button Press to turn hyperscroll on or off.

8 Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.

- Receiver light Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

LATVIAN

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

6 Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

To download the Bluetooth Pairing User Guide, go to

Connect the mouse to one computer using the receiver and

To program the mouse buttons or change the DPI setting

does not download automatically, on your computer, open

Microsoft Store or Apple Store. Search for HP Accessory

By default, press to display the next page in your application

By default, press to display all virtual desktops in Windows 10.

By default, press to display the previous page in your application

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

(1200 DPI by default), use the software. If the software

Bluetooth pairing lights

is in pairing mode

http://www.hp.com/support

up to two computers via Bluetooth.

Center, and then download the app.

Programmable forward button

2 Programmable Task View button

pairing mode for the selected channel.

Programmable right-click button

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

Bluetooth pairing lights

is in pairing mode.

Blinking amber: The mouse needs to be charged.

White (5 s): The mouse is on.

Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

Programmable back button

Components description

history.

history.

Pairing button


LITHUANIAN


White (5 s): The mouse is on.

Programmable forward button By default, press to display the next page in your application history.

Programmable Task View button

By default, press to display all virtual desktops in Windows 10.





 $\mathbf{123} \mathbf{4}$

Connect the mouse to one computer using the receiver and

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software

does not download automatically, on your computer, open

By default, press to display the next page in your application

By default, press to display all virtual desktops in Windows® 10.

By default, press to display the previous page in your application

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

selected and the receiver is not connected to a computer.

Microsoft Store or Apple Store. Search for HP Accessory

6

9

D-

Ð

up to two computers via Bluetooth[®].

Center, and then download the app.

Components description

Programmable forward button

Programmable Task View button

pairing mode for the selected channel.

9 Programmable right-click button 6 Programmable scroll wheel

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

which the receiver is connected.

Bluetooth pairing lights

White (5 s): The mouse is on.

Output Programmable back button

Pairing button

Hyperscroll button

8 Battery light

Receiver light

ARABIC

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

• Programmable forward button By default, press to display the next page in your application history.

Programmable Task View button By default, press to display all virtual desktops in Windows 10. Programmable back button

By default, press to display the previous page in your application history.

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

Programmable right-click button

6 Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

 Hyperscroll button Press to turn hyperscroll on or off.

Battery light

White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.

Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

X 💽 On

し (ひ) (i) www.hp.com/support

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support.

- B Programmable back button By default, press to display the previous page in your application
- Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

 Programmable right-click button **6** Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

- Hyperscroll button Press to turn hyperscroll on or off.
- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. **Solid amber:** The mouse is charging. Solid white: The mouse is fully charged and connected to power.
- Receiver light Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

To download the *Bluetooth Pairing User Guide*, go to

http://www.hp.com/support Connect the mouse to one computer using the receiver and

up to two computers via Bluetooth. To program the mouse buttons or change the DPI setting

(1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.
- Programmable back button By default, press to display the previous page in your application
- Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.
- Programmable right-click button
- Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.
- Hyperscroll button Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged.
- **Solid amber:** The mouse is charging. Solid white: The mouse is fully charged and connected to power. Receiver light
- Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights
- Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

- B Programmable back button By default, press to display the previous page in your application
 - Pairing button Press to switch between channels. Press and hold for 3 s to enter
- pairing mode for the selected channel. Programmable right-click button
- **6** Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use
- functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.
 - Hyperscroll button
- Press to turn hyperscroll on or off. Battery light
- White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power. Receiver light
 - Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. **Solid white (5 s):** The mouse is connected to the computer to which the receiver is connected.
 - Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in p<mark>air</mark>ing mode.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.
- Programmable back button By default, press to display the previous page in your application
- history. 4 Pairing button
- Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.
- **9** Programmable right-click button
- Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.
- Hyperscroll button Press to turn hyperscroll on or off.

is in pairing mode.

- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. **Solid amber:** The mouse is charging.
- Solid white: The mouse is fully charged and connected to power. Receiver light
 Quickly blinking white (5 s): The receiver channel is currently
- selected and the receiver is not connected to a computer Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel

- Operation Programmable back button By default, press to display the previous page in your application
- Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel. • Programmable right-click button
- Programmable right-click button **6** Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll
- the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down. Hyperscroll button
- Press to turn hyperscroll on or off.
- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.
- Receiver light
 Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.
- To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support
- Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.
- To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.
- Output Programmable back button By default, press to display the previous page in your application history.
- Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.
- Programmable right-click button **6** Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.
- Hyperscroll button Press to turn hyperscroll on or off.
- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. **Solid amber:** The mouse is charging.
- Solid white: The mouse is fully charged and connected to power. Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

Programmable back button

By default, press to display the previous page in your application

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.

PRINTER: Replace this box with Printed- In (PI) Statement(s) as per spec NOTE: This box is simply a placeholder. Pl Statement(s) do not have to fit inside the box but should be placed in this area.



M17587-A21


B

∦

NB_OPT_SIP_Brain_M17587-A21_v9.indd

8/28/2020 8:26:05 PM







HUNGARIAN

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.
- B Programmable back button
- By default, press to display the previous page in your application history.
- Pairing button
- Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

• Programmable right-click button

6 Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button Press to turn hyperscroll on or off.

- Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.
- Receiver light
 Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app

Components description

Programmable forward button By default, press to display the next page in your application

Programmable Task View button

By default, press to display all virtual desktops in Windows 10. Programmable back button

- By default, press to display the previous page in your application history Pairing button
- Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel Programmable right-click button

O Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button Press to turn hyperscroll on or off.

Battery light White (5 s): The mouse is on.

Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.

Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer **Solid white (5 s):** The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode

POLISH

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory Center, and then download the app.

Components description

history.

Pairing button

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.

By default, press to display the previous page in your application

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**. and then download the app.

Components description

Programmable forward button By default, press to display the next page in your application

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

B Programmable back button By default, press to display the previous page in your application history

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

• Programmable right-click button **6** Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button

Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging.

Solid white: The mouse is fully charged and connected to power Receiver light Quickly blinking white (5 s): The receiver channel is currently

selected and the receiver is not connected to a computer Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

RUSSIAN

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward buttor By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth. To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open

Microsoft Store or Apple Store. Search for HP Accessory

Components description

Center, and then download the app.

• Programmable forward button

By default, press to display the next page in your application history. Programmable Task View button

By default, press to display all virtual desktops in Windows 10.

Operation Programmable back button By default, press to display the previous page in your application

history. Pairing button Press to switch between channels. Press and hold for 3 s to enter

pairing mode for the selected channel Programmable right-click button

6 Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down

Hyperscroll button

Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.

Receiver light Quickly blinking white (5 s): The receiver channel is currently

selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected. Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

history.

Pairing button

Programmable forward button By default, press to display the next page in your application history. Programmable Task View button By default, press to display all virtual desktops in Windows 10.

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

history.

Pairing button

Programmable forward button By default, press to display the next page in your application

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

pairing mode for the selected channel

OPROGRAMMABLE REPORT OF A STATE OF A STAT

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel

To download the *Bluetooth Pairing User Guide*, go to

Connect the mouse to one computer using the receiver and

To program the mouse buttons or change the DPI setting

does not download automatically, on your computer, open

Microsoft Store or Apple Store. Search for HP Accessory

(1200 DPI by default), use the software. If the software

Bluetooth pairing lights

is in pairing mode.

http://www.hp.com/support

up to two computers via Bluetooth.

Center, and then download the app.

Components description

history.

Programmable forward button

White (5 s): The mouse is on.

6 Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

Programmable back button

By default, press to display the previous page in your application

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

selected and the receiver is not connected to a computer.

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.

which the receiver is connected

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode

DUTCH

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

- Programmable forward button By default, press to display the next page in your application history.
- Programmable Task View button By default, press to display all virtual desktops in Windows 10.
- Programmable back button By default, press to display the previous page in your application
- history.
- Pairing button

Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

9 Programmable right-click button

6 Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left. click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button

- Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging.
- **Solid white:** The mouse is fully charged and connected to power. Receiver light
- Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.
- Bluetooth pairing lights Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a 🖊 computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

B Programmable back button

pairing mode for the selected channel.

Programmable right-click button

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

White (5 s): The mouse is on.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

Bluetooth pairing lights

is in pairing mode.

http://www.hp.com/support

Components description

history.

Programmable forward button

Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

White (5 s): The mouse is on.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

Bluetooth pairing lights

is in pairing mode.

PORTUGUESE

6 Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

Operation Programmable back button

By default, press to display the previous page in your application 4 Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

Programmable right-click button

6 Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, til<mark>t r</mark>ight to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button

Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging. Solid white: The mouse is fully charged and connected to power.

Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support Connect the mouse to one computer using the receiver and

up to two computers via Bluetooth. To program the mouse buttons or change the DPI setting

(1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

Programmable forward button By default, press to display the next page in your application

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

Pairing button

6 Programmable scroll wheel Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

 Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. **Solid amber:** The mouse is charging.

Receiver light

selected and the receiver is not connected to a computer Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

Operation Programmable back button

pairing mode for the selected channel.

9 Programmable right-click button

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

White (5 s): The mouse is on.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

To download the *Bluetooth Pairing User Guide*, go to

Connect the mouse to one computer using the receiver and

To program the mouse buttons or change the DPI setting

does not download automatically, on your computer, open

Microsoft Store or Apple Store. Search for HP Accessory

By default, press to display the next page in your application

By default, press to display all virtual desktops in Windows 10.

By default, press to display the previous page in your application

Press to switch between channels. Press and hold for 3 s to enter

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

the screen right, tilt left to scroll the screen left, click to use

(1200 DPI by default), use the software. If the software

Bluetooth pairing lights

is in p<mark>air</mark>ing mode.

http://www.hp.com/support

up to two computers via Bluetooth.

Center, and then download the app.

Components description

history.

history.

Pairing button

Programmable forward button

Programmable Task View button

pairing mode for the selected channel.

• Programmable right-click button

you move the mouse up or down.

Press to turn hyperscroll on or off.

Solid amber: The mouse is charging.

which the receiver is connected.

computer, the pairing was not successful.

paired to the illuminated Bluetooth channel.

Bluetooth pairing lights

is in pairing mode.

Blinking amber: The mouse needs to be charged.

White (5 s): The mouse is on.

O Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

Programmable back button

SERBIAN

Programmable scroll wheel

Hyperscroll button

Battery light

Receiver light

By default, press to display the previous page in your application history

Programmable back button

Programmable Task View button

By default, press to display the previous page in your application

By default, press to display the next page in your application

By default, press to display all virtual desktops in Windows 10.

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel.

9 Programmable right-click button

Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button

Press to turn hyperscroll on or off. Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. Solid amber: The mouse is charging.

Solid white: The mouse is fully charged and connected to power. Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.

UKRANIAN

To download the *Bluetooth Pairing User Guide*, go to http://www.hp.com/support

Connect the mouse to one computer using the receiver and up to two computers via Bluetooth.

To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

Components description

Programmable forward button By default, press to display the next page in your application history.

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

Programmable back button

By default, press to display the previous page in your application history.

Pairing button

Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel

Programmable right-click button

6 Programmable scroll wheel

Scrolls the screen up or down. Tilt right, tilt left, or click to use functions programmed in the app. By default, tilt right to scroll the screen right, tilt left to scroll the screen left, click to use application-specific functions, and click and hold to scroll when you move the mouse up or down.

Hyperscroll button Press to turn hyperscroll on or off.

Battery light White (5 s): The mouse is on. Blinking amber: The mouse needs to be charged. **Solid amber:** The mouse is charging. Solid white: The mouse is fully charged and connected to power.

Receiver light

Quickly blinking white (5 s): The receiver channel is currently selected and the receiver is not connected to a computer. Solid white (5 s): The mouse is connected to the computer to which the receiver is connected.

Bluetooth pairing lights

Quickly blinking white (5 s): The illuminated Bluetooth channel is currently selected. If you attempted to pair the mouse to a computer, the pairing was not successful. Solid white (5 s): The mouse is connected to the computer that is paired to the illuminated Bluetooth channel. Slowly blinking white (180 s): The illuminated Bluetooth channel is in pairing mode.



 Programmable back button By default, press to display the previous page in your application Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel. Programmable right-click button

Hyperscroll button

Press to turn hyperscroll on or off.

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

To download the *Bluetooth Pairing User Guide*, go to Connect the mouse to one computer using the receiver and

up to two computers via Bluetooth. To program the mouse buttons or change the DPI setting (1200 DPI by default), use the software. If the software does not download automatically, on your computer, open Microsoft Store or Apple Store. Search for HP Accessory **Center**, and then download the app.

By default, press to display the next page in your application

Programmable Task View button By default, press to display all virtual desktops in Windows 10.

Programmable back button By default, press to display the previous page in your application

Pairing button Press to switch between channels. Press and hold for 3 s to enter pairing mode for the selected channel. O Programmable right-click button

Scrolls the screen up or down. Tilt right, tilt left, or click to use

functions programmed in the app. By default, tilt right to scroll

application-specific functions, and click and hold to scroll when

Solid white: The mouse is fully charged and connected to power.

Quickly blinking white (5 s): The receiver channel is currently

Solid white (5 s): The mouse is connected to the computer to

Quickly blinking white (5 s): The illuminated Bluetooth channel

Solid white (5 s): The mouse is connected to the computer that is

Slowly blinking white (180 s): The illuminated Bluetooth channel

is currently selected. If you attempted to pair the mouse to a

selected and the receiver is not connected to a computer.

the screen right, tilt left to scroll the screen left, click to use

Blinking amber: The mouse needs to be charged.



Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados

RMN/型號/型号: STA-AM02 + STA-AD01

© Copyright 2020 HP Development Company, L.P.

The Bluetooth trademarks are owned by their proprietor and used by HP Inc. under license.

Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as onstituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: September 2020

NB_OPT_SIP_Brain_M17587-A21_v9.indd 2

8/28/2020 8:26:07 PM