



JX91
Stick Type TWS



Instruction manual

Product Description



1: Multi-function touch button
2: Earbud indicator/microphone
3: Indicator light
5: Type-C USB charging port


Power on/off

Power on: The headset will automatically turn on when the charging compartment is opened, or manually press and hold the touch button for 3S.


Power off: Put the earphone into the charging compartment and close the cover. The earphone will automatically shut down. If it is not connected to any device within 5 minutes, it will automatically shut down.

Manual power off: Long press the headset touch key for 5s to manually shut down.


Bluetooth pairing




❶ Open the charging compartment and take out the earbud to turn it on automatically.



❷ After turning on, put the left and right earphones close to each other. After the team is successful, the indicator light: the main earphone flashes red and blue lights alternately, and the auxiliary ear flashes blue light once every 5 seconds.




5 seconds flashing blue light once.



Red and blue lights Alternate flashing

Music



► Music pause/play: During playback, short press the multi-touch button.

► Previous song: Double-click the left ear multi-function touch button.

► Next song: Double-click the right ear multi-function touch button.


Wake up voice assistant function
(requires mobile phone support)

► After successfully connecting with the mobile phone, except during a call, long press the left ear touch key for 3S to activate the voice assistant function (SIRI).

Game mode

► Long press the right ear for 3s to enter or exit the game mode.

Call



► Answer: When a call comes in, short press the multi-function touch key.

► Reject: During a call, double-click the multi-function touch key.

► Hang up: During a call, double-click the multi-function touch key.

Headset restore factory settings

When the headset is turned on, press the left/right headset multi-function button for 5S at the same time, the red LED on the headset flashes quickly 5 times, and the factory settings are restored successfully.

Charging

❶ Charge the charging bin through the charging cable, and the indicator light of the bin is always on when it is fully charged.

❷ Put the earphone into the charging compartment, and it will be charged automatically. When the earphone is fully charged, the indicator light of the earphone will go out.

Earbuds charging	Red light is on
Earbuds is fully charged	Red light is off
Charging compartment is charging	Red light is light up in sequence
Charging compartment is fully charged	The light is always on

Specifications

- Model: JX91
- Bluetooth version: 5.2
- Single earbud weight: 3.9g
- Earbud size: 33.5*17*26MM
- Earbud battery capacity: 3.7V/2*35mAh
- Earbud charging time: about 30 minutes
- Play music time: about 4.5 hours(Medium volume)
- Support Agreement: SPP / HFP / A2DP / AVCTP / HID
- Frequency: 2.4GHz~2.48GHz
- Bluetooth distance: 10M
- Power input: DC 5V/500mA
- Charging compartment battery capacity: 3.7V/300mAh
- Charging bin to charge the earbud: 2 times
- Charging bin size: 59*25*52mm
- Charging bin weight: 40g

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Label

Stick Type TWS

Model: JX91

FCC ID: 2A30A-STEM