




18+
MONTHS

Instructions For Use

V1.0



6601

 +1(855) 888-6699

 www.holystone.com

 usa@holystone.com (USA)
ca@holystone.com (CA)

eu@holystone.com (EU)
jp@holystone.com (JP)



1.0 PREFACE

To make your experience with this remote control car as straightforward and convenient as possible, please read this Instructions For Use before operating and keep it for the future reference and maintenance.

1. In order to protect the legitimate rights and interests of users, please be sure to carefully read the relevant contents of this manual provided with this product before using this product. This product is not recommended for people under the age of 8.

2. During the use of this product, please be sure to strictly observe and perform the requirements including but not limited to the instructions and safety instructions. For any personal injury, accident, property loss, legal dispute, or any other adverse event causing a conflict of interest resulting from the use of the product or any irresistible factors that are in violation of the safety instructions, the user shall bear the related responsibilities and losses. Holystone will not take any responsibility.

3. Once you start using this product, you are deemed to have read, understood, endorsed, and accepted all the terms and contents of the instructions (including disclaimers, safety instructions, warning instructions, etc.) included with this product.

4. In case of having difficulties on any aspect of the product, operation or maintenance, please contact your local sales agent or contact customer support here at Holystone.

2.0 WARNINGS

1. Please install and use it correctly according to instructions or instructions on the package. Some parts need to be assembled and adjusted by adults.
2. Please use under the guidance of an adult.
3. Please promptly put away the packing materials so as not to cause harm to children.
4. Do not operate in a place where water is trapped or in the rain. Parts on the product may be wet and cause malfunction.
5. Do not touch the rotating wheel to avoid unnecessary injury.
6. The product contains small parts that may pose a risk of ingestion or suffocation.
7. It is forbidden to remotely control the road or the crowd to avoid accidents.
8. It is necessary to periodically check the charging USB cable, plug, housing and other components and immediately stop using it until it is found to be damaged.
9. This product can only use the factory configured USB cable to charge the product battery.
10. USB cable, battery box, and battery must be inserted into the same specified power supply as the product symbol.
11. Charge the USB cable and the battery is not a toy.
12. Disconnect the rechargeable USB cable before cleaning the toy.
13. If you experience thunder, lightning, etc. during remote control, stop the remote control immediately.
14. When installing or replacing the battery, pay attention to the correct polarity of the battery.

15. The remote control car uses a 7.4V 1200mAh Li-Po battery.
16. Never short-circuit, disassemble, modify, impact, crush, puncture, drop high, throw fire, etc. to avoid danger.
17. Do not expose the battery to prolonged exposure to sunlight to prevent danger.
18. It is advisable to store the battery at a temperature below 30°C. Do not store it in a place with heat, high temperature, or humidity to avoid danger.
19. Non-rechargeable batteries cannot be charged.
20. When charging a rechargeable battery, adult supervision is required.
21. The rechargeable battery should be removed from the toy before charging.
22. Do not mix old and new or different types of batteries.
23. Only use the USB cable configured by this product to charge the battery when charging the battery.
24. Do not disassemble the battery or modify the battery at random to avoid the risk of fire or explosion.
25. After the battery is used, it should be taken out of the remote control car, and after cooling, fully charged and placed in a safe position. Unplug the battery plug from the USB charging cable when it is not charging, and disconnect the power.
26. The battery should stop using the battery as soon as it smells or suddenly becomes hot, deformed, discolored, or otherwise abnormal during use or charging.

- 27. After the remote controller runs, the battery temperature is high. It is recommended that you wait for about 30 minutes before charging the battery. Otherwise, the battery may be damaged.
- 28. Exhausted batteries should be removed in time.
- 29. The wiring port should not be short-circuited.
- 30. If you do not use the product for a long time, remove the batteries of the remote control car and remote control.
- 31. The packaging and instructions contain important product information, please give it reservations.