



产品包材标准	
产品型号 ZJO2常规(不含适配器)说明书 ZJO2常规(不含适配器)说明书 ZJO2常规(不含适配器)说明书	ZJ02 常规 (不含适
尺寸75*90mm (合起来尺寸)材质157	I57g铜版纸
工艺说明/印刷要求 四色印刷,双面彩印,7折页 1:1	:1
使用单位 mm A0	0
物料编码 时间 2025	)25-02-11
制图 尹	



# Instructions for use

1.Please use a 9V/2A or higher adapter (QC 2.0 or QC 3.0) and a fast charging cable. 2. Put the phone in the mobile phone charging area and the mobile phone can be charged 3.Place the watch in the watch charging area to charge the watch 4.Put the wireless charging Bluetooth earphone box in the earphone

### charging area to charge the earphone LIGHT INSTRUCTIONS

ower On	•	The ice blue light will turn off after 10 seconds of illumination	
Standby	0	No light	
Charging	•	Ice blue light on, turn off after 20 seconds	
FOD	0	Ice blue light flashing rapidly	

1. This 3-in-1 wireless charging station only supports Apple Watch S10/S9/S8/S7/S6/SE S5/S4/S3/S2/Ultra/Hermès. (Note: Apple watch series 1 is not supported) 2. Do not charge the charging station of Apple products from the computer USB interface or other power converters. 3. When charging, place the enabled device in the center of each wireless charging area 4. Make sure your device is in the middle of the cordless charger area. 5. The silicone shell of iWatch and AirPods may cause abnormal charging. It is best to tak

### COMPATIBLE DEVICES

iPhone 16,16 Pro, 16 Pro Max, 16 Plus iPhone 16 Series Case with MagSafe iPhone 15,15 Pro, 15 Pro Max, 15 Plus iPhone 15 Series Case with MagSafe iPhone 14,14 Pro,14 Pro Max, 14 Plus iPhone 14 Series Case with MagSafe iPhone 13,13 Pro, 13 Pro Max, 14 mini iPhone 13 Series Case with MagSafe iPhone 12,12 Pro, 12 Pro Max, 12 mini iPhone 12 Series Case with MagSafe

### iPhone Leather Wallet with Magnetic 2.Apple Watch

Apple iWatch S2,S3,S4,S5,S6,S7,SE,SE 2,S8,S9,S10,Ultra, Ultra 2 3.Earbuds Apple AirPods 2/ AirPods 3/ AirPods 4/AirPods Pro/ AirPods Pro 2.

PRODUCT SPECIFICATION Input: 9V==2A

Output(Phone):15W(Max)/10W/7.5W/5W Conversion Rate:≥73%(Phone)

Output(Earbuds): 3.0W(Max)

1. Magnetic wireless charging X1 2.User manual X1

And more TWS(others Oi enable earbuds)

Product Size:

105.6X94.4X127.4mm

Input Port: Type-C

Output(iWatch): 2.5W(Max)

PACKING LIST

3. Type-C quick charging cable X 1

FAQ 1. If you're experiencing interrupted or slow charging, check the following: 1) The back of your devices should not have any metal, pop sockets, or credit cards.

 2) Put the devices in the center of the charging surface (this lets the charging coil in your devices line up with the one inside the wireless charger).
3) Check whether the adapter is QC 3.0 fast charger. 2. If you're failing to charge your device, please try out the following:

(1) Please restart your cell phone and test with other Type-C charging cable. (2) Please check whether the indicator turns on or not. (3) Please check if the adapter is a QC3.0 fast charger (output: 9V/2A and above).

3. Charging slow. Charging efficiency depends on the receiving power of your devices, and do not keep those app keep running during charging.

4. The phone is charging intermittently, or the indicator light flashes. If the charging current is not enough, please use a adapter with sufficient power 9V/2A above.

5. Charging fever. It is normal for the receiving coil or transmitter board to generate heat during wireless charger is the wireless charger is too hot, please take your devices off it, when the wireless charger is cooled down, please charger it again.

6. The charger does not work. Do not put metal debris or magnetic cards on the charging area. If the product does not wo to overheating, please take off the phone and charge it again when it is cooled down.

7. If there are another problems, please contact our after-sales for solution.

## SAFETY NOTICE

1. Do not disassemble or throw the product into fire or water to avoid short circuit. 2. Do not use wireless charger in extremely hot, humid or corrosive environment. 3. Make sure there are no any metal, pop rings, credit cards or magnetic interference charges. 4. Keep out of reach of children and pets. 5. If the charging station overheats and stops charging during use, please remove

the charging device and try charging after cooling down. 6. Avoid dropping the product from high place.

# 说明书 注:以产品实际签样为准

适配器)说明书