

Bluetooth Speaker User Manual

Mini Speaker

USER MANUAL

Bluetooth Speaker

In the box

Location of controls

On a BlackBerry®

- Go to **SETTINGS>OPTIONS>BLUETOOTH**
- Enable **BLUETOOTH** (Make sure Bluetooth is turned ON)

On an Android Phone

- Go to **SETTINGS>BLUETOOTH>MENU**
- Select **Bluetooth** (Make sure Bluetooth is turned ON)

Playing Music

To enjoy wireless music on your Mini Speaker, make sure you are connected to a Bluetooth enabled device. Once connected you can press **PLAY** on your Bluetooth enabled device. When playback has begun, you can control the music with your connected device (which must have the AVRCP Bluetooth profile).

1

Next mode, enabled, next phone, will play, connected to the Wireless Speaker. This means you can make phone calls and enjoy your music.

Using as a wired speaker

1. Turn on the speaker.
2. Connect one end of the 3.5mm AUX Cable to the **AUX IN** jack on the side of the speaker, and the other end of the cable to an external device's headphone jack (smartphone, tablet, MP3 player).
3. Use the controls on your connected device to control music playback.
4. Turn the Power/Volume knob on the front of the speaker to adjust the volume, or you can use the volume control on your connected device.

Legal information

FCC Part 15.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this equipment not expressly approved by the responsible authority may void the user's authority to operate the equipment.

NOTE: This signal must be kept shielded and shielded in accordance with the requirements of the FCC. This device is not intended to be used in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere.

Important: There is no guarantee that interference will not occur in a particular area. If you experience interference, you should try the following steps to resolve the problem, which may be determined by turning the radio part of the device off. If the use of the device is not possible, you should contact the manufacturer for assistance.

- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.

Consult the dealer or an experienced radio/TV technician for help.

Class B FCC limits.
This product must be used with this antenna to ensure compliance with the Class B FCC limits.

FCC Part 15.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this equipment not expressly approved by the responsible authority may void the user's authority to operate the equipment.

NOTE: This signal must be kept shielded and shielded in accordance with the requirements of the FCC. This device is not intended to be used in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere.

Important: There is no guarantee that interference will not occur in a particular area. If you experience interference, you should try the following steps to resolve the problem, which may be determined by turning the radio part of the device off. If the use of the device is not possible, you should contact the manufacturer for assistance.

- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.

Consult the dealer or an experienced radio/TV technician for help.

Class B FCC limits.
This product must be used with this antenna to ensure compliance with the Class B FCC limits.

Charging the Mini Speaker

1. Plug the small end of the Micro USB cable into the Micro USB charging port on the side of the speaker.
2. Plug the other end into a USB port on your computer or other device made for USB charging.
3. The LED indicator light on the front of the speaker lights up RED when charging. It will shut off when fully charged.

Pairing the speaker with a Bluetooth enabled device

1. Turn the Power/Volume knob to the right to turn the speaker ON.
2. A tone will be heard and the LED indicator light will be flashing BLUE.
3. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
4. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.

On other Cell Phones/Devices

- Review the instruction manual that came with your phone device.

Pairing the speaker with a Bluetooth enabled device

1. When the Bluetooth enabled device finds the Mini Speaker, select the Mini Speaker from the list of found devices.
2. If required, enter the passcode 0000. Select OK or Yes to pair the two units.
3. After successful pairing, a tone will sound and the LED indicator light will flash BLUE every 2 seconds.

NOTE: If you would like to connect the speaker to another device, you must unpair the speaker from the currently paired device first. On your device's Bluetooth settings, select the Mini Speaker and select "unpair." When the speaker has been unpaired, it automatically goes into pairing mode again.

Troubleshooting tips

1. Can pair the Mini Speaker with my Bluetooth device, but I cannot hear any music.
 - Make sure your Bluetooth device supports A2DP profile.
 - Turn up the volume on your Bluetooth device or the speaker.
 - You may have to unpair the speaker, then re-pair to your device.
2. I cannot get the Mini Speaker into pairing mode.
 - Make sure the Mini Speaker is turned ON before beginning the pairing process.
 - The speaker will emit a tone and the LED indicator light will be flashing BLUE.
 - The speaker is now in pairing mode.
3. My Bluetooth device is not able to pair with the Mini Speaker.
 - Make sure the Mini Speaker is turned ON before beginning the pairing process.
 - Keep your Mini Speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
 - The speaker will emit a tone and the LED indicator light will be flashing BLUE.
 - Check that YOUR device's Bluetooth feature is turned ON.
 - Try repeating the pairing process, see "Pairing the speaker with a Bluetooth enabled device."

Limited warranty

This product is sold and distributed by All Inc. ("All") to the original consumer purchaser is warranted by All against defects in materials and workmanship for a period of one (1) year from the date of purchase. ("Warranty"). This warranty does not cover damage caused by misuse, accident, or other circumstances not within the scope of the product. The warranty is void if the product is not used in accordance with the instructions. The warranty is void if the product is not used in accordance with the instructions. The warranty is void if the product is not used in accordance with the instructions.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (dated all of the original consumer purchaser).
- Return the product to the authorized service center, and include a return shipping address (P.O. Box), a telephone contact number, and a return receipt for the product.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines that the product is defective. The product will be shipped as a result of shipping, we require you to file a claim with the carrier.

The shipping address of the authorized service center is:

All Inc.
All Inc. Service Center
142-134th Street
Brooklyn, NY 11234

NOTE: All Inc. Service Center is not responsible for any damage to the product or any other equipment that may be damaged while the product is in the service center. All Inc. Service Center is not responsible for any damage to the product or any other equipment that may be damaged while the product is in the service center. All Inc. Service Center is not responsible for any damage to the product or any other equipment that may be damaged while the product is in the service center.

Charging the Mini Speaker

1. Plug the small end of the Micro USB cable into the Micro USB charging port on the side of the speaker.
2. Plug the other end into a USB port on your computer or other device made for USB charging.
3. The LED indicator light on the front of the speaker lights up RED when charging. It will shut off when fully charged.

Pairing the speaker with a Bluetooth enabled device

1. Turn the Power/Volume knob to the right to turn the speaker ON.
2. A tone will be heard and the LED indicator light will be flashing BLUE.
3. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
4. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.

Using your Mini Speaker

Powering ON/OFF

- To turn ON, turn the Power/Volume knob on the front of the speaker to the right.
- To turn OFF, turn the Power/Volume knob on the front of the speaker to the left.

Adjusting the volume

- Turn the Power/Volume knob on the front of the speaker to adjust the volume to the desired level.

NOTE: You can also adjust the volume from your connected device's volume control.

Pairing the speaker with a Bluetooth enabled device

1. When the Bluetooth enabled device finds the Mini Speaker, select the Mini Speaker from the list of found devices.
2. If required, enter the passcode 0000. Select OK or Yes to pair the two units.
3. After successful pairing, a tone will sound and the LED indicator light will flash BLUE every 2 seconds.

NOTE: If you would like to connect the speaker to another device, you must unpair the speaker from the currently paired device first. On your device's Bluetooth settings, select the Mini Speaker and select "unpair." When the speaker has been unpaired, it automatically goes into pairing mode again.

Legal information

FCC Part 15.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this equipment not expressly approved by the responsible authority may void the user's authority to operate the equipment.

NOTE: This signal must be kept shielded and shielded in accordance with the requirements of the FCC. This device is not intended to be used in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere. This device is not intended for use in the presence of a hazardous explosive atmosphere.

Important: There is no guarantee that interference will not occur in a particular area. If you experience interference, you should try the following steps to resolve the problem, which may be determined by turning the radio part of the device off. If the use of the device is not possible, you should contact the manufacturer for assistance.

- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.
- Relocate the equipment.

Consult the dealer or an experienced radio/TV technician for help.

Class B FCC limits.
This product must be used with this antenna to ensure compliance with the Class B FCC limits.