



855.999.8041 | WWW.XTREMECABLES.COM

SAFETY AND CARE INSTRUCTIONS

Read **all** the instructions before using the product and then store them for future reference. Failure to **follow** these safety instructions, could lead to fire, electrical shock, personal injury, property damage, or damage to the product,

- This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, **follow** your local / state guidelines.
- Do not expose to rain, moisture, or other liquid. Do use near water such as swimming pools, bathtubs, or sinks. If it becomes wet, immediately **unplug** the product from a power source. Do not handle the unit, USB cord or wall charger with wet hands.
- Do not charge, or use, the product if it has been submerged in water, of if water has got inside the product.
- Do not expose to heat sources, the sun, or leave in a hot vehicle. Do not dispose of in a fire.
- Do not expose the product to extremely high or low temperatures. Use this product in a location with a temperature of 32°F - 95°F. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 170°F could cause serious damage and explosion.
- Do not disassemble, there are no serviceable parts inside. Do not drop. Do not use if damaged or modified or if you see any bulging, swelling, leakage or other abnormality. Never insert objects other than the specified cables into the product. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not modify or try to use for a non-intended purpose. Do not use the power bank more than its output rating. Overload outputs above rating may result in a risk of fire or injury.
- Do not place anywhere where the product would become crushed or punctured.
- Place the charger on a flat, sturdy surface during charging. Charge in a well-ventilated area and make sure it is not covered with any material. Power banks generate heat when charging, and the power bank may temporarily stop charging if it gets too hot.
- Charge using the correct wall charger, and make sure that the charger is inserted **all** the way into the electrical outlet. Disconnect the charger once the product is fully charged.
- This product is not a toy. Keep out of reach of children or those that require supervision.
- Do not use abrasive cleaning solvents to clean the unit.

Note: Lithium-ion batteries **will** self-discharge over time, and it is normal for battery performance to decline after several years of usage. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery **will** no longer have the ability to be recharged.

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

ONE YEAR LIMITED WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact **Customer Service:** customerservice@xtremecables.com



XTREMECABLES

Made in China for
Jem Accessories, Edison, N.J. 08817



ACTIVE NOISE CANCELLING

WIRELESS HEADPHONES

With built-in microphone

855.999.8041 | WWW.XTREMECABLES.COM

XBH9-1032
User Manual V1.0 0624

INTRODUCTION

Thank you for choosing our ANC Wireless Headphones. This manual will guide you through the setup and usage of your new headset. Enjoy an immersive listening experience with active noise cancellation and superior sound quality.

PRODUCT DESCRIPTION


Block out the world and any distractions while you listen to your music in a blissful silence, thanks to ANC Wireless Headphones. These headphones have a soft, comfortable ear cup design that let you listen for hours in plush comfort. When a call comes in, you can seamlessly switch gears thanks to the built-in microphone, and the easy-to-use controls let you manage your music and calls without missing a beat. The fold and swivel design allows for compact storage and easy portability, making these headphones your perfect travel companion.

- ANC:** Eliminate outside noise with option to have it On or Off
- HANDS FREE CALLING:** One touch call controls
- AUX PORT:** Cable included
- COMPACT:** Fold and put a way in your to-go back with ease

SPECIFICATIONS

- Supports: HSP, HFP, A2DP, AVRCP
 - Wireless Distance: 10 meters
 - Playing time (based on max volume):
 - ANC on: about 28hrs
 - ANC off: about 36hrs
 - Standby Time: 90 hours
 - Battery Capacity: 400mAh
 - Charging Specification: 350mA/5V
- Charging Time: 2-3 hours
 - Driver Unit: 40mm
 - Impedance: 32 ohms
 - Frequency Response: 20Hz-20KHz
 - Maximum Noise Reduction Level: 20±2dB
 - Material: ABS + PU
 - Dimensions: 7.28 * 6.69 * 2.95 inches
 - Net Weight: 180g
 - USB Cable Length: 19.7 inches ±0.8 inches
 - Aux Cable Length: 39.4 inches ±0.8 inches

GET TO KNOW YOUR PRODUCT



NOTE: Before first use, charge the headphones for at least 1 hour.

Charging

Connect the included charging cable to the headphones and plug it into an appropriate power source. The LED will display red, indicating charging status.

Operation

To power on, press and hold **[▶|]** for about 3 seconds until the LED indicator flashes, indicating the headset is on. It will immediately be in pairing mode.

To power off, press and hold **[▶|]** for about 3 seconds until the LED indicator turns off.

Bluetooth Pairing

Ensure the headphones are powered on.
The light will flash blue and red to indicate it is in pairing mode
Open the Bluetooth settings on your device and search for new devices.

Select "Xtreme XBH9-1032" from the list of available devices.
Once paired, a confirmation tone will sound.

(R) SIDE

- Volume Up
- Power On/Off
Play/Pause/Answer/End Call
- Volume Down

(R) BOTTOM

- 1 LED Indicator
- 2 USB-C Charging Port
- 3 Aux line-in
- 4 Microphone
- 5 ANC On/Off

TOUCH CONTROLS

- Play/Pause:** Tap **[▶|]** once.
- Next Track:** Hold **[+]** for 2 seconds.
- Previous Track:** Hold **[-]** for 2 seconds.
- Volume Down:** Tap **[-]** once.
- Volume Up:** Tap **[+]** once.
- Answer/End Call:** Tap **[▶|]** once when receiving/ending a call.
- Reject Call:** Hold **[▶|]** when receiving a call.
- Redial:** Double tap **[▶|]** to redial most recent number.
- Active Noise Cancelling (ANC) Mode:**
Long press the **[ANC]** to turn ON ANC mode. The indicator light will be green.

Long press the **[ANC]** to turn off the ANC mode. The LED light will turn off.
- Activate Voice Assistant:** Triple Tap **[▶|]** Button.

Aux line-in

Insert the 3.5mm audio cable into the AUX port and connect the other end to your MP3/MP4 player, mobile phone, or other compatible device to play music.

WHAT'S INSIDE

- ANC Bluetooth® Wireless Headphones
- USB- Charging Cable (19.7 inches)
- Auxiliary Cable (39.4 inches)

TROUBLESHOOTING

If you are unable to connect your headphones to your Bluetooth device, please try the following steps:

1. Ensure your headphones are turned on and fully charged
2. Make sure your your phone or Bluetooth playback device's Bluetooth setting is on
3. Please charge the headphones and Bluetooth device
4. Restart your Bluetooth device

Tips

- Performance can be affected by the environment or when the headphones become discharged
- Interruption can be caused by obstacles between the earphones and the Bluetooth device, by wi-fi or other high frequency signals, or if the earphones are brought out of range of the Bluetooth device (approx. 33 ft)
- To maintain healthy battery performance, charge the charging case (and earphones) periodically, if not in use