



OWNER'S MANUAL


Please read and understand all precautions prior to use.

Thank you for choosing a premium New Bright product.

CONTENTS


Component Checklist

- (1) R/C Vehicle With USB Cord
- (1) Transmitter
- (2) AA Batteries



VEHICLE

Features



The ON/OFF Switch controls the main power to the vehicle. To save battery life, always remember to put switch in the OFF position when not in use.

BATTERY

USB Smart Charge Technology

This product is equipped with USB Smart Charge Technology. The built-in "smart chip" can recognize the power output level of your chosen USB charging device. Charge times will vary between charging devices. Charging from a wall outlet with a USB adapter may be faster than charging from a USB port on a computer. Using Advanced USB Power Delivery, the smart chip will charge the vehicle's internal battery at the fastest speed allowed by your charging device.

Charging the Vehicle

This vehicle is equipped with an internal Lithium-Ion battery that is recharged via USB. **ON/OFF Switch must be in the OFF position prior to charging.**

1. Locate the ON/OFF switch and USB cord on the under side of the vehicle.
2. Turn the ON/OFF switch to the "OFF" position.
3. Slide open Storage Compartment cover.
4. Remove USB cable from the Storage Compartment. (Use care when extending cord as it is attached to inside internal battery). Cord can be plugged into any computer or USB outlet adapter (not included).



5. While charging, the LED under the vehicle will be on. Once fully charged the LED will turn off. Charging is completed in approximately 1 - 1.5 hours depending on the type of charging device you use. Return cord and secure storage lid before operating the vehicle.

TRANSMITTER

Features and Functions



FORWARD/REVERSE DRIVING
Push BOTH joysticks forward for Forward Driving.
Push BOTH joysticks back to drive in Reverse.



TRANSMITTER

Battery Installation

1. Locate the Transmitter Battery Compartment, which is on the back of the Transmitter.
2. Move the Battery Compartment Lock towards the Battery Compartment and remove the Battery Compartment Cover.
3. Insert 2 "AA" batteries. Make certain the plus (+) and minus (-) markings on the batteries are in the same position as the plus (+) and minus (-) markings inside the Battery Compartment.
4. Replace Battery Compartment Cover making certain that the Battery Compartment Lock has "snapped" into the locked position.

Note: When replacing batteries:
- Use original batteries only.
- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.



Precautions and Care



SUPPORT

Trouble shooting & Support

Problem - Vehicle does not move or moves slowly.
- Make certain there are fresh batteries in the transmitter and that they have been installed in the correct position.
- Are the (+) and (-) markings on the batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Are the metal contact tabs touching, only or dirty in the transmitter?
- Has the rechargeable internal battery been fully charged?
- Make certain that the vehicle ON/OFF switch is in the "ON" position.

Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.
- Make certain there are no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

Always remove Batteries from transmitter when not in use.
Do not disassemble batteries in fire. Leakage, explosion and personal injury may result.
Do not attempt jumps or tests with this vehicle.
Do not attempt to remove internal battery.
Do not use included USB cord for anything other than its intended purpose.
Always keep USB cord stored when not in use.
Adult supervision recommended.

F.C.C. 2016 Rules
This device is not to be used in any way that is prohibited by the FCC. The user is responsible for the consequences of any use of this device that is not in accordance with the FCC Rules. This device is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARRANTY
New Bright warrants its products to be free of defects in materials and workmanship under normal use for a period of 90 days from the date of purchase. This warranty does not cover damage caused by misuse, accident, or other causes not within the scope of the warranty. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty.

USA & Canada

New Bright Customer Service

New Bright Customer Service is the original source for all information on New Bright products and accessories. Please call or write to New Bright for more information. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty.

Should you ever have a defect under this warranty, this will be the first time you will contact New Bright. Please do not contact New Bright again unless you have a defect under this warranty. Please do not contact New Bright again unless you have a defect under this warranty. Please do not contact New Bright again unless you have a defect under this warranty.

When returning a defective product, please package the product in the original packaging. Please do not use the product again unless you have a defect under this warranty. Please do not use the product again unless you have a defect under this warranty. Please do not use the product again unless you have a defect under this warranty.

New Bright warrants its products to be free of defects in materials and workmanship under normal use for a period of 90 days from the date of purchase. This warranty does not cover damage caused by misuse, accident, or other causes not within the scope of the warranty. New Bright is not responsible for damage to the vehicle or its components caused by misuse, accident, or other causes not within the scope of the warranty.

Warranty only in the USA & Canada

Contact New Bright Customer Service for more information.
1-877-466-7575
1-877-466-7575

Monday through Friday 9:00 AM to 5:00 PM Eastern Time

U.S. for Sales and Marketing Co., Inc.
2000 Glen Cove Drive - 3rd Floor
Glen Cove, NY 11545
1-877-466-7575
http://www.newbright.com

This transmitter is equipped with 2.4GHz technology which allows up to 8 vehicles to be raced at the same time.

The transmitter will automatically sync with the vehicle.

