

Date: 28 JUN 2023 Product: SP-0225 IM SKU:



SP-0225 IM

Size: 322.5(w) x 100(h) mm





Wireless Speake 1. LED Indicator (Speaker) 2. USB Type-C Charging FM Radio Mode Button

Charging Dock

Charging your Wireless speaker

wall adapter to begin charging.

fully charged.

more than 6 months.

to charge the product, as it might damage the product.

Charging your wireless speaker with charging dock

1. Use the USB Type-C charging cable provided with this wireless speaker.

- 2. Connect the USB Type-C plug to USB Type-C port on the charging dock, then connect the USB plug to the USB port on a computer or wall adapter. 3. Place the wireless speaker on to the
- charging dock to begin charging. 4. The light will turn red while charging
- and will turn off once fully charged.

Technical specification

Specifications Driver Diameter: 45 mm Impedance: 3.2 Ohms Power Supply: Li-ion Battery 3.7V 300 mAh Playtime: 1.5-2 Hours Charging Time: 1.5-2 Hours Bluetooth Range: 32.8 Feet Bluetooth Version: 5.3 USB Type-C Charging Cable Included FM Radio Mode

FAQ

. If the Wireless speaker cannot be paired with your device, please try the following

Ensure that your speaker is in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated

. If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

A Safety instructions for the lithium battery and charging the product

- -The input voltage to the product is DC 5V 1A.
- -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/adapter for charging the product. -Only charge the product at ambient temperatures between 10°C/50°F and 40°C/104 °F
- Do not heat above 70°C/158°F, eq. Do not expose to sunlight or throw into fire. -Switch off the product after use.
- -Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property. and we cannot control the operating process during the time the user using this

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FC.

Class 1 LED product

FCC ID: 2ADM5-SP-0225

For Future Reference

ITEM# SP-0225 Distributed by 1616 Holdings, Inc.

701 Market Street, Suite 200 **Keep All Relevant Information**

Philadelphia, PA 19106

Made in China



4. Volume Up/Next Song Button 5. Volume Down/Previous Song Button 6. USB Type-C Charging Port (Charging Dock) 7. LED Indicator (Charging Dock) **Package Contents** 1(One) Spectrum LED Wireless Speaker 3.15in. x 5.83in. x 3.15in. (8cm x 14.8cm x 8cm) 1(One) Charging Cable 11.8in. (30cm) 1(One) Instruction Manual Power On/Off Power on Press and hold 2 second on the Power Button. Power off Press and hold 2 second on the Power Button. Note: Always power off the speaker when not in use. Pair Wireless speaker with your mobile device 1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet. 2. Power on the wireless speaker. 3. Activate the Bluetooth function on your phone within range and select "BT SPECTRUM SPEAKER" from the list shown. 4. You will hear a beep sound when pairing is successful

Reconnect Wireless speaker to your mobile device

the last successfully paired device.

When powered on, the wireless speaker will automatically connect with

USB Plug USB Type-C Charging Plug ACAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product. Change to FM Radio Mode Short press the Power Button one time to change to FM Radio mode. Short press the Power Button one more time to change to Bluetooth mode.

⚠ For your safety, please always use appropriate 5V output charger/ Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter

1. Use the USB Type-C charging cable provided with this wireless speaker.

speaker, then connect the USB plug to a USB port on a computer or

2. Connect the USB Type-C plug to USB Type-C charging port on the

3. The LED Indicator will turn red while charging and will turn off once

You must select a qualified charger from a regular manufacturer.

You must charge the Wireless speaker if it has been not used for

Approval: Date: