产品规格

产品名称	PXN Sense Elf S2			
连接方式	无线连接			
输入	DC 5V 1A			
频响	20HZ – 20KHZ			
最大工作距离	10米(无障碍)			
工作时间	约5小时			
充电方式	约 1.5 小时(耳机) 约 2 小时(充电盒+USB–C数据线)			
产品尺寸	约61.5*61.4*32mm (充电盒)			

注意事项


- 1)避免保存于潮湿、高温、油烟等场所。
- 2)避免水或其它液体进入耳机内。
 3)避免长时间高音量使用耳机,如果出现耳鸣、耳痛等现象,应该停止收听。
- 4) 如有质量问题或建议请与销售商或售后人员联系。
- 警告:本产品的可充电电池必须妥善处置,以便回收利用,请不要将电池放入火中,以免 引起爆炸。

建议:如果长时间不打算使用耳机,请您储存在干燥的地方;每月至少需要为耳机充电— 次以延长电池使用寿命。

- 14 -

Overview & Package Contents

Package contents includes PXN Sense Elf S2 Earbuds, 3 sizes of earbuds tips (M size tips are installed in the earbuds), USB-C cable and user manual.





- 13 -

			Auto Power ON & OFF
接听来电 📞 结束通话 🎜	点击2次(L/R) 双通有声	()	 Open the charging case and the earbuds will power ON automatically. Put the earbuds back to the charging case and close the case, the earbuds will power OFF and enter the charging state. If no connection to any smart device for more than 3 seconds after removing the earbuds from the charging case, the earbuds will power OFF automatically.
拒接来电 🔝	长按2s(L/R)	长按2s	Manual Power ON & OFF • Under power OFF state, long press the touch senor area on the L & R earbuds simultaneously for 3 seconds to power ON. (Voice guidance: Power ON.) • Under power OFF state, long press the touch senor area on the L & R earbuds simultaneously for 5 seconds to power ON. (Voice guidance: Power OFF.)
游戏模式 🞮	点击3次 (R) 语音提示:Game Mode	E# R	Connect Smart Device in Dual Earbud Mode • For the first use, the earbuds indicator will keep on White for 2 seconds after removing from the charging case. (Voice guidance: Power ON.) L & R earbuds will pair automatically. (Voice guidance: Beep.) After successful pairing, the White and Blue indicator will flash alternately and enter the Bluetooth Search
			state. (Voice guidance: Pairing.) Now can connect with the smart device. PXN Sense Elf S2 • Open the Bluetooth on the smart device and search "PXN Sense Elf S2" to pair.

S-S2-V01-2205


音乐模式 🕽	点击3次(R) 语音提示:Music Mode	V
激活语音助手 开启/关闭	点击3次(L)	() 三击 L
耳机RGB灯模式 开启/关闭	点击4次(L/R)	四击 L/R
	- 12 -	

If you need to re-pair under special circumstances, please follow these steps: • Double click the earbuds simultaneously when L & R earbuds enter to the search state. The White

indicator on the earbuds will enter the breathing flash state and start to pair. • The indicator on the earbuds will flash in White and Blue alternately after successful pairing. (Voice guidance: Beep.) Now can connect with the smart device.

Indicator State

Earbuds	P l ay	Game	Music	Standby	Incoming call
Mode	Mode	Mode	Mode	Mode	Mode
Indicator State	Blue/White light Breathing cycle flashing	Blue light flashes	White light flashes	Blue/White light flashes 4s/time(under Game mode/Music mode)	White light flashes quickly



自动开关机

- 将充电盒打开,耳机自动开机。
- 将耳机放回充电盒内,并关闭充电盒,耳机将关机并进入充电状态。
- 取出耳机后超过3分钟未连接智能设备,将自动关机。

手动开关机

- 关机状态下,同时长按左右耳触控区域约3秒,耳机开机。 (语音提示: Power on)
- 开机状态下,同时长按左右耳触控区域约5秒,耳机关机。 (语音提示: Power off)

双耳机模式连接智能设备

- 首次使用耳机时,从充电盒内取出耳机白灯长亮 2 秒(语音提示: Power on) 左右耳将自动配对 (语音提示:嘟嘟), 配对成功后白蓝灯交替闪烁进
- 入蓝牙搜索状态(语音提示:Pairing)此时可与智能设备进行连接。 将智能设备蓝牙开启,寻找到设备为"PXN Sense Elf S2"的名称, 点击"配对",耳机与设备配对成功后(语音提示: Connected)。

单耳机模式连接智能设备

•从充电盒中取出左/右耳时,按上述双耳机模式配对完成连接即可。

自动回连

- 打开充电盒,耳机将自动回连最后一次成功连接过的智能设备。
- 当耳机与智能设备超出有效距离即断开连接(语音提示: Disconnected); 在3分钟内回到有效距离内,自动重新连接。

左右耳机的TWS配对连接

耳机出厂时,正常情况左右耳机已成功完成TWS配对,连接设备可正常使用。

- 当特殊情况下您需要重新配对时,请按以下步骤操作: 左右耳机进入搜索状态时,同时双击耳机,耳机白色指示灯进入呼吸状态,开始配对。
- 左右耳配对成功后 (语音提示:嘟嘟),双耳指示灯进入白蓝灯交替闪烁,此时可与智能 设备进行连接。

- 10 -

Charging

When using the charging case for charging at the first time, please put the earbuds back into the charging case and close the cover. Use the data cable included with this product to connect to the power supply for charging.

Earbuds Charging	Put the earbuds into the charging case and close the cover for charging	When the earbuds are charging, the white indicator on the earbuds will remain on for 3 seconds and then the indicator will be off gradually. After fully charged, the corresponding RGB White light will remain ON for 3 second and then OFF.	
Charging Case Charging	Use the USB-C cable included for charging	During charging, L/R indicator is red breathing flashing. When fully charged, L/R indicator will remain Green for 1 minute and then OFF	

Restore Factory Settings (Operate with Caution)

- Restoring the factory settings will clear all pairing information of the earbuds.
- Under Power OFF state, long press the touch sensor area for 10 seconds until the earbuds are turned off again. After the restoring is completed, the Blue indicator on the earbuds will remain ON for 2 seconds and power OFF.
 Please follow the steps in "TWS Pairing Connection of L & R Earbuds" to complete the TMS experimentation of the temporation of t

- (he The earbuds will be paired with the smart device fu**ll**v. (Voic
- Connect Smart Device in Mono Earbud Mode
- Remove the L / R earbuds from the charging case and pair it according to the above dual earbud mode to complete the connection.

Auto-Reconnection

- . Open the charging case, and the earbuds will automatically connect back to the last successfully connected smart device.The earbuds will be disconnected with the smart device when they are beyond the effective distance.
- (Voice guidance: Disconnected.) Return to the effective distance within 3 minutes, the earbuds and smart device will reconnect automatically.

TWS Pairing Connection of L & R Earbuds


When the earbuds leave the factory, the L & R earbuds have successfully completed TWS pairing under normal conditions, and the earbuds can be used normally after connecting with the smart device - 2 -

耳机模式	播	放模式	游戏模式	音乐模式	待机模式	来电模式
指示灯 状态		/白灯 吸循环	蓝灯 闪烁	白灯 闪烁	蓝/白灯 4s/次	白灯 快闪
功能		触招	触控操作说明		手势	
播放/暂停)	• / 11	点击	2次(L/R)	T T	XX	、击 L/R
音量 ◀》		点击1次(L-/R+)			, and the second	è击 L- /R+
上 — 曲 ₩	≟—⊞ ₩		长按2s(L)) 长按2s	
下──曲 ▶▶ 长按2s(R)			长按2s			

Answer a call 🔇 End call 🔗	Click 2 times (L/R) Two–way voice	Contraction Double-click	
Reject call 🛭 😞	Hold press for 2s (L/R)	Hold press for 2s	
Game mode 🎮	Click 3 times (R) (Voice guidance: Game Mode)	Olick 3 times (R)	
Music mode よ	Click 3 times (R) (Voice guidance: Music Mode)		
Activate voice assistant ON/OFF	Click 3 times (L)	Click 3 times (L)	
Earbuds RGB mode ON/OFF	Click 4 times (L/R)	Click 4 times (L/R)	
	- 4 -		


概览和包装清单

包装盒中包含PXN Sense Elf S2真无线电竞耳机及充电盒,3种尺寸的耳帽(M号耳帽已预 装在耳机上), USB–C数据线,使用说明书。



设置 蓝牙





真无线游戏耳机 使用说明书

Q: Bad signal in call when using the earbuds?

A: a. Confirm whether the smart device is in the area with strong signal.

- b. The effective distance of the earbuds is 10m, please make sure that the earbuds are within the effective distance and there is no obstacle between the earbuds and the smart device.
- Q: Unable to pause, resume, previous song and next song control when using the earbuds to play music?
- A: This function requires that the device paired with the earbuds supports the AVRCP protocol. (Audio/Video Remote Control Profile.)

Product Specification

Product Name	PXN Sense Elf S2		
Connection	Wireless connection		
Input	DC 5V == 1A		
Frequency Response	20HZ – 20KHZ		
Maximum Wireless Range	10 m (Barrier-free)		
Battery Life	About 5 hours		
Charging Method	About 1.5 hours (earbuds charging) About 2 hours (charging case + USB–C cable charging)		
Product Size	About 61.5 * 61.4 * 32 mm (charging case)		

- 6 -

Attention

- Avoid placing in humid, high temperature or soot place.
- Prevent water or other liquids from entering the inside of the earbuds.
- Avoid using the earbuds at a high volume for a long time. If tinnitus or earache occurs, please stop using.
- . If you have any problems or suggestions about the product, please contact the seller or the after-services
- Warning: The rechargeable battery of this product must be disposed of properly for recycling, please do not put the battery into the fire to avoid cause an explosion.
- Advise: If not use the earbuds for a long time, please store it in a dry place. The earbuds need to be charged at least once a month to extend the battery life.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the Connect the equipment and an other of a circuit dimension from the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help

- 7 -

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please read the manual carefully before using, and keep this manual for future reference

PXN Sense Elf S2

- 8 -