

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in aresidential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipment off and on, the useris encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician

Changes or modifications not expressly approved by iKF could void the user's authority to operate this equipment. his device complies with part 15 of the FCC Rules standard(s). Operation is subject to the following two conditions: This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation. This device complies with FCC radiation exposure limits set forth for general population.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits se forth for an uncontrolled environment. This equipment should installed and operated with minimum distance 0cm between the radiator and your body.

For assistance with this product, please contact our custome service at the website where you purchased the product. leave a message or email us, we will answer as soon as possible.

Company: Dongguan Oumu Technology Co., Ltd. Address: Room 315–318. Building D. Nanxin Industry International. Nancheng District, Dongguan City, Guangdong Province, China Website: http://ikf.net.cn Email : supportikf@163.com


Specifications

Model: iKF-R1 Bluetooth version: 5.3 Power input: DC 5V Input parameters: 300mA Charging interface: TYPE-C USB Battery capacity; 400mAh harging time: about 2 hours Supporting agreement: HSP/HFP/A2DP/AVRCP

Charging Your Headset

For the first time use, please fully charge the product.

Charging: Light is always on Full power: Light off Charging time: 2 hours



Warnings

When charging the headset, to avoid damage to the battery, it is recommended to use a 5V/2A charging head to charge The power of the charging head should not exceed 24W. Avoid using car charger/fast charging power bank or charging head with unknown power for charging, there may be situations where charging cannot be performed or the power consumption is too fast and the signal is poor.



ower On/ Off

Power on: Long press the power button 3 seconds and hear the prompt that it is turned on; Power off : Long press the power button 3 seconds and hear the prompt that it is turned off;

ransparent Mode

Turn on : Double-tap the power button, hear two prompts to enter the transparent mode Turn off : Double-tap the power button, hear a prompt sound o exit the transparent mode

How to connect

. Long press the power button 3S and hear the prompt that it is turned on:

Open the Bluetooth interface of the mobile phone. search for "iKE-R1", click to connect:

3. After the first pairing and connection is successful, the headset will automatically connect to the last mobile phone with a connection record every time it is turned on, and there is no need to repeat pairing.



Tap the power button	Answer/ Hang up
Long press the power button	Incoming telegram: Reject
Media Functions	
Tap the power button	Play/Pause
Tap the power button Tap the + button	Volume up
	,
Tap the + button	Volume up

ransparent mode

Double-tap the power button and hear beep twice which means that the transparent mode is turned on. Double-tap the power button and hear beep once which means that the transparent mode is turned off.

rn on /Turn off game mode

Triple-tap the power button and hear 3 beeps indicating. which means that the game mode is turned on. Triple-tap the power button and hear 1 beep indicating, which means that the game mode is turned off.

connect/Res

and connect.

In the shutdown state, press and hold the "power button" for 5S to force the headset to enter the pairing state.re-search

iKF APP connection

Android phone connection

1. The headphone is turned on and the Bluetooth of the mobile phone is turned on, and the APP is running on the page

- 2. 1 APP page pop-up window pops up the model, just connect On the home page of the APP, click "e " in the upper right corner to add a device
- 3 After automatically searching for the device, click "Connect".

iOS system device connectio

- Need to manually connect the headset on the iOS device Bluetooth page
- Open the iKF APP page
- ② On the home page of the APP, click " ⊖ " in the upper right corner to add a device
- 3 After automatically searching for the device, click "Connect".

TIPS

 Make sure the headset and the connected device are within a valid connection range and there are not too many obstacles that interfere with the signal: 2、It is normal for the headset to be disconnected occasionally, Just like WiFi, occasionally the connection is During the warranty period of the product, due to the quality unstable. It may be due to interference in signal transmission. Please wait a moment or change the location to resolve:

3. When the headset cannot be connected to the device, please check whether the headset has power or is connected to other devices:

4. Please fully charge the Headphone once a month. If the Headphone isnot used for a long time, the battery of the Headphones may be damaged.

5, The sound insulation and sound leakage of headphone are related to the way of wearing the headphones and the volume of the headphones.

You can adjust the wearing angle and degree of ear wrapping of the headphones in time according to the actua comfort of use. Please close the ear/head foam part of the headphone as much as possible.

6, Please use a standard-compliant charging head to charge the headset.

3. APP page pop-up window pops up the model, just connect 7, Do not wear the product for bathing, or use it in the rain, and do not soak the product in water. After each normal use, it is recommended to dry the sweat or stain on the headphone with a dry cloth, paper towel, etc., an then store it.

Limited warranty

Warranty period 1 year from the date of product receipt

of the product itself, please contact us with the warranty card and shopping records to receive a return authorization / fre maintenance and shipping instructions.

Fault Table

Bluetooth headset cannot hear sound;

. The other side cannot hear the voice during the call:

Unable to charge Bluetooth headset

The following conditions will not provide free repair

Unauthorized maintenance, misuse, collision, neglect, abuse, accident, alteration, or damage or alteration of the appearance of the product; 2. The product exceeds the warranty period specified by the company: 3.Damage caused by self-disassembly; Failures caused by accidents such as water ingress or falling, squeezing, etc; Normal wear and dirt caused by use, such as scratches, damage caused by contact with chemical reagents, contact with sharp objects, etc: 6. Outer packaging and accessories, gifts, services other than the products promised by the sales staff, and additional configurations and gifts; Improper storage: If the product is exposed to abnormal humidity and temperature for a long time, the performance is damaged; 8. Failure or damage caused by force maieure:



Focus on interestin musical products

Made in China