


PHOTOGRAPHS OF THE TEST CONFIGURATION

Set UUT as Slave mode (Radar injected into Master) (For Slave Mode)







Set UUT as Slave mode (Radar injected into Master) (For TDLS Mode)