



| Name of key | Letters or functions |
|-------------|----------------------|
| 1key        | .,?!"'~@::/_ 1       |
| 2key        | ABCab2               |
| 3key        | DEFdef3              |
| 4key        | GHIghi4              |
| 5key        | JKLjkl5              |
| 6key        | MNOmno6              |

|                                   |                                                                                                                                                                                                                |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7key                              | PORSpgs7                                                                                                                                                                                                       |
| 8key                              | TUVTu8                                                                                                                                                                                                         |
| 9key                              | WXYZwxyz9                                                                                                                                                                                                      |
| 0key                              | 0                                                                                                                                                                                                              |
| *key                              | 1. After inputting telephone number, if you want to input extension number, please press twice asterisk key, after the display screen shows "+", please input your extension number.<br>2. *27 @: # \$ % - ... |
| #key                              | 1. In text editing interface, press "#" key to switch the text input method.<br>2. On the standby interface Press and hold "#" key to transfer the profile of General/Silent/Vibrate.                          |
| Scrolling Up<br>Scrolling down    | Move cursor up<br>Move cursor down                                                                                                                                                                             |
| Scrolling left<br>Scrolling right | Move cursor left<br>Move cursor right                                                                                                                                                                          |
| Left soft/ right<br>key           | In the standby mode, press Left Soft key to access Main menu, Right Soft key to access Contacts.                                                                                                               |
| Ok key                            | determining options                                                                                                                                                                                            |
| Dial key                          | dial telephone numbers and receive incoming calls                                                                                                                                                              |
| End                               | 1.Return to idle screen 2.End calls or reject incoming calls.                                                                                                                                                  |

|                                                                                   |          |
|-----------------------------------------------------------------------------------|----------|
|  | Contacts |
|-----------------------------------------------------------------------------------|----------|

|                                                                                     |              |
|-------------------------------------------------------------------------------------|--------------|
|  | Message      |
|  | Call logs    |
|  | Settings     |
|  | Multimedia   |
|  | File manager |
|  | Application  |
|  | Profiles     |
|  | Internet     |
|  | FM Radio     |
|  | Audio        |
|  | Calendar     |

- 3 -

- 10 -

- 11 -

■ Le non-respect des restrictions ci-dessus peut entraîner une violation des consignes d'exposition aux RF.

- 12 -

#### 4.1.Call Settings

Your phone provides the following selections for your option:  
Dual-SIM: Standby mode/Reply by original SIM/Set SIM name  
Call divert: call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel all diverts  
Call waiting: Activate/Deactivate/Query Status.

memory for camera, you need to delete old photos to free some spaces for new photos or you can choose to save

|                                                                                                        |                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| photos in memory card. The status of your camera setting will be displayed on the top of preview mode. |                                                                                                                                                                    |
| Store photos                                                                                           | You can review pictures you have taken by pressing OK                                                                                                              |
| DV mode                                                                                                | Switch to DV mode                                                                                                                                                  |
| Effect                                                                                                 | Set photo color                                                                                                                                                    |
| Settings                                                                                               | Size:Set photo size<br>Quality:Set photo quality<br>Banding:to avoid flashing<br>Shutter sound:activate/off<br>Auto save:activate/off<br>Storage:phone/memory card |

To view the file memory.

- Auto search and save:Search frequency available automatically.

---

- 11 -

■ Le non-respect des restrictions ci-dessus peut entraîner une violation des consignes d'exposition aux RF.

- 12 -

#### 4.1.Call Settings

Your phone provides the following selections for your option:  
Dual-SIM: Standby mode/Reply by original SIM/Set SIM name  
Call divert: call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel all divers  
Call waiting: Activate/Deactivate/Query Status.