

**FIREBULTT**



**BSW042**  
**Smart Watch**  
**User Manual**

## Downloading and connecting of smart watch with Do Fit APP


1. Download and install Do Fit APP
2. Scan QR code with mobile phone to download APP.
3. For IOS system, select APP Store, search for Do Fit App.

Android system, select Google Play to download and install Do Fit App. Or scan QR code to download



Note: your mobile phone must support Android 5.1 or iOS 9.0 or above, and Bluetooth 4.0 or above.

### Connect smart watch with Do Fit APP




Click on "Add Device" to connect the smart watch



Click on your device in the device list scanned. Connect it directly to Android system.



The IOS system will show a Bluetooth pairing request and you can click on Bluetooth "Pairing" to confirm.



Successfully connected



For both android & iOS click on Notifications Tab in the Dafit app

**NOTIFICATIONS**

Enable all the notifications  
for the ease of use

**BLUETOOTH CALLING FUNCTION**

This watch comes with a special feature of Bluetooth calling. The user can make calls without having to open the phone. You can also view the call history of the watch. You need to keep the connection between the watch and the phone stable when using the Phone Call function.

The watch also has a microphone and a speaker built in for the ease of talking through the watch and to hear music, phone calls, and other notifications.

Follow the steps to activate the calling function and much more.

**Part A - How to connect**

- **Step 1:** After connecting the watch to the Do Fit App, you need to go the bluetooth settings of the phone and pair the watch there as shown below.

## For iOS



Switch on the bluetooth in the phone bluetooth settings and you shall see the available device as "FB\_BSW042\_PHONE"

# shall show Connected

## For Android



Accept the Bluetooth Pairing Request



Once accepted you can see the following screens saying  
- **"Connected for calls & audio"**

- **Step 2:** Go to the watch and swipe left to the phone function.



- After successfully connecting the bluetooth you will get this screen.
- Upon clicking on the recent call you can see the recent calls of your device



- When you click on the dial pad you shall get this screen on your watch.



- Once you digi the number the call button on the right corner shall appear.



- You click the dial button, you can see that the number is dialling



- Through the microphone available in the watch you can talk through the watch and adjust the speaker volume by the + & - sign on the watch and disconnect the call.

### Part B - How to disconnect.

To disconnect the bluetooth calling the user simply has to go to the phone's bluetooth setting and "unpair" the FB\_BSWD42\_PHONE device

### Part C - Add contacts



- You can add upto 8 contacts - Add the contacts from the Daft App. Go to "Favourite Contacts" and add contacts. The selected contacts will get synced to your watch.

Click on Favorite Contact to add the contacts



Select the contacts you want to add.

The contacts will get added.

#### Part D - Switch between Phone / Watch

**Switch Between Watch / Phone During an Active Call :** If your watch is connected to the Phone via Bluetooth, all calls will come on the watch by default. If you want to change the call to the phone, during an active call, simply click on Handset earpiece icon to select it. The call will then come on your phone.



## Part E - Battery Advisory

### Battery.

- The battery lasts for 3 to 5 days with bluetooth calling mode enabled.
- If the bluetooth calling mode is disabled then the battery can last for 7 days.
- On standby the battery can stay for as long as 20 days.
- Advisory- To conserve battery, it is advised to turn off the bluetooth when not in use.

## Functions Navigation

The screen can be navigated by sliding left/right or sliding up/down



## Watch Face Functions Navigation and Button Instructions

The watch features a full touch control screen with a reflective display and two buttons.

### Functions Navigation

The screen can be navigated by sliding left/right or sliding up/down.

By default, the watch face page displays, and on the watch face page, you can:

- Slide down to view watch settings.



- Battery Saver
- Themes
- Flashlight
- Vibrate
- Brightness
- Settings

- Slide up to view messages and other notifications.

