User Manual A WARNING: **ET LED DESIGN HEADPHONE** FCC statement: + Love Bettery: LED light fleshes, in red. This device complies with Part 15 of the FCC Roles. Operation is subject to the · Charge and operate only as indicated in this manual, as improper use may . To Charge: following two conditions: result in damage to the product or invev-OH/OF/Play/Places (1) this device may not cause harmful interference, and (2) this device . To evoid risk of shock or injury, do not diamentle the device or insert any 1. Insert the USB connector end of the included cable (see packing list) into the USB objects into the Resphone. must accept any interference received, including interference that may cause. lack on the charger or USB port on the computer. *To avoid electronic interference and/or compatible conflicts, turn off the Next area / Yourse Up. undesired operation: 2. The indicator light will be red while charging. product in any facilities where posted notices instruct you to do so. . Do not pull the Heaphone charging cable. Demage may result to the cable. 3. When the headphone is fully charged, the indicator light will turn of from being red. Priestove worse l'interne Dieser-. Keep out of reach of children. This is not a toy. Please singling your changer from the power source. - SSLINE · Avoid exposure to moisture, liquids, heat, flame and high voltage equipment. 4. Places use a qualified charger to recharge your hondphone. If red, it may result in More USB Charging Port. . Retain these instructions as they contain important information. This equipment has been tested and found to comply with the limits for a damage or even explosion. . Do not short circuit the input terminals of the Heaphone. Ministerie Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are 5. Repeated charging and discharging of the headphone will lead to decreased battery Do not drop, place heavy weight or allow heavy impact to the Heaptyone. **IEC Indicator** designed to provide respondite protection against harnful interference in a We over time, which is normal for rechargoodile Setteries. . PCB of bettery should not be crushed and twisted. residential installation. This equipment generates, uses and can radiate radio 6. You must charge the Bluetooth Heaphone If it has not been used for more than 6. · Battery body should not be Sended. frequency energy and, if not irretalled and used in accordance with the months. . Do not disassemble and Do not dispose of in fire. Package Contents: instructions, may cause harmful interference to radio communications. . Do not use the product while driving or crossing the road. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or "Sturricoth freadphone v1. RF energing statement: . Charging ceble sit. television reception, which can be determined by turning the equipment off and The device has been evaluated to meet general RF exposure requirement. . Usor's Marsan of on, the user is encouraged to by to correct the interference by one or more of the The risvice can be used in portable exposure condition without restriction. Many Intel Prop. the following measures: Regrierd or relocate the requiving entering. Button Description F00 0 2A2H6-MU01035 Technical Specifications Increase the asparation between the equipment and receives. · Connect the equipment into an outlet on a circuit different from that to which 301. Building Plant No.5 Anliang Road, Xi Keng Community, Longgang district. "C" ONOFF Passa Play Wasic + Model Number: MU01035 the receiver is corrected. - a - Short press for increase volume / long press flext song + Range: 30tt / 10 m Shenzhen, Guangdong, China Consult the dealer or an auguriamond radio/TV technician for help. - * Short press for reduce valures / long press Previous sang + Battery Capacity: 200 mAn . Voltage: 3.7 V. Play Time: 4-5 hours. WARNING: Changes or modifications to this unit rost expressly. How To Use: Keep At Retevent Information For Future Reference. . Charge Time: 2 hours approved by the party responsible for operpliance could void the user's . Charging Input IV 7T 150 mA Power on: Press the critoff key " (2) 2 seconds when it is off. The blue LED authority to operate the equipment. + Frequency Response: 30Hz-2004z light will be on, and begin to alternate blueted LED light. A voice will prompt "power on", Operating temperature range: 0.45 C this indicates the healthfore is in pairing mode. Paining: Activate the blumboth function on your phone within range and select "BT LED HEADPHONE II" from the bid shown. When the blasted LED light stress fleating. if hos pierod successfully end you will hear "connected". The blue LED will turn off when playing music. Play/Pause: When it is playing, great the covidf key." (I to pause, then press the 1) Why can't I start my Bluetooth heapphone? onloff key " e's again to play. Amover: Please ensure that the headphone is fully charged for your first use. Wakene up: Press '+' once to increase the uplume 2) Why wan't sound come out of the healthcores? Volume down: Press "-" once to decrease the volume. Apparer: Check whether the playback device and the Bluetonth hearphore are Previous song: Hold down the "" to play the previous song successfully established. If the audio device is not properly connected. Next song "Hold down the "+" to play the next songplease reconnect. Please also adjust your mobile phone or Bluelooth healthforw. Phone Call Volume to a suitable volume level. Press (v) to answerrend a call. 3) Why can't I first this headphone in my tituelooth options? Press and hold "O" for about 1.5 seconds to reject an incoming call. Answer: Make sum the Shartoots is in "youtto mode". If no pairing occurs, the Power aff. When the headphone is an standby or operating, press and test the center Stustooth function will automatically shut off. Please reopen Elustooth to key "(f)" I seconds to shut down the headphone (voice prompt "power off") "visible mode". If there is a program error, please reboot your phone, and if program: error is caused by your Haletooth headphone, please restort the headphone.