

vtech Quick start guide



د محدت عبه بسخانانا (SOD) 972 أمانيا و SOD (SOD) 672 أباوعادل (SOD) 97223, United States (SOD) 1 (SOD) 972-9721 in the U.S. or 1 (SOD) 767-7737 in Canada The case of this user's manual. Vieth Communications, in an enter of this product.

Vieth Communications, In shirt parties that may also through the use of this product.

Vieth Communications, In.

Vieth Communications, In.

### DISCLAIMER AND LIMITATION OF LIABILITY

Zoom

Press ® to zoom in or out

	Parent unit, 2:8V ZUUMAN Li-non battery  Baby unit power adapter: Output: 3V DC @ 500mA  Parent unit power adapter: Output: 3V DC @ 21A
Power requirements	
Acminal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
TCD	5" Color LCD (WGVGA 480x272 pixel)
Channels	32

Baby unit; 2405 - 2475 MHz Parent unit: 2405 - 2475 MHz Transmit frequency TECHNICAL SPECIFICATIONS

#### **IMPORTANT SAFETY INSTRUCTIONS**

- responsibility. This product could cease operating, and therefore you should not assume it will continue working properly for any given period of time. Further, this is not a medical device and should not be used as such This record
- temporature and low air pressure at high affitude during use, storage or transportation. Disposal of battery into fite or a hot own, or mechanically crushing or cutting of the battery can result in an explosion. Leaving the battery in an externelly high temperature surrounding environment can result in an explosion or the leakage of filammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispo used battery according to the information in The RBRC sea

## Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously disease the product.

damage the pr...
Power adapter inform
Power init output: SV DC 1A

Rechargeable battery information:

crimped. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer of local power company.

receptions.

Precautions for users of implanted cardiac pacemakers
Cardiac pacemakers (applies only to digital cordiacs device
Wineless Technology Research, LLC (WTR), an independer
research entity, led a multidisciplinary evaluation of the
interforence between portable wireless device and

stribulinesses use per complete the stribulinesses and per complete the stribulinesses and the stribulinesses the stribulinesses the stribulinesses the stribulinesses the stribulinesses a short circlis. Hower gold liquid of any kind on the product.

To reduce the risk of electric thack, do not disassemble this product, but liste size of electric thack, do not disassemble this product, but liste size of electric thack, do not disassemble this product, but liste and the stribulinesses of the stribulines

SAVE THESE INSTRUCTIONS

Marning – Strangulation Hazard –
Children havd STRANGLED in cords. Keep
this cord out of the reach of children
(more than 3 ft (0.9m) away). Do not
remove this tag.

acemaker patients

Should keep wireless devices at least six inches from the paremaker. pacemaker. Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned ON

's evaluation did not identify any risk to bystanders with makers from other persons using wireless devices.

educt complies with all standards re-sc fields (EMF). If handled

RESET

14 Power iack

13 Stand

## WHAT'S IN THE BOX




## CONNECT THE BABY MONITOR

- The rechargeable battery in the parent unit is built-in
- Use only the power adapters supplied with this product.


  Make sure the baby monitor is not connected to a switch-controlled ele

Overview - Baby unit

Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.



#### POWER ON OR OFF THE BABY MONITOR 3 Positioning the baby monitor



4 STATUS CHECK

your baby unit and parent unit, your parent unit displays image from the baby unit, and the LINK LED light turns on.

The baby unit ON LED light



#### BASIC OPERATION - PARENT UNIT



Press a viii / vii a to adjust your parent unit

Adjust speaker volume

#### Talk to your baby unit Turn off the screen

Press and hold TALK and speak to your parent unit. Your voice is transmitted to the baby unit. Release TALK when finish talking and hear your baby again



Press and hold LCD ON/OFF to switch off the baby unit.



Press any key on the parent unit to turn on the

#### Use the menu

Press  $\frac{\text{MENU}}{\text{SELECT}}$  to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.

#### While in the menu


- Press MENU to select an item, or to save a setting.
   Press A or V to scroll among the sub-menus,
- or to adjust a setting.
- Press < to return to the previous menu options without changing the current setting.
- Press @ /EXIT to return to live video

Microphone


4 POWER

TALK

#### OVERVIEW - PARENT UNIT



VIEW/LCD ON/OF



10 Temperature sensor

13 Slots for wall mounting

11 Pair key

12 Power jack

- - 3 Gloss lens
  - 4 Microphone
  - Night light
  - On/Off switch On/Off LED light
  - On when the baby unit is turned on and is paired to the parent unit. Flashes when the baby unit is not being viewed; or when the link to the parent unit is lost.

## NEED HELP?

For operations and guides to help you operate your video monitor, and for the latest information and support, check out our online help topics and FAOr.

Go to https://help.vtechphones.com/vm\$254 or https://help.vtechphones.com/vm\$254-2; OR

Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the pop-up notification to be redirected to the online help page. If the GR code is not clearly displayed, adjust your camera's focus by me your device closer or further away until the image is clear.

You can also call our Customer Support at 1 (800) 595-9511 [in US] or 1 (800) 267-7377 [in Canada] for help.

麔





-**D**-



Baby unit speaker volume Adjust the baby unit's speake

Slide the ON/OFF switch to power on or off your baby unit

Press and hold POWER to power on or off your parent unit.

(3) 

Lullaby J ▶ / ■ Play/Stop Iullaby ≋1 ≋2 ≋3 ≋4

 Select one of the soothing sounds, or white noise. **11 11 2 11 3 11 4 11 5**  Select one of the five melodies. Play all melodies.

60min 45min 30min 15min Set timer to stop playing the selected melody or soothing sound.

# ■ PARENT UNIT ICONS

LINK



Change to all seven colors in cycles. 60min 30min 15min Set timer to turn the night light off.

OFF

• Select to set the night light to always on.

AUTO
Self to auto turn on the night light when baby unit defects sound. It will turn off after 15 mitures of no sound defection. You can self VOX sensitivity level to defect sounds to the control of th

ON/OFF

ON/OFF furn on/off temperature alert tone.
Set the parent unit to beeps when





Set the maximum temperature.

 Set temperature display in Fahrenheit
 (°F) or Celsius (°C) °F°C



Alert tone



Set the parent unit to beep when and the baby unit is lost.

Set the parent unit to beep when the baby unit detects sounds while in Split mode (For VM5254-2 only)

Sound activation - screen and audio

#### ON/OFF Turn on/off sound activation · Set sound activation on or off.

Set sound activation on or off.
 When it is on, and the baby unit detects no sound, the parent unit screen stays off to save power. Once a sound is detected, the parent unit screen and speaker turns on automatically, and you can see and hear your baby. The parent unit will then turn off again after 50 seconds of no sound detection.

Sound detection.

NOTE

When the parent unit screen is off and it receives alerts, for example, link lost between parent unit and baby unit, or battery is low, the parent unit screen and speaker will turn on for 10 seconds.

VOX (Voice Activated Alert) Sensitivity



· You can set VOX sensitivity level to activate parent unit screen and sound when baby unit detects sounds that exceed certain levels. See Sound sensitivity and sound activation section.



#### PARENT UNIT ICONS (CONT'D)

#### Connection status Till - Strong signal strength. Til - Moderate signal strength. Til - Low signal strength.

. T - Weak signal strength.

Patrol mode

(\*For VM5254-2 only) **Q**1 Current view status · The baby unit number that is <u>@</u>2 being viewed when in:

Single CAM mode. Patrol mode (\*For VM5254-2 only). Split mode (\*For VM5254-2 only).

C Night vision - On ⊕

 $\blacksquare$ 

П

· 🙀

Lullaby - On



Night light - Auto-on.

Color icon indicates the night light is set to auto-on, and is currently turned on by sound activation.

Gray icon indicates the night light is currently off but is set to auto-on. Night light will turn on when sound is detected by the baby unit.

#### Status icons

## °F or °C Real-time temperature Real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. 57 °F or 14 °C).

Temperature alert tone - On 9-level sound indicator

 indicates low sound level detected by the baby unit. indicates moderate sound level detected by the baby unit. • IIII indicates birth

sound level detected by the baby unit.

Mute alert

Displays when the parent unit speaker volume is set to off.

Displays when the parent unit is talking to the baby unit. animates

when the battery is charging.

ulii - battery is fully charged battery is low and needs

#### Alert icons

90

)))g

A

· Displays when parent unit's battery is low and needs charging.

Displays when connection between parent unit and baby unit is lost.

· Displays when sound is detected at a baby unit when in Split view. (For VM5254-2 only)

Baby unit detects temperature reaches or exceeds the set maximum.

#### Sound sensitivity and sound activation

#### Adjust sound detection sensitivity You can turn on Sound activation and adjust

the VOX sensitivity to detect sounds and turn on the parent unit while its screen is switched off or dimmed.

When the baby unit detects sounds that exceed certain levels, the parent unit stream will turn on and the baby unit starts transmitting the sounds to the parent unit, and you can see and hear your baby. If you have turned on the Night light Auto-on feature, it will turn on automatically to sooth

If you turn off Sound activation, you will hear sounds from the baby unit all the time, even when the parent unit screen is switched off. If you have turned on sound alert, the parent unit beeps when the baby unit detect sounds while in **Split** mode (\*For **VM5254-2** only).

VOX SENSITIVITY LEVEL	Level 5 (Highest)	Level 4 (High)	Level 3 (Medium)	Level 2 (Low)	Level 1 (Lowest)
			<b>₽</b> ≡	<b>₽</b> ≡	4
	(Default setting) The parent unit screen and speaker turn on for very small sounds, including background noises from your baby's	The parent unit screen and speaker turn on for soft babbling and louder sounds from your baby. The parent unit remains quiet when your	The parent unit screen and speaker turns on for loud babbling and louder sounds from your baby. The parent unit remains quiet when your	The parent unit screen and speaker turn on for crying and louder sounds from your baby. The parent unit remains quiet when	The parent unit screen and speake turn on for loud crying or screechi sounds froi your baby, parent unit remains qui when your

#### Sound activated screen and audio

When Sound activation is on, the parent unit screen stays off o save power when the baby unit detects no sound. Once the baby unit detects sounds that are louder than the chosen sound sensitivity level, the parent unit screen and speaker turn on automatically. The parent unit will then turn off again after 50 seconds of no sound detection.

MOTE







# Change different views - Single CAM

Change different views - Patrol

10s

For VM5254-2 ONLY

Status check - Two baby units

If you are viewing baby unit  $2 \frac{1}{2}$ , the **POWER** LED light of baby unit  $2 \frac{1}{2}$  turns on. As baby unit  $2 \frac{1}{2}$  is not

being viewed, its POWER LED light flashes.

In Single CAM or VIEW to switch of baby units 21 and @8

PNOTE



Press VIEW in Single CAM or Patrol mode to switch to the baby unit you have powered on.



## NIGHT VISION



The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and appears on the screen.

#### ■ Notes

It is normal if you see a short white glare on your parent unit screen as the baby unit is adapting to the dark environment. When the infrared LEDs are on, the images are in black and white. This is normal.

SE TIP

7.5 LIP.
Depending on the surroundings and oth interfering factors, like lightings, objects, colors and backgrounds, the video gustimary vary. Adjust the baby unit's angle or pisce the baby unit at a higher level to prevent glare and Burry display.

#### DIM MODE

The parent unit display will dim to conserve energy after 10 minutes of inactivity, in which there is neither key pressed nor alert received from the baby unit.









Select **Split** as your monitoring mode to view the images from both baby units at once.



### MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)

#### Notes

Check for reception strength and cam angle before drilling the holes.

angle before drilling the holes.
The types of screws and anchors you need depend on the composition of the wall. You may need to purchase the screws and anchors separately to mount your camera units.

1. Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill hit)



OR

If you drill the holes into a stud, go to step 3.

 If you drill the holes into an object other than a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the





4. Place the camera unit on the wall mount bracket, and then slide it forward until it locks into place. Connect the power adapter to the camera unit and a pow supply not controlled by a wall switch.



3. Insert the screws into the holes and tighten the screws until only 1/4 inch of the screws are exposed.

mount bracket, and then slide it forward until it locks into place. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.



5. You can maximize your camera unit's viewing angles by filting the wall mount bracket. Hold the camera unit, and then rotate the knob in anticlockwise direction. This will bosen the joint of the wall mount bracket. Till your camera unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.





#### THE RBRC SEAL

a convenient alternative to placing used Li-lon batteries into the trash or municipal legal in your area.

"The chip participation is useful in your lates.

VTech's participation hashed it easy for you to do they of this appent battery at local retailers participating in the program or at authorised VTech product service centers. Please call 3 (800) 8 ANTEKY for information on 1-i-on battery recycling an endoughout banch receitors in your area. VTech is reviewhern in the program is part of its commitment to producting our entered and consistency and are received.

The RRIC cast and 1-10-0 8 ANTEKY are registered trademarks of Califorcycle, Inc.

#### FCC AND IC REGULATIONS

#### FCC Part 15

FCC Part II

The equipment has been headed and found to comply with the requirements for a Class B digital device under Part II of the
hamily interference in a recidental installation. This equipment generates, uses and can redain and be frequency genergy
hamily interference in a recidental installation. This equipment generates, uses and can redain and be frequency genergy
recidence in the complex part of the complex part

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliant could void the user's authority to operate the equipment.

anvice. The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were

#### RF radiation exposure statement

FF radiation exposure statement the baby unit compile with PCC FF radiation exposure limits set forth for an uncontrolled environment. The baby unit should be installed and operated with a minimum distance of 8 in (20 cm) between the baby unit and all personn's body. Use of other accessorises may not ensure compliance with PCC FF exposures quicilents. This transmitter must not be co-located or operating in conjunction with any other relations or transmitter. This equipment compiles also with industry Canada RSS-102 with respect to Canada's Health Code for Feposure of Humans to RF Fields:

#### CALIFORNIA ENERGY COMMISSION BATTERY CHARGING TESTING MODE

This baby manifer meets the California Energy Commission (EES) regulations for energy consumption. You is set up to comply with the energy-conserving standards right out of the box. Follow the instructions to the battery, The CEC battery charging testing mode is activated while charging, Even if the parent unit is pa units, the CEC battery charging testing mode is activated while it is powered off and charging.

#### FOR CETL COMPLIANCE ONLY

# Mesures de sécurité importantes La plaque signalétique appliquée est située au bas du socie de

rvez toutes les instructions et mises en garde inscrites sur

rapparer.
L'installation par un adulte est requise.
MISE EN GARDE: N'installez pas l'unité du bébé à une hauteu

Miss EN ONDER: Primitating part traffer as bodes are installed. Co product in enreptice parts is surrelation audited did nounterant as application dura constraint as the recognition dura constraint as the recognition duration and the recognition of the production of the recognition of the recogni

mentris votre sécurité en peint.

Adaptateur à funité du parent Sortie : SV CC 1A.

Adaptateur à funité du parent Sortie : SV CC 1A.

Visch felocommunications Ltd.

Adaptateur de l'unité du parent Sortie : SV CC 600mA Visch felocommunications Ltd.

Adaptateur de l'unité du bébé : Sortie : SV CC 600mA Visch felocommunications Ltd.

Modèlle : VIOSEUSISSOBO Informations sur les piles rechargeables :

Zhongshan Tianmao Battery Co., Ltd. Model Number: BP1763 Model Municipal IPT/20 Internal Interna

d'ammission de l'action de la cordon d'alimentaire o completifier.

No faint fonctionner cet appareil qu'avec le hype principier.

No faint fonctionner cet appareil qu'avec le hype principier.

No faint fonctionner cet appareil qu'avec le hype principier.

No faint fonctionner cet appareil qu'avec le hype principier.

No faint fonctionner le la constitut votre marchand ou votre compagnie colorielle, consultate votre marchand ou votre compagnie social d'alectrici.

No faint fonctionner le la consultate votre marchand ou votre compagnie de la consultate votre marchand ou votre compagnie de la consultate de la con

retraction designed parties primare consistent management in the Ne places past cell appareil sur un charlot, meuble, trépied, support de montage ni table chancelants. Les trous et ouvertures du bothier, située à l'arrière de l'appareil ou sous cellui-ci, servent à aérer l'appareil. Pour l'énipédient des surchaufférs, ne blocause sous aiux un prétent l'énipédient des surchaufférs, ne blocause sous aiux un prétent de l'appareil ou servent de l'appareil pour l'étant de l'appareil pour l'énipédient des surchaufférs, ne blocause sous aiux un prétent de l'appareil ou servent de l'appareil pour le l'énipédient sous aiux un prétent de l'appareil ou servent de l'appareil pour le l'appareil pour l'énipédient sous au l'appareil servent de l'appareil pour l'énipédient sous au l'appareil servent de l'appareil pour l'énipédient sous l'appareil servent de l'appareil pour l'énipédient de l'appareil pour l'appareil pour l'énipédient sous l'appareil pour l'énipédient de l'appareil pour l'énipédient sous l'appareil pour l'énipédient sous l'appareil pour l'énipédient sous l'appareil pour l'énipédient de l'appareil l'a

remontage incorrect peut par la suite présenter des risques d'électrocurion. Vous deviroz tester la réception chaque fois que vous mettez l'appareil en fonction. ntes afin de vérifier si celles-ci ne sont 

2.1 excelse un hor traces require aix period or controllational period. Siliciphones care fifth feet. The or their proteins of proteins of the period of

Misse or garde

1. Utiliser et entrepocete le princiulir à une termpérature entre 0 ° C (27 ° pt et 0 ° CD4 ° pt )

2. Ex pt et de CD4 ° pt ; de la des frecis ou des c'haleurs entrene 3 ° C (27 ° pt et 0 ° CD4 ° pt )

2. entrene s'ant cya' à la ternière d'erecte du solei. Ne l'installez pis prés d'une source de c'haleurs et de la colei de l

The regard is further of solid to Just fee.

A monitoration of the state of the sta

Til.

Stimulateurs cardiaques implantés dans l'organisme
Les simulateurs cardiaques (ne s'applique qu'aux dispositifs numéricaues sans fil): contraction of the contraction o

Vous devirier maintenir les dispositifs sant fil à au moins six pouces du simulateur cardiacque. Ils ne dolvent PAS placer le néléphone sans fil directement sur le stimulateur cardiaque, sel que dans une poche de chemise, lorsque calui-ci est el marché.

#### LIMITED WARRANTY

How long is the limited warranty period?

Refurbished products purchased from our online store carry a 90-day replacement warranty.

Product returned without a valid proof of purchase (see item 2 below); or

What is not covered by this limited warranty?

What does this limited warranty cover? The manufacturer of this VTech Product was holder of a valid proof of purchase ("Consu

save you a service call. Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Productly to the service location. VTech Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product In transit.

#### Other limitations

Please retain your original sales receipt as proof of purchase.