Open-Ear Headphones


OPENEAR Air F3

User Manual

How to Wear



What's In the Box



Specifications

Model: OPENEAR Air F3

Type: Open-Ear Communication Headset

BT Version: 5.3

Connection: ≈10m

Music Mode: ≥19h(80%volume)


Communication Mode: ≥17h(80%volume)

Charging Time: ≈50min

Charging Voltage: DC 5V


Waterproof: IPX5 rating

Button Control



Silicone Strap Usage

For a smaller head circumference, use this silicone strap accessory to secure headphones better. Tie each end of the strap to the headphone hanging wires behind the ears.



Operations

Power On/Off

Power On: Press and hold the power button for 3 seconds until the LED flashes white and green. Prompt: power on pairing.

Power Off: Press and hold the power button for 3 seconds until the LED flashes green three times. Prompt: power off.

BT Connection

Select "OPENEAR Air F3" in BT menu to connect, Prompt: connected.

Battery Level Notification

Automatically announce the real-time battery level of the headphones after power on.

Battery 100%-70%: Prompts: battery high. Battery 69%-40%: Prompts: battery medium. Battery 39%-10%: Prompts: battery low.

Switch Music/Communication Modes

The headphones is built-in 2 sound modes. Double click the power button to switch. Prompt: music mode / communication mode.

Mute On/Off

Double click the MFB during a call to turn on/off mute function. Prompt: mute on / mute off.

Answer/Hang Up/Reject A Call

Answer/Hang Up A Call:Click the MFB once. Reject A Call: Double click the MFB.

Play/Pause Music

Click the MFB once.

Previous/Next Track

Previous Track: Press and hold the + button. Next Track: Press and hold the - button.

Volume Up/Down

Volume Up: Click the button + .
Volume Down: Click the button - .
When the volume reaches the maximum, Prompt maximum volume.

Activate Voice Command

Press and hold the MFB for 2 sec.

Low Battery


The green LED flashes three times every 3 minutes when the headset battery is lower than 20%, Prompt: low battery.

Restore Factory Setting

Press and hold "+" and "—"button at the same time under power-on status. Prompts: Restore to factory setting, power off.

Charge

Please use DC 5V adapter for charging.Green LED is on charging. White LED is on after fully charged.



Attentions

- Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Do not use high volume for long periods of time.
- 2. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones.
- 3. Do not remove or modify the headphone, as this may cause damage or burn out.
- 4. Do not throw, twist on headphones or put them into a fire.
- 5. Keep it away from fire, hydration and high pressure equipment.
- 6. Not suitable for children under 10-year-old containing small parts.
- 7. Do not classify it as household waste. Please sendit to the local electrical equipment recycling station.

Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general
RF exposure requirement. The device can be
used in portable exposure condition without
restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may cause undesired operation.

