



Device basics



- | | |
|---|--------------------------------------|
| 1 | Charging/Notification light |
| 2 | NFC |
| 3 | Volume/Zoom key |
| 4 | Power key/Fingerprint sensor |
| 5 | Nano SIM/Memory card slot |
| 6 | Camera key |
| 7 | Charger/USB Type-C™ cable port |
| 8 | Tray 2 for SIM card 2 or memory card |
| 9 | Tray 1 for SIM card 1 |


To insert either two nano SIM cards or a nano SIM card and a memory card




! Using two SIM cards and a memory card at the same time is not possible. Tray 2 allows you to use either a second SIM card or an additional memory card. Do not cut your SIM cards, as this may damage your device.

- 1 Drag out tray 2 and tray 1.
- 2 Place the main SIM card securely in tray 1, as shown in the illustration.
- 3 Place either the second SIM card or the memory card securely in tray 2, as shown in the illustration.
- 4 Gently push first tray 1, then tray 2, back into their slots until they fit into place.

To turn on your device

- ! It is important to use the USB Type-C cable provided when charging your device, as other types of USB cables can damage your device. It is recommended to charge the battery for at least 30 minutes before you turn on your device for the first time.
- 1 Press and hold down the power key  until your device vibrates.
 - 2 Wait a moment for your device to start.

To activate the screen

- Briefly press the power key .

Screen protection

- ! Before using your device, remove the protection film by pulling up on the protruding tab.



Screen covers and protectors may help you protect your device against damage. We recommend you use only those screen covers intended for your Xperia™ device. The use of third party screen protection accessories may prevent your device from working correctly by covering sensors, lenses, speakers, or microphones and can invalidate the warranty.

Support for you

You can access our support website directly from your device by visiting support.sonymobile.com to find user guides, downloadable content, troubleshooting tips and contact information.

- ! Even if you don't have a network connection, you can access support contact information on your device. Depending on the country or region where you purchased your device, you can find this information using the Support application.

To access the Support application

- 1 From your **Home screen**, tap .
- 2 Find and tap .

- ! Connect to the internet when using the Support application for the best available support.


Warranty, SAR and usage guidelines

For information about warranty, SAR (Specific Absorption Rate) and safety guidelines, please read the **Important information** provided under **Settings > System > About phone > Legal information** on your device.

Transferring contacts and content

If you need help with transferring contacts, messages, photos or other data from an old device to your new device, we recommend that you use the Xperia™ Transfer application. Visit www.sonymobile.com/xperiatransfer for more information.

To view the CE marking and the FCC ID



- 1 Drag out tray 2.
- 2 Drag out the label strip in the same way.

! To see the full text of the EU declaration of conformity, visit: <http://www.compliance.sony.de/>

To view the regulatory compliance mark

- Open the phone dialer, then enter ***#07#**.

Legal information

Publication number: 1309-7838.1

This Startup guide is published by Sony Mobile Communications Inc. or its local affiliated company, without any warranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications Inc. at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.

See regulatory information such as the device CE marking in the relevant label tray in the device.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved.

Visit www.sonymobile.com/global-en/legal/ for more information.

Manufacturer: Sony Mobile Communications Inc., 4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo, 140-0002 Japan. For EU product compliance: Sony Belgium, bijkantoor van Sony Europe Limited, Da Vincilaan 7-D1, 1935 Zaventem, Belgium.

© **2017** Sony Mobile Communications Inc. All rights reserved.

Supported frequency bands

Some frequency bands might be turned off in certain markets or by certain operators.

G8342

UMTS HSPA+ (Bands 1, 2, 4, 5, 6, 8, 19) GSM GPRS/EDGE 850, 900, 1800, 1900 LTE (Bands 1, 2, 3, 4, 5, 7, 8, 12, 13, 17, 19, 20, 25, 26, 28, 29, 32, 38, 39, 40, 41, 66) WLAN, 2.4G/5G, NFC

You can find your model number under **Settings > System > About phone**.

GSM 850/900 : Power Class 4, DCS(1800)/PCS(1900) : Power Class 1, UMTS : Power Class 3, LTE : Power Class 3, 2.4GHz : 100mW, 5.15-5.35GHz : 200mW, 5.47-5.725GHz : 500mW, NFC 13.56MHz

SONY®

Startup guide

Xperia™ XZ1
G8342

XPERIA

CE

1309-7838.1