

4.11 Transmitter Tune-Up Procedure 2.1033 (c) (9)

All frequency adjustments are set at the factory and there are no frequency field adjustments for this product. The transmit frequency is locked to the base station and controlled by VCTCXO adjustments to offset any possible errors.