

LIGHT BAR+ WITH REMOVABLE MULTI-POSITION BASE

QUICK START GUIDE

MLB7-1041-PCB (MLB7-1042-PCB)
V1.0 06/20

GETTING STARTED

Thank you for choosing the Smart Multi-Color LED Light Bar+ by Monster Smart Illuminescence. This quick start guide will help you with setup and installation of your device.

WHAT'S IN THE BOX

- Smart Multi-Color LED Light Bar+
- Multi-position Base with Attachment Screws
- Optional Wall-Mount Accessories
- Quick Start Guide

WHAT DO YOU NEED?

- Cellphone or tablet with Android 6.0 or higher / iOS 10 or higher
- Wi-Fi router with an INTERNET connection
- Wi-Fi 2.4GHz 802.11n

Before setup, make sure your phone is connected to the **2.4GHz Wi-Fi network** that your Light Bar+ will be placed on. You may also need to turn on location to find nearby devices.

TIP: Do you know your Wi-Fi network name and password? Write it down now if it's hard to remember.

ANYTHING ELSE?

Your Light Bar+ can be mounted on a wall. For secure mounting with the included mounting screw, you will need a Phillips head screwdriver (not included).

TIP: Save these instructions for future reference.

SETUP COMPLETE SETUP BEFORE INSTALLATION

STEP 1

Remove your Smart Multi-Color LED Light Bar+ and all components from the box.



STEP 2

Download the **MONSTER SMART** app from the App Store (for iPhone) or Google Play Store (for Android phones).



Free Download

STEP 3

Make sure your phone or tablet is successfully connected to the **2.4GHz Wi-Fi network** that your Light Bar+ will be placed on.

Open the **MONSTER SMART** app and create an account by following the on-screen instructions.

STEP 4

It is recommended to first pair your Light Bar+ in a location close to your router **BEFORE** installation.

Connect the USB plug to a powered 5V 1A USB port. The Light Bar+ will begin blinking when it has entered pairing mode and is ready to pair.



Pairing Modes:

EZ MODE - RAPIDLY BLINKING LED (default)
EZ Mode is the default mode for quick and easy pairing setup.
AP MODE - SLOWLY BLINKING LED
Access Point Mode is a specialty setup that can help connect to mixed networks. Follow the on-screen step-by-step instructions.

Press and hold the controller button for 5-6 seconds to enter pairing mode or change between pairing modes.



NOTE: At any time after 10 seconds of pairing mode you can disconnect the power for 10 seconds and then reconnect it to cancel pairing and operate the product without Wi-Fi. Advanced features will not be available.

STEP 5

In the **MONSTER SMART** app, select the "+" in the upper right corner of the home screen to add a new device and then select "Lighting (Wi-Fi)" to add your device.



If needed, click "Net Pairing Mode" in the upper right to switch the default EZ pairing mode for 2.4GHz Wi-Fi networks to AP mode for mixed Wi-Fi networks.

STEP 6

Confirm that the LED indicator is **RAPIDLY** blinking. Confirm that the network displayed is your **2.4GHz Wi-Fi network**, then enter your Wi-Fi password and click "Confirm".

Confirm that the LED indicator is **SLOWLY** blinking. Confirm the network is your **mixed Wi-Fi network**, enter your Wi-Fi password and click "Confirm". Follow the on-screen instructions to set up your device via wireless access point.



Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your Light Bar+ is now setup and you can proceed to installation.

You can now use the app to add voice control (see pg 8), adjust settings, create custom lighting effects, set schedules, and more!

INSTALLATION

STEP 1

Determine where and in what orientation you would like to use your Light Bar+. Horizontal or vertical orientation on a shelf or table, or mounted on the wall as an LED sconce.


STEP 2

Pass the USB power cord and controller through the opening in the multi-position base.



STEP 3

For horizontal or wall mounted orientations, attach the base in the center of the light bar using the two included screws. For vertical orientation, route cord through the cord channel and attach the base at the end of the light bar.



STEP 4

Connect the USB plug to a powered 5V 1A USB port. The Light Bar+ will automatically reconnect to the paired Wi-Fi network and will now be ready to use!

HOW TO USE

Your Light Bar+ can be easily controlled with the in-line controller, the **MONSTER SMART** app to access advanced and customizable lighting effects, or by using a compatible voice assistant product for hands-free operation. (see page 8)



- SCENES:** click - change between preset scenes or access the custom edits of those scenes. requires Wi-Fi pairing and app!
- POWER:** double-click - click twice quickly to power on or off your device.
- RESET:** press and hold - reset the device and to pair to your Wi-Fi network.
- Microphone for music reactive effects (controlled via app)

APP CONTROL: CUSTOM SCENES




- PICTURE:** edit your scene thumbnail
- NAME:** edit your scene name
- COLOR SETS:** choose from 8 preset color sets or add your own colors and arrange and adjust them as you wish
- Individual color adjustments
- TIP:** Set Brightness to 0% create an "off" color.
- TIP:** Set Saturation to 0% create a white color.
- MODE:** choose between 3 color changing modes: Fade, Flash, and Music Reactive (activated built-in mic)
- PATTERN:** choose between 6 directional patterns for the LED light effects
- SPEED:** adjust the color transition speed
- SAVE:** submit and save your scene!

The Smart Multi-Color LED Light Bar+ is great to use in multiples. You can control each Light Bar separately or easily group multiple devices together in the app to control them all as one. Click on the menu button in the upper right corner and then click "Create Group" to group your devices.




Q: Why is my device failing to connect to my Wi-Fi network?
A1: Make sure your phone or tablet is successfully connected to the **2.4GHz Wi-Fi network** that your device will be placed on.
A2: You may first need to enable and allow location services on your phone or tablet to find nearby devices.
A3: If your Wi-Fi network is a mixed 2.4GHz/5GHz network, try using AP pairing mode for better results.
A4: If you still have issues with your mixed network, you may need to access your router settings and/or call your Internet Service Provider to create a separate 2.4GHz network.



WALL MOUNTED

Make sure your Amazon Alexa device is installed and setup

- NOTE:** Use the same login information that you used to create your Monster Smart account.




Using the name **Light Bar** or the name you assigned your Light Bar, you can ask Alexa to control your device, just say "Alexa" and ask, "Turn on my Light Bar", "Set my Light Bar to blue", "Set my Light Bar to 50% brightness", and more!



Make sure your Google Assistant device is installed and set up.

- STEP 1:** Open the Google Home app, go to the Home menu, and tap the "+" button.
- STEP 2:** Click "Set up device."
- STEP 3:** Click "Have something already set up?"
- STEP 4:** Search for and choose **MONSTER SMART** and authorize your account using your login information.
- NOTE:** Use the same login information that you used to create your Monster Smart account.



Using the name Light Bar, or the name you assigned your Light Bar, you can ask your Google Assistant to control your device. Just say "Hey Google" and say: "Turn on my Light Bar", "Set my Light Bar to blue", "Set my Light Bar to 50% brightness", and more!



Requires iPhone running iOS 12 or later

- STEP 1: Open the **MONSTER SMART** app and go to the "Smart" menu, tap the "+" button to create a new Tap To Run Smart Scene
- STEP 2: Tap "launch Tap To Run" and fill out the information
- STEP 3: Once your Smart Scene is created and saved, click the button that appears at the bottom of the screen that says "Add to Siri" to open the list of options
- STEP 4: Select your new Tap To Run Smart Scene from the list and click "Add to Siri"
- STEP 5: Create a custom phrase to say to Siri to run your Smart Scene (this can be any verbal command)



WARRANTY

1 Year Limited Warranty - Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void.

- Keep these instructions

- Do not drop, puncture, or disassemble this product
- Do not install this product in any way other than what is outlined in this guide
- Do not use this product in wet or very humid environments or expose to dripping or splashing liquids of any kind
- Do not immerse in water
- Avoid long exposure to direct sunlight, which may cause damage
- Do not use this product in small, enclosed locations that could limit the flow of air or trap excess heat
- Do not expose this product to open flames
- Do not use the product in a strong magnetic field
- Do not use this product for emergency lighting/exits
- Do not allow small children to operate, modify, or install this device unsupervised
- Use a clean, soft cloth to clean - do not use any corrosive cleaners/bills to clean
- For indoor use only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and/or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Industry, Science, and Economic Development Canada licence-exempt RSS standard(s).
Le présent appareil est conforme aux normes RSS standard(s) exemptes de licence d'Industrie, Science et Développement économique Canada applicables aux appareils radio exempts de licence. L'appareil ne crée ni n'est sensible aux interférences suivantes :

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil ne crée ni n'est sensible aux interférences, y compris les interférences qui pourraient entraîner le fonctionnement indésirable de l'appareil.

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliant with RF exposure guidelines, using Canadian/Canadian information on RF exposure and compliance. The maximum distance from body to use the device is 20cm.

Le présent appareil est conforme aux normes d'exposition aux radiofréquences et à la conformité et conformité d'après les informations canadiennes. La distance minimale du corps à utiliser le dispositif est de 20cm.

Item Accessories, Inc. Limited Warranty Policy for Monitor Stand Products last updated: March 17, 2020

The limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

1. WHAT THIS LIMITED WARRANTY COVERS: PERIOD OF COVER Item Accessories, Inc. ("Item Accessories"), 32 Broadway Ave., Edison, New Jersey, USA, warrants to the owner of the enclosed Monitor Stand Product provided product is covered in this Item ("Product") will be free from defects in materials and workmanship for a period of one (1) year. Notwithstanding the foregoing, the Warranty Period for a factory refurbished Product is one (1) year, even if available by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Item Accessories will, at its sole discretion, either (a) repair or replace any defective Product in component, with proof of purchase and original documentation. Repair or replacement may be made with a new or refurbished product in component, at Item Accessories's sole discretion. If the Product is a component incorporated within a item longer available, Item Accessories may, at Item Accessories's sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) nine (9) days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is not transferable from the original purchaser to subsequent owners.

2. TOTAL SATISFACTION RETURN POLICY If you are the original purchaser of the Product and you are not

Satisfied with this Product for any reason, you may return it in its original condition to the retailer in compliance with the retailer's return policy.

WARRANTY CONDITIONS, HOW TO GET SERVICE If you want to **CLAIM** under this LIMITED WARRANTY, please mailing a claim under the Limited Warranty. The owner of the Product must fill out www.boschpower.com/us/support during the Warranty Period to provide notice of your warranty claim and describe the alleged defect, and (2) comply with our Accounts (see the authorized distributor's return shipping instructions). You however will have no warranty obligations with respect to a returned Product if it otherwise, at its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below). Our Accounts will bear all costs of return shipping to owner, and will reimburse any shipping costs incurred by the owner except with respect to any Ineligible Product or product shipped internationally, for which the owner will bear all shipping costs.

THEY ARE LIMITED IN THAT THEY DO NOT COVER THE FOLLOWING: (1) Any "Warranty" that does not cover the following collectively: "Multiple Products"; (2) Products marketed as "sample" or "Not for Sale," or sold "AS-IS," (3) Products that have been subject to: (a) modifications, alterations, tampering, or tampering in connection with repairs; (b) handling, storage, installation, testing, or use not in accordance with any quick-start guide, manual or other instructions provided by the Accreos; (4) abuse or misuse of the Product; (5) fire, flood, lightning, or other natural or man-made causes; (6) damage to the telecommunications network; or (7) Acts of God, including but not limited to lightning, flood, storms, or tsunamis; or (8) any two (2) or more Accreos located in the same household; even if packaged or sold with any Accreos hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defect in materials or workmanship of the Product, or software (even if packaged or sold with the product), unless Accreos

We warrant that you are fully satisfied with your purchase for maintenance or repair. Unauthorized use of the Product

[illegible]

8. LIMITATION OF REMEDY: In addition to the above warranty disclaimer, in no event, will Jern Accounting be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product, and Jern Accounting's total cumulative liability arising from or relating to this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

7. **LIMITATION OF LIABILITY** The Jet-Accounts online services at members.thomson.com ("services") provide you information ("product information") regarding your Jet-Accounts products or other peripheral connected to your products ("product peripherals"). The type of product peripheral that may be connected to your product may change

From time to time, without notifying the generality of the customers above, all product information is provided by your management. The ICF website will also have information about our treatment program as well as other information that we think

information will be available, accurate, or reliable or that product information or use of the services or product will provide safety to you or others. You use all product information, the services, and the product at your own discretion and risk. You will be responsible for (and you agree to defend, indemnify and hold us, our affiliates, or licensors, including

your wiring, fixtures, electrical, home, product, product peripheral, computer, mobile device, and all other items and sets in your home, resulting from your use of the product information, services, or product. Product information provided by the service is not intended as a substitute for direct means of obtaining the information; for example, a notification provided through the service is not intended as a substitute for audible and visible indications in the home and/or on the product, nor for a third party monitoring service that monitors alarm state.

8. YOUR RIGHTS AND THE LIMITED WARRANTY This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the Restrictions in the Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisors service.

If you need to start a warranty claim for your Mac mini (4th) device, please reach out to Customer Support by emailing customerservice@macmini.com or calling our support number 866-246-2080. Please allow 7-10 business days to process warranty claims. Customers located outside of U.S. will be responsible for all shipping costs.

LIGHT BAR+ AVEC BASE MULTIPositionS

GUIDE DE DÉPART RAPIDE
MLB7-1041-RCB (MLB7-1042-RGB)
V1.0 06/20

FR

COMMENCER

Merci d'avoir choisi la Light Bar+ avec base multipositions de Monster Smart Illuminescence. Ce Guide de départ rapide vous aidera à configurer et à installer votre dispositif.

INCLUS DANS LA BOÎTE

- Base de lumière à DEL multicolore
- Base multiposition avec vis de fixation
- Accessoires de fixation murale optionnels
- Guide de départ rapide

QU'AVEZ-VOUS BESOIN?

- Téléphone cellulaire ou tablette avec: Android 6.0 ou supérieur / iOS 10 ou supérieur
- Routeur Wi-Fi avec connexion internet
- Wi-Fi 2.4-GHz 802.11n

Avant la configuration, assurez-vous que votre téléphone ou votre tablette est connecté au **réseau Wi-Fi 2.4 GHz** sur lequel votre Light Bar+ sera placé. Vous devez également vous assurer que la fonction de localisation est activée afin de localiser les dispositifs se trouvant à proximité.

CONSEIL: Connaissez-vous le nom et le mot de passe de votre réseau Wi-Fi? Notez-le maintenant s'il est difficile de vous en souvenir.

RIEN D'AUTRE?

Votre Light Bar+ peut être montée sur un mur. Pour un montage sûr avec la vis de montage incluse, vous aurez besoin d'un tournevis cruciforme (non inclus).

CONSEIL: Conservez ses instructions pour consultation ultérieure.

INSTALLER

CONFIGURATION
COMPLETE AVANT
L'INSTALLATION

ÉTAPE 1

Retirez votre barre de lumière multicolore à DEL intelligente et tous les composants de la boîte.



ÉTAPE 2

Téléchargez l'appli **MONSTER SMART** sur l'App Store (pour iPhone) ou Google Play Store (pour les téléphones Android).



Téléchargement gratuit

ÉTAPE 3

Assurez-vous que votre téléphone ou votre tablette est correctement connecté au **réseau Wi-Fi 2.4 GHz** sur lequel votre Light Bar+ est placé.

Ouvrez l'appli **MONSTER SMART** et créez un compte en suivant les instructions à l'écran.

ÉTAPE 4

Il est recommandé de coupler d'abord votre Light Bar+ dans un endroit proche de votre routeur AVANT l'installation.

Branchez la prise USB à un port USB 5V 1A alimenté. La Light Bar+ se mettra à clignoter lorsqu'elle sera en mode de jumelage et qu'elle sera prête à être jumelée.



Mode de jumelage:

MODE EZ - DEL CLIGNOTANT RAPIDEMENT (PAR DÉFAUT): Le mode EZ est le mode par défaut pour une configuration de jumelage rapide en facile.

MODE AP - DEL LUMINEUX CLIGNOTANT: Le mode point d'accès est une configuration secondaire qui peut aider à se connecter à des réseaux mesh. Suivez les instructions étape par étape à l'écran.

Appuyez sur le bouton d'alimentation et maintenez-le enfoncé pendant 5-6 secondes pour entrer en mode de jumelage ou pour passer entre les modes de jumelage.



REMARQUE: À tout moment, après 10 secondes de mode de jumelage, vous pouvez déconnecter l'adaptateur pendant 10 secondes, puis le reconnecter pour annuler le jumelage et faire fonctionner le produit sans Wi-Fi. Les fonctions avancées ne seront pas disponibles.

ÉTAPE 5

Dans l'appli **MONSTER SMART**, sélectionnez le "+" dans le coin supérieur droit de l'écran d'accueil pour ajouter un nouveau dispositif, puis sélectionnez "Lighting (Wi-Fi)" (Éclairage (Wi-Fi)) pour ajouter votre dispositif.



Simultanément, cliquez sur "Fast Pairing Mode" (mode de jumelage) dans le coin supérieur droit pour passer au mode de jumelage EZ par défaut pour les réseaux Wi-Fi 2.4 GHz en mode AP pour les réseaux Wi-Fi mesh.

ÉTAPE 6

Confirmez que le voyant à DEL clignote RAPIDEMENT. Confirmez que le réseau affiché est votre **réseau Wi-Fi 2.4 GHz**, puis entrez votre mot de passe Wi-Fi et cliquez sur "Confirmer" (Confirmer).

Confirmez que le voyant à DEL clignote LENTEMENT. Confirmez que le réseau est votre **réseau Wi-Fi mesh**, entrez votre mot de passe Wi-Fi et cliquez sur "Confirmer" (Confirmer). Suivez les instructions à l'écran pour configurer votre dispositif via un point d'accès sans fil.



Une fois terminé, votre dispositif sera connecté au réseau. Confirmez ou modifiez les paramètres de votre dispositif, puis cliquez sur "Done" (Terminer). Votre Light Bar+ est maintenant configuré et prêt à être utilisé.

Vous pouvez maintenant utiliser l'appli pour ajouter une commande vocale (voir p. 8), ajuster les paramètres, créer des effets d'éclairage personnalisés, définir des horaires et plus encore!

INSTALLATION

ÉTAPE 1

Déterminez où et dans quelle orientation vous souhaitez utiliser votre Light Bar+, orientation horizontale ou verticale sur une étagère ou une table, ou montée sur le mur comme une applique à DEL.

ÉTAPE 2

Faites passer le cordon d'alimentation USB et le contrôleur par l'ouverture de la base multipositions.



ÉTAPE 3

Pour les orientations horizontales ou murales, fixez la base au centre de la barre lumineuse à l'aide des deux vis fournies. Pour une orientation verticale, faites passer le cordon dans le canal du cordon et fixez la base à l'extrémité de la barre de lumière.



ÉTAPE 4

Branchez la prise USB à un port USB 5V 1A alimenté. La Light Bar+ se reconnectera automatiquement au réseau Wi-Fi jumelé et sera alors prête à l'emploi!

COMMENT UTILISER

Votre Light Bar+ peut être facilement contrôlée à l'aide du contrôleur en ligne, de l'appli **MONSTER SMART** permettant d'accéder à des effets lumineux avancés et personnalisables, ou en utilisant un assistant vocal compatible pour un fonctionnement mains libres. (voir page 8)



CONTRÔLE PAR APP: SCÈNES PERSONNALISÉES



FR

