

Hands-free call Short press ① to answer an incoming call, press ① again to end the call.	 Each speaker will reconnect automatically TWS and phone after the next power on. 	Charging 1.When the speaker warning low power, it means that battery is going to drained. The speaker will automatically reduce the volume when its battery is low, and the volume will return to your normal	BLUETOOTH SPEAKER
Pause/Play music Short press ① to pause music while playing, press ① again to play. TWS connection 1. After both speakers are power on, connect one of them to your phone's bluetooth, and the other one do not connect to any device. 2. Double press ① button on both speaker, working indicator will flash in blue and white alternately. 3. After the pairing is completed, the left channel speaker working indicator keep lighting in blue, and the right channel speaker working indicator keep lighting in blue,	Clear connection 1. Triple press ① button will clear and disconnect the connection with TWS and Bluetooth. 2. The speaker enter the waiting pairing state, working indicator flash in blue. Save power The speaker will power off automatically to save power if it stops working for more than 20 min.	 settings once the battern is charged to more than 15%. 2. In this case, please charge the speaker in no time. While charging, the charging indicator keep lighting in orange. 3. Once the charge is completed, the charging indicator will keep lighting in green. NOTE: It's recommended to power off the units while the speaker is charging, please don't play music unit! the unit is charged for 30 min at least. And if not used for a long time, please charge the speaker at least once every 3 months. These practices all help extend battery life. 	CO3

Any Cha