


JBP TEST SETUP PHOTOS


B.1 Radiated Field Strength Measurement




30 MHz-1 GHz (USB Test Mode)



Above 1 GHz (USB Test Mode)

AY0520 Charger


30 MHz-1 GHz (Camera Test Mode)



Above 1 GHz (Camera Test Mode)


ONE0520 Charger

30 MHz-1 GHz (Camera Test Mode)




Above 1 GHz (Camera Test Mode)

B.2 Conducted Emission




USB Test Mode

AY0520 Charger



Camera Test Mode



Camera Test Mode