DO NOT PRINT COMMENTS

MERKURY

MERKURY INNOVATIONS CONFIDENTIAL

FILE INFORMATION

DATE: 03/23/2017

MODEL NUMBER: UZ-BTE85

PRINTER SPECIFICATIONS

FILE NAME: UZ-BTE85_Manual_032317.ai

SCALE: 100%

SIZE: Trim: W 202mm x H 152mm

PAPER STOCK: 80g Art Paper

INNER STRUCTURE: (none)

FINISH: PP Matte Varnish Coating

INKS: 1/0

Greyscale

PRESS WORK / NOTES: Trim to size, score, fold,

& glue in specified areas.

---- Score

DO NOT print Comments or Dielines.

Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT

MERKURY CHINA:

perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)

File created by Dmitry Shmakov

- Please include this manual in all packaging
- for UZ-BTE85 - Greyscale
- Double sided printing
- FIT INSIDE STORAGE COMPARTMENT IN INNER TRAY

HOW TO FOLD IT (reference only)

PLACE IN STORAGE COMPARTMENT ONCE FOLDED









TROUBLESHOOTING

No powe

Recharge your earbuds using the included Micro USB charging cable

Music is not playing

Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth.

Now follow the steps to pair your device again.

Bluetooth device will not reconnect with the earbuds

Restart the earbuds to reconnect your Bluetooth device. Navigate to your Bluetooth settings menu on your Bluetooth device, tap "UZ-BTE85", and select "Forget".

Specification:

Bluetooth® Version: 4.2 Bluetooth® Range: Up to 30ft. Charging Voltage: 5V Charging Input: Micro USB Battery Capacity: 55mAh Charging Time: Approx. 1.5 Hours Playback Time: Approx. 4.5 Hours* Standby Time: Approx. 3000 Hours Freq. Response: 20Hz - 20KHz *Depends on individual use

FCC Notice:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Recorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technical for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

Merkury Innovations

45 Broadway 3rd Fl. New York, NY 10006

www.merkuryinnovations.com E-mail: support@merkuryinnovations.com

© 2017 Merkury Innovations LLC
To explore our full selection of products, visit us at: www.merkuryinnovations.com


The Bluetooth word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.

Made in China



IMPORTANT Please read before using this product

PRODUCT/CONTROLS DIAGRAM



- Plug the micro USB cable into the micro USB port on the side of the in-line remote and connect
- the other end of the cable to either a computer USB port or a USB-compatible charger.

 Solid red LED light will indicate when the earbuds are charging, even while they are turned off.

 When charging is complete, the LED light will turn off.

 Charging time is approximately 1.5 hours.

- Press & hold the power button on the BLADE earbuds for 3-4 seconds.
 The earbuds will power on, a blue LED light will flash, and will automatically reconnect to the last Bluetooth device they were connected to.
 If you haven't connected the earbuds to any device follow the steps below.

PAIR & CONNECT WITH A NEW DEVICE

- If your earbuds are OFF, press & hold the power button for 6-10 seconds to power on and enter pairing mode.
- If your earbuds are ON, press the power button once to enter the pairing mode.
- The LED light will quickly flash red & blue. Your earbuds are ready to be paired.
 On your Bluetooth-enabled device, navigate to the Bluetooth settings menu, turn on the Bluetooth feature and search for new devices. After a few seconds you will see "UZ-BTE85" listed.
- Tap this model to select it. The LED will begin to slowly blink blue, and the earbuds will emit a tone
 to indicate that it has been successfully paired with your device.

NOTE: You only need to pair your Bluetooth device with the BLADE earbuds once. NOTE: If your device asks for a password to connect to the earbuds, enter "0000"

PLAY

- Connect your device to the BLADE earbuds via Bluetooth (see "Pair & Connect with a New
- Open your favorite music app and press play.
- Control the track & volume from your device, or using the in-line controls on the BLADE earbuds. Press the "Power" button once to play/pause music & answer calls.
 Press the "+" or "-" button once raise/lower the volume on the earbuds. Press and hold to skip to
- the next/previous track. Note: Volume on your device and on the earbuds are controlled separately. • All audio, including music, games, videos, and notifications will be routed through the BLADE

POWER OFF

Press and hold power button for 3-5 seconds.
The earbuds and LED light will turn off.