
# **OPTIONAL IJET ACCESSORIES** continued: iPOD Stand:

This dual function stand is the perfect option for your iPOD because it is both fully functional and decorative. It props the iPOD upright on your stereo system, television or wherever you choose to place it mak-ing viewing of the LCD screen easy as well as keeping the IJET upright for maximum reception of the remote. The top section can be removed if you are not using the iPOD charger or place it in the base to hide the charger plua, ear buds or any other small iPOD accessory. Part Number iJET-Stand.









Toll Free 888-869-4737 1185 Park Center Drive • Vista, CA 92081 www.abtech2.com

# **CONGRATULATIONS ON YOUR PURCHASE OF THE IJET WIRELESS RF REMOTE CONTROL**

The iJET was designed to provide maximum control of your iPOD from anywhere you choose to place it regardless of whether it is in your backpack at school or hundreds of feet away in a different room connected to your home stereo.



## **OPERATION:**

Plug the iJET into the top of your iPOD and WAIT 30 seconds. A self diagnostic will automatically run and your wireless remote will be ready for operation within 30 seconds. Plug in your ear buds, speakers or connect to your home stereo through a set of RCA jacks (supplied in some iJET kits). The connection of ear buds, RCA jacks or stereo wire is imperative for optimum performance since the iJET uses this plugged in wire as an antenna (Patent Pending) for maximum range.


Per FCC 15.21, you are cautioned that changes or modifications not expressly approved by the part responsible for [] compliance could void the user's authority to operate the equipment.

# **OPTIONAL IJET ACCESSORIES** continued: iPOD Stand:

This dual function stand is the perfect option for your iPOD because it is both fully functional and decorative. It props the iPOD upright on your stereo system, television or wherever you choose to place it making viewing of the LCD screen easy as well as keeping the IJET upright for maximum reception of the remote. The top section can be removed if you are not using the iPOD charger or place it in the base to hide the charger plug, ear buds or any other small iPOD accessory. Part Number iJET-Stand.









Toll Free 888-869-4737 1185 Park Center Drive • Vista, CA 92081 www.abtech2.com

# **CONGRATULATIONS ON YOUR PURCHASE OF THE IJET WIRELESS RF REMOTE CONTROL**

The iJET was designed to provide maximum control of your iPOD from anywhere you choose to place it regardless of whether it is in your backpack at school or hundreds of feet away in a different room connected to your home stereo.




## **OPERATION:**

Plug the iJET into the top of your iPOD and WAIT 30 seconds. A self diagnostic will automatically run and your wireless remote will be ready for operation within 30 seconds. Plug in your ear buds, speakers recupy for operations within 3 sections. They in your ear bods, speakers or connect to your home stereo through a set of RCA jacks (supplied in some iJET kits). The connection of ear buds, RCA jacks or stereo wire is imperative for optimum performance since the iJET uses this plugged in wire as an antenna (Patent Pending) for maximum range.

# **OPERATION** continued:

## **REWIND:**

Press and release this button to move track BACKWARDS. Press and HOLD this button to rewind through the track



FORWARD:

Press and release

**VOLUME DOWN:** Press and HOLD this button to scroll volume down

PAUSE/PLAY/SLEEP: Press and release to toggle between Pause and Play.\* Press and HOLD for 2 full seconds to put the iPOD into sleep mode. \*If you press and hold this button for longer than 1 second but less than 2 seconds the iJET will ignore your request.

# **ADVANCED LOW POWER MODE (ALPM):**

The iJET uses an advanced power down mode which minimizes current draw on your iPOD battery if you are not connected to a constant power source. After 20 minutes of sensing no music playing or no remote commands being sent, the iJET goes into an advanced battery save mode. The iJET receiver will automatically re-power itself when it detects music playing (If there was none before) or it sees a remote button being pressed for more than .6 seconds.

# **OPTIONAL IJET ACCESSORIES:**

### iJET Remote:

Program up to 10 iJET remotes into any receiver. Place an iJET remote in each bedroom, out by the pool or anywhere you choose to control your music. **Part Number iJET-Remote.** 

The optional Belt clip is perfect for the mobile iPOD user. It easily clips to your belt, Backpack strap, purse or anywhere you desire to keep track of your JET remote control. The remote easily snaps into the belt dip for maximum flexibility. **Part Number JET-Belt** 





### Optional Color Remote Faces:

For iPOD personalization you can purchase optional matching color remote and receiver cases. Simply snap off the top cover of the iJET remote and the receiver's face plate. Snap on a new metallic remote face on both the remote and receiver (Packaged together). The package comes complete with all iPOD mini color configurations.

Part Number: iJET-Pink, iJET- Blue, iJET-Silver, iJET-Gold,

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions.

FORWARD:

- 1). This device may not cause harmful interference, and
- 2)•This device must accept any interference received, including interference that may cause undesired operation.

# **OPERATION** continued:

### **REWIND:**

Press and release this button to move track BACKWARDS. Press and HOLD this button to rewind through the track



volume down

# Press and release this button to move track FORWARD. Press and HOLD this button to forward through the track.

# VOLUME UP:

Press and HOLD this button to scroll volume up

# PAUSE/PLAY/SLEEP:

Press and release to toggle between Pause and Play.\* Press and HOLD for 2 full seconds to put the iPOD into sleep mode.
\*If you press and hold this button for longer than 1 second but less than 2 seconds the iJET will ignore your request.

# **ADVANCED LOW POWER MODE (ALPM):**

The iJET uses an advanced power down mode which minimizes current draw on your iPOD battery if you are not connected to a constant power source. After 20 minutes of sensing no music playing or no remote commands being sent, the IJET goes into an advanced battery save mode. The IJET receiver will automatically re-power itself when it detects music playing (If there was none before) or it sees a remote button being pressed for more than .6 seconds.

# **OPTIONAL IJET ACCESSORIES:**

### iJET Remote:

Program up to 10 iJET remotes into any receiver. Place an iJET remote in each bedroom, out by the pool or anywhere you choose to control vour music. Part Number iJET-Remote.

The optional Belt clip is perfect for the mobile iPOD user. It easily clips to your belt, Backpack strap, purse or anywhere you desire to keep track of your iJET remote control. The remote easily snaps into the belt clip for maximum flexibility. **Part Number iJET-Belt** 





## Optional Color Remote Faces:

For iPOD personalization you can purchase optional matching color remote and receiver cases. Simply snap off the top cover of the UET remote and the receiver's face plate. Snap on a new metallic remote face on both the remote and receiver (Packaged together). The package comes complete with all iPOD mini color configurations.

Part Number: iJET-Pink, iJET- Blue, iJET-Silver, iJET-Gold, iJET-Green.