




LED Wi-Fi Flex Light

Model - 58085, 58087, 58088



Your Enbrighten LED Wi-Fi Flex Light transforms your space with vibrant colors and dynamic customization — all using the free Enbrighten Wi-Fi app.

Note: Read all instructions before installing. Please read all the warning statements included in these instructions.



MANUAL OPERATION

Press the button on the power supply to cycle through each of the following color settings:

1. White, 100% brightness

2. White, 50% brightness

3. White, 25% brightness

4. Color fade

5. Red

6. Green

7. Blue

8. Yellow

9. Purple
10. Pink

11. Orange

12. Teal

13. Holiday

14. July 4th

15. Rainbow

16. Twinkle

17. OFF

Suppliers Declaration of Conformity | Model #: 58085, 58087, 58088 | Jasco Products Co., 10 E. Memorial Rd., Oklahoma City, OK 73114, www.byjasco.com This device complies with Part 15 of the FCC and Industry Canada license exempt RSS standards. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a 8in minimum distance between the radiator & your body.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.

PDF icon Consult the dealer or an experienced radio/TV technician for help.

Remotely operate your smart flex lights with the easy-to-use Enbrighten app. Follow the available instructions and resources to set up your smart device.

NOTE: For best results, pair your lights near your router prior to installation. Requires 2.4GHz Wi-Fi connection

1

Download the app

Scan the QR code above or search Enbrighten on the Apple App Store or on Google Play

2

Setup and installation

1.

2.

Create an account in the Enbrighten app

Install flex light

3

Setup and installation

1.

2.

Plug flex light into GFCI-protected outlet

Add devices, control the smart flex lights from anywhere and create schedules

4

Voice control

Compatible with Amazon Alexa or Google Assistant-enabled devices

Select "Support" in the Enbrighten app or follow the steps in the Amazon Alexa or Google Home app to connect your Enbrighten account

IMPORTANT SAFETY INSTRUCTIONS

This portable luminaire has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

WARNING!
WARNING: When using outdoor use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

- a)

Use only three-wire outdoor extension cords that have three-prong grounding plugs and grounding receptacles that accept the appliance's plug.
- b)


Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.
- c)

Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SEOW, SOW, SOOW, STW, STOW, STOW, SJEW, SJEOW, SJEOW, SJW, SJOW, SJOW, SJTW, SJTOW, or SJTOW.

READ ALL INSTRUCTIONS

Refer to the manual or visit www.byjasco.com for limitations and restrictions on warranties and the product registration information.
WARNING: When using outdoors use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electrical shock, and personal injury, including the following:
Ground fault circuit interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety. The maximum distance to the receptacle is determined by the length of cord provided.
WARNING: Keep these bags away from babies and children. Do not use in cribs, beds, carriages, or playpens. The thin film may cling to nose and mouth and prevent breathing.
WARRANTY INFORMATION: This Jasco product is warrantied for three years with a limited-lifetime replacement warranty on Enbrighten LED light source only.

WARNING!
To prevent failure, do not bend more than 4.72in.



⚠ WARNING

RISK OF ELECTRIC SHOCK

- OUTLETS USED FOR POWERING FLEX LIGHTS SHALL COMPLY WITH ALL NATIONAL AND LOCAL ELECTRICAL CODES. CONSULT LOCAL ELECTRICIAN IF UNSURE OF COMPLIANCE REQUIREMENTS.
- FOR USE ONLY ON GFCI PROTECTED CIRCUITS.
- DO NOT SUBMERGE.
- DO NOT USE AROUND AQUARIUMS.
- FLEX LIGHTS ARE A WET LOCATION PRODUCT AND HAVE NO SERVICEABLE PARTS.
- DO NOT USE WITH EXTENSION CORD NEAR WATER OR WHERE WATER MAY ACCUMULATE.
- KEEP LAMPS AT LEAST 16FT. FROM POOLS AND SPAS.
- KEEP PLUGS AND RECEPTACLES DRY.
- AVOID DAMAGE TO THE CORDS AND LAMP ASSEMBLIES DURING INSTALLATION. PERIODICALLY INSPECT THE FLEX LIGHTS FOR PHYSICAL DAMAGE OR OTHER DAMAGE CAUSED BY OUTDOOR EXPOSURE TO THE ELEMENTS.
- REPLACE ANY DAMAGED FLEX LIGHTS.
- DO NOT INSTALL IN LOCATIONS WHERE FLEX LIGHTS CAN BE STEPPED ON.
- ENSURE FLEX LIGHTS ARE UNPLUGGED FROM POWER DURING INSTALLATION.
- CHILDREN SHOULD NOT BE ALLOWED TO PLAY WITH FLEX LIGHTS.
- NOT SUITABLE FOR FIELD CUTTING OR SPLICING.
- UL RECOMMENDS TESTING GFCI CIRCUITS AND RECEPTACLES EVERY MONTH TO ENSURE PROPER OPERATION.
- DO NOT MOUNT OR SUPPORT FLEXIBLE LIGHT IN A MANNER THAT CAN DAMAGE THE OUTER JACKET OR CORD INSULATION.
- MATERIAL MAY BECOME BRITTLE WHEN COLD. DO NOT INSTALL WHERE IT MAY BE STEPPED ON OR SUBJECT TO PHYSICAL DAMAGE.
- DO NOT USE WITH EXTENSION CORD NEAR WATER OR WHERE WATER MAY ACCUMULATE. FOR USE ONLY ON GFCI PROTECTED CIRCUITS.

RISK OF FIRE

- NOT INTENDED FOR INSTALLATION IN CEILINGS, SOFFITS, CABINETS, ATTICS, OR OTHER ENCLOSED SPACES.
- DO NOT INSTALL NEAR FLAMMABLE LIQUIDS.
- DO NOT COVER FLEXIBLE LIGHT AS THE COVERING MAY CAUSE THE FLEXIBLE LIGHT TO OVERHEAT AND MELT OR IGNITE.
- TO PREVENT OVERHEATING, DO NOT ALLOW CONTACT BETWEEN FLEXIBLE LIGHT CABLES OR PARTS OF THE FLEXIBLE LIGHT CABLE. MAINTAIN AT LEAST 12MM (0.47IN.) SPACING BETWEEN LIGHT CABLE OR LIGHT CABLE PARTS.
- UNCOIL FLEXIBLE LIGHT PRIOR TO PLUGGING IN.


SAVE THESE INSTRUCTIONS.

INSTALLATION

This flexible LED strand can be planted in the ground with stakes, installed to surfaces with clips or simply laid out in a line or around corners. Select a clean, sturdy location that is within reach of an outlet. The maximum distance to the receptacle is determined by the length of cord provided.

Power supply

The power supply features a push button that serves both as a means of pairing with the app and manual operation. Mount it using the keyholes on the back or the tabs on the side. IMPORTANT: Do not lay power supply on the ground or where water may accumulate.




Ground mounting

1. Place strand directly onto ground or garden bedding.

Stake mounting

1. Insert the top of a stake into a clip's keyhole slot, sliding it forward until it clicks into place.




2. Carefully thread the flex light through each clip.
3. Firmly plant the stakes into soil or garden bedding.


Note: If it requires more than a firm push, loosen the soil or remove debris.

Clip mounting

1. Mark the locations for each clip with a pencil, leaving about 1.5ft. of space between each.
2. Drill pilot holes on each marking using a 1/16in. drill bit.
3. Insert the included screws into the pilot holes with a Phillips-head screwdriver, leaving about 1/8in. of remaining space.




4. Place the clips over the screws — tightening the screws as needed.
5. Carefully thread the flex light through the installed clips.



Connect to power

After installing, plug the power cord into a 120VAC, 60Hz outlet.



Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video. Scan code or visit byjasco.com/58085i.

Register your product



Receive exclusive deals and register your product. Scan code or visit byjasco.com/deals.



Home automation is in your palm with Wi-Fi smart devices and accessories at www.enbrightenwifi.com.



Like our product? Leave a review on your favorite retailer website or amazon.com.



Having problems? Let us know how we can help. Call 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

05/04/2022 v1

All brand names shown are trademarks of their respective owners App Store is a service mark of Apple Inc. Google, Google Play and Google Home are trademarks of Google LLC. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

MADE IN VIETNAM

Distributed by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114. This Jasco product comes with a 3-year limited warranty. Visit www.byjasco.com for warranty details. Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.




Electrical Ratings

Input: 120V, 60Hz

Model No.	Input Amps, Max.	Location Use
58085	0.25A	Wet
58087	0.47A	
58088	0.70A	

LED Wi-Fi
Luz flexible

Modelo - 58085, 58087, 58088



Su Enbrighten LED Wi-Fi Flex Light transforma su espacio con colores vibrantes y personalización dinámica, todo usando la aplicación gratuita Enbrighten Wi-Fi.

NOTA: Lea todas las instrucciones antes de instalar. Lea todas las declaraciones de advertencia incluidas en estas instrucciones.



OPERACIÓN MANUAL

Presione el botón pulsador en la fuente de alimentación para activar una de las siguientes configuraciones de colores:

- | | |
|------------------------------|-------------------|
| 1. Blanco, 100% brillo | 10. Rosa |
| 2. Blanco, 50% brillo | 11. Naranja |
| 3. Blanco, 25% brillo | 12. Verde azulado |
| 4. Desvanecimiento del color | 13. Fiesta |
| 5. Rojo | 14. 4 de Julio |
| 6. Verde | 15. Arcoíris |
| 7. Azul | 16. Centelleo |
| 8. Amarillo | 17. APAGADO |
| 9. Morado | |

Declaración de conformidad de proveedores | Modelo n.º: 58085, 58087, 58088 | Jasco Products Co., 10 E. Memorial Rd., Oklahoma City, OK 73114, www.bjjasco.com Este dispositivo cumple con las normas RSS de exención de licencia de la Parte 15 de la FCC y de Industry Canada. Su funcionamiento está sujeto a las siguientes dos condiciones: (1) este dispositivo no podrá causar interferencias perjudiciales, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan causar un funcionamiento no deseado.

NOTA DE LA FCC: El fabricante no se responsabiliza por ninguna interferencia de radio o TV causada por modificaciones no autorizadas a este equipo. Tales modificaciones podrían anular el derecho del usuario a hacer uso del equipo. Este equipo debe instalarse y operarse con una distancia mínima de 8in entre el radiador y su cuerpo.

NOTA: Este equipo se sometió a pruebas y cumple con los límites establecidos para un dispositivo digital Clase B de acuerdo con la Parte 15 de las Normas de la FCC. Dichos límites están diseñados para proporcionar una protección razonable contra la interferencia perjudicial en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia. Si no se instala y usa de acuerdo con estas instrucciones, podrá causar interferencia perjudicial a las radiocomunicaciones. Por otro lado, tampoco es posible garantizar que no ocurrirán interferencias en una instalación en particular. Si este equipo causa interferencias perjudiciales en la recepción de radio o televisión, las cuales pueden comprobarse encendiendo y apagando el equipo, se recomienda al usuario que intente corregir la interferencia adoptando una o más de las siguientes medidas:

- Cambiar la orientación o ubicación de la antena receptora.
- Aumentar la distancia entre el equipo y el receptor.
- Conectar el equipo a la salida de un circuito diferente al cual está conectado el receptor.
- Consultar al distribuidor o a un técnico de radio o TV experimentado para obtener ayuda.

Opere de forma remota sus luces flexibles con la app Enbrighten fácil de usar. Siga las instrucciones y los recursos disponibles para configurar su dispositivo inteligente.

NOTA: Para obtener los mejores resultados, empareje sus luces cerca de su enrutador antes de la instalación. Requiere conexión wifi de 2.4GHz.

1

Descargue la app

Escanee el código QR anterior o busque Enbrighten en App Store de Apple o en Google Play

Consíguelo en el App Store

DISPONIBLE EN Google Play

2

Configuración e instalación

1.

Cree una cuenta en la app Enbrighten

2.

Instalar luz flexible

3

Configuración e instalación

1.

Enchufe la luz flexible en el tomacorriente protegido por GFCI

2.

Agregue dispositivos, controle las luces flexibles inteligentes desde cualquier lugar y cree horarios

4

Control por voz

Compatible con Amazon Alexa o Asistente de Google-dispositivos habilitados

compatible con alexa

funciona con Google Home

Seleccione "Soporte" en la aplicación Enbrighten o siga los pasos en la aplicación Amazon Alexa o Google Home para conectar su cuenta Enbrighten

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Esta luminaria portátil tiene un enchufe polarizado (una clavija es más ancha que la otra) como característica para reducir el riesgo de descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado de una sola manera. Si el enchufe no encaja completamente en el tomacorriente, invierta el enchufe. Si aún no encaja, comuníquese con un electricista calificado. Nunca lo use con un cable de extensión a menos que el enchufe se pueda insertar completamente. No altere el enchufe.

¡ADVERTENCIA!

ADVERTENCIA: Cuando utilice luminarias portátiles para uso en exteriores, siempre se deben seguir las precauciones básicas de seguridad para reducir el riesgo de incendio, descarga eléctrica y lesiones personales, incluidas las siguientes:

- a) Utilice únicamente cables de extensión para exteriores de tres hilos que tengan tres clavijas, enchufes con conexión a tierra y receptáculos con conexión a tierra que acepten enchufe del aparato.
- b) La protección del interruptor de circuito de falla a tierra (GFCI) debe proporcionarse en el(los) circuito(s) o la(s) salida(s) que se usará(n) para el lugar húmedo portátil luminaria. Los receptáculos están disponibles con protección GFCI incorporada y se pueden utilizar para esta medida de seguridad.
- c) Úselo solo con un cable de extensión para uso en exteriores, como una extensión cable de cable tipo SEW, SEOW, SEOWW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEW, SJEDW, SJEDOW, SJW, SJOW, SJOWW, SJTW, SJTOW, or SJTOOW.

LEA TODAS LAS INSTRUCCIONES

limitaciones y restricciones de la garantía y la información para registrar el producto.

ADVERTENCIA: Cuando utilice luminarias portátiles para exterior, siempre respete las precauciones básicas para reducir el riesgo de incendio, descargas eléctricas y lesiones a personas, incluidas las siguientes:


Proteja los circuitos o los tomacorrientes que utilizará para alimentar las luminarias portátiles en lugares húmedos mediante un interruptor de circuito de falla de puesta a tierra (GFCI). Es posible conseguir tomacorrientes con protección GFCI incorporada para cumplir con esta medida de seguridad. La distancia máxima al receptáculo está determinada por la longitud del cable provisto.

ADVERTENCIA: Mantenga las bolsas lejos del alcance de bebés y niños. No use en cunas, camas, cochecitos ni corrales para bebés. Su capa fina puede pegarse a la nariz y la boca, lo que impide la respiración.

INFORMACIÓN SOBRE LA GARANTÍA: Este producto de Jasco tiene una garantía de tres años y una garantía limitada de por vida únicamente para los repuestos de la fuente de luz LED Enbrighten.

¡ADVERTENCIA!

Para evitar fallas, no doble más de 4.72 pulg




INSTALACIÓN

Esta tira de LED flexible se puede plantar en el suelo con estacas, instalarse en superficies con clips o simplemente colocarse en línea o alrededor de las esquinas. Seleccione un lugar limpio y resistente que esté al alcance de una toma de corriente. La distancia máxima al receptáculo está determinada por la longitud del cable proporcionado.

Fuente de alimentación

La fuente de alimentación cuenta con un botón pulsador que sirve como medio de emparejamiento con la aplicación y operación manual. Móntelo usando los agujeros de cerradura en la parte posterior o las pestañas en el costado. IMPORTANTE: No coloque la fuente de alimentación en el suelo o donde se pueda acumular agua.




Montaje en tierra

1. Coloque el hilo directamente sobre el suelo o la ropa de cama del jardín.

Montaje de estaca

1. Inserte la parte superior de una estaca en la ranura del ojo de la cerradura de un clip, deslizándola hacia adelante hasta que encaje en su lugar.




2. Pase con cuidado la luz flexible a través de cada clip.
3. Plante firmemente las estacas en el suelo o en la ropa de cama del jardín.


NOTA: Si requiere algo más que un empujón firme, afloje la tierra o elimine los escombros.

Clip de montaje

1. Marque las ubicaciones de cada clip con un lápiz, dejando unos 1.5 pies. de espacio entre cada uno.
2. Taladre orificios piloto en cada marca con una broca de 1/16 pulg. broca.
3. Inserte los tornillos incluidos en los orificios guía con un destornillador de cabeza Phillips, dejando aproximadamente 1/8 pulg. del espacio restante.




4. Coloque los clips sobre los tornillos, apretando los tornillos según sea necesario.
5. Pase con cuidado la luz flexible a través de los clips instalados.



Conectar a la energía

Después de la instalación, enchufe el cable de alimentación en un tomacorriente de 120VCA, 60Hz.



¡Gracias por su compra!

Instrucciones fáciles



Lea las instrucciones o mire el video con el paso a paso.

Escanee el código o visite bjjasco.com/58085i.

Registre su producto



Recibe ofertas exclusivas y registra tu producto.

Escanee el código o visite bjjasco.com/deals.



La domótica está al alcance de su mano con los dispositivos y accesorios inteligentes con wifi en www.enbrightenwifi.com.



Le gusta nuestro producto?

Deje una reseña en el sitio web de su comercio favorito o en amazon.com.



¿Tiene algún problema?

Díganos cómo podemos ayudar. Llame al 1-800-654-8483, entre las 7 a. m. y las 8 p. m., hora estándar del centro.

Todos los nombres de marcas son marcas comerciales de sus respectivos propietarios. App Store es una marca de servicio de Apple Inc. Google, Google Play y Google Home son marcas de Google LLC. Amazon, Alexa y todos los logotipos relacionados son marcas registradas de Amazon.com, Inc. o sus filiales.

HECHO EN VIETNAM

Distribuido por Jasco Products Company LLC, 10 E Memorial Rd., Oklahoma City, Oklahoma 73114. Este producto de Jasco tiene una garantía limitada de 3 años. Visite www.bjjasco.com para conocer los detalles de la garantía.
¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7AM y las 8PM hora estándar del centro

Especificaciones eléctricas

Entrada: 120 V, 60Hz

Modelo n.º	Amperios máximos de entrada	Lugar de uso
58085	0.25A	Húmedo
58087	0.47A	
58088	0.70A	