



EVERYDAY EARBUDS PRO

QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE
GUÍA DE INICIO RÁPIDO




CONNECT
RELIER
CONECTAR



 Pairing mode
Mode d'appariement
Modo de emparejamiento

FIND THE BEST FIT
TROUVEZ LE MEILLEUR AJUSTEMENT
ENCUENTRE EL MEJOR AJUSTE



FUNCTIONS
LES FONCTIONS
FUNCIONES


TAP
TAPOTER
TOCAR

HOLD
TENIR
MANTENER



L	L / R	R
Speaker icon ● Volume down icon ● ● ●	Play/Pause icon ● ● Phone icon ● ● ● ● Green phone icon ● Phone icon ● ● Red X icon ● ● [3s] Power icon ● ● [2s] Refresh icon ● ● [10s]	Speaker icon ● Volume up icon ● ● ●

SOUND PROFILES & FEATURES
PROFILS SONORES ET FONCTIONNALITÉS
PERFILES DE SONIDO Y CARACTERÍSTICAS



L [1.5s]



BALANCED SOUND
SON ÉQUILIBRÉ
SONIDO BALANCEADO



BASS SOUND
SON DE BASSE
SONIDO BAJO



PURE SOUND
SON PUR
SONIDO PURO



R [1.5s]



AWARENESS MODE
MODE DE SENSIBILISATION
MODO DE CONCIENCIA



FULL USER MANUAL
MANUEL UTILISATEUR COMPLET
MANUEL UTILIZADOR COMPLETO



<https://rayconglobal.com/pages/the-everyday-earbuds-pro-full-user-manual>