

62MM



## Ease Life User Manual

Smart Wi-Fi Camera

V3-2405

128MM

**Download App**  
Scan the QR code below, or directly search for "Ease Life" in the App Store and Google Play to download the latest version.

**Télécharger l'application**  
Scannez le code QR ci-dessous ou recherchez directement « Ease Life » dans l'App Store et Google Play pour télécharger la dernière version.

**Lade App herunter**  
Scannen Sie den QR-Code unten oder suchen Sie direkt im App Store und bei Google Play nach „Ease Life“, um die neueste Version herunterzuladen.

**Scarica l'applicazione**  
Scansiona il codice QR che sotto o cerca direttamente "Ease Life" su App Store e in Google Play per scaricare la versione più recente.

**Descargar aplicación**  
Escanea el código QR a continuación o busca directamente "Ease Life" en App Store y Google Play para descargar la última versión.

**アプリをダウンロードする**  
下記QRコードをスキャンするか、App Store または Google Play で「Ease Life」を直接検索して、最新のバージョンをダウンロードしてください。



**Log in**  
Enter your username and password, then click the "Log in" button (If you're using Ease Life for the first time, please register an account first).

**Se connecter**  
Entrez votre nom d'utilisateur et votre mot de passe, puis cliquez sur le bouton « Connexion » (Si vous utilisez Ease Life pour la première fois, veuillez d'abord créer un compte).

**Anmeldung**  
Geben Sie Ihren Benutzernamen und Ihr Passwort ein und klicken Sie dann auf die Schaltfläche „Anmelden“ (Wenn Sie Ease Life zum ersten Mal verwenden, registrieren Sie bitte zuerst ein Konto).

**Login**  
Inserisci il tuo nome utente e la tua password, quindi fai clic sul pulsante "Accedi" (Se stai utilizzando Ease Life per la prima volta, registra prima un account).

**Acceso**  
Ingresa tu nombre de usuario y contraseña, luego haz clic en el botón "Inicio sesión" (Si estás utilizando Ease Life por primera vez, primero registra tu cuenta).

**ログイン**  
ユーザー名とパスワードを入力し、「ログインボタン」をクリックしてください (初めてEase Lifeをご利用の場合は、アカウントを登録してください)。



**Add Device By Bluetooth**  
1. The APP automatically searches nearby devices.  
2. Make sure that the Bluetooth of the phone is enabled and allow "Ease Life" to access it.


**Ajouter un appareil par Bluetooth**  
1. L'APP recherche automatiquement les appareils à proximité.  
2. Assurez-vous que le Bluetooth du téléphone est activé et autorisez « Ease Life » à y accéder.

**Gerät per Bluetooth hinzufügen**  
1. Die App sucht automatisch nach Geräten in der Nähe.  
2. Stellen Sie sicher, dass Bluetooth auf dem Telefon aktiviert ist, und erlauben Sie „Ease Life“, darauf zuzugreifen.

**Aggiungi dispositivo tramite Bluetooth**  
1. L'APP ricerca automaticamente i dispositivi nelle vicinanze.  
2. Assicurati che il Bluetooth del telefono sia abilitato e consenti a "Ease Life" di accedervi.

**Agregar dispositivo por Bluetooth**  
1. La APP buscará automáticamente dispositivos cercanos.  
2. Asegúrese de que el Bluetooth del teléfono esté habilitado y permita que "Ease Life" acceda a él.

**Bluetoothでデバイスを追加**  
1. アプリは自動的に近くのデバイスを検索します。  
2. 携帯電話のBluetoothが有効になっていることを確認し、「Ease Life」がアクセスできるようにします。



**Add Device By Bluetooth**  
3. Select a device, enter your home Wi-Fi network name and password correctly.  
4. Wait patiently for 1 to 2 minutes. If you hear "Network connection failed", please double-check your Wi-Fi network name and password.


**Ajouter un appareil par Bluetooth**  
3. Sélectionnez un appareil, saisissez correctement le nom et le mot de passe de votre réseau Wi-Fi domestique.  
4. Attendez patiemment 1 à 2 minutes. Si vous entendez « Échec de la connexion réseau », veuillez vérifier le nom et le mot de passe de votre réseau Wi-Fi.

**Gerät per Bluetooth hinzufügen**  
3. Wählen Sie ein Gerät aus und geben Sie den Namen und das Passwort Ihres WLAN-Netzwerks korrekt ein.  
4. Warten Sie 1 bis 2 Minuten geduldig. Wenn Sie „Netzwerkverbindung fehlgeschlagen“ hören, überprüfen Sie bitte noch einmal den Namen und das Passwort Ihres WLAN-Netzwerks.

**Aggiungi dispositivo tramite Bluetooth**  
3. Seleziona un dispositivo, inserisci correttamente il nome e la password del tuo rete Wi-Fi domestica.  
4. Attendere pazientemente per 1 a 2 minuti. Se senti "Connessione di rete non riuscita", rivedi il nome e la password della tua rete Wi-Fi.

**Agregar dispositivo por Bluetooth**  
3. Seleccione un dispositivo, ingrese correctamente el nombre y la contraseña de su red Wi-Fi doméstica.  
4. Espere pacientemente de 1 a 2 minutos. Si escucha "Error en la conexión de red", verifique nuevamente el nombre y la contraseña de su red Wi-Fi.

**Bluetoothでデバイスを追加**  
3. デバイスを選択し、自宅のWi-Fiネットワーク名とパスワードを正しく入力します。  
4. 1〜2分間静かに待ちます。「ネットワーク接続に失敗しました」と聞かえる場合は、Wi-Fiネットワーク名とパスワードを再確認してください。



**Add Device By Bluetooth**  
4. Wait patiently for 1 to 2 minutes. If you hear "Network connection failed", please double-check your Wi-Fi network name and password.

**Ajouter un appareil par Bluetooth**  
4. Attendez patiemment 1 à 2 minutes. Si vous entendez « Échec de la connexion réseau », veuillez vérifier le nom et le mot de passe de votre réseau Wi-Fi.

**Gerät per Bluetooth hinzufügen**  
4. Warten Sie 1 bis 2 Minuten geduldig. Wenn Sie „Netzwerkverbindung fehlgeschlagen“ hören, überprüfen Sie bitte noch einmal den Namen und das Passwort Ihres WLAN-Netzwerks.

**Aggiungi dispositivo tramite Bluetooth**  
4. Attendere pazientemente per 1 a 2 minuti. Se senti "Connessione di rete non riuscita", rivedi il nome e la password della tua rete Wi-Fi.

**Agregar dispositivo por Bluetooth**  
4. Espere pacientemente de 1 a 2 minutos. Si escucha "Error en la conexión de red", verifique nuevamente el nombre y la contraseña de su red Wi-Fi.

**Bluetoothでデバイスを追加**  
4. 1〜2分間静かに待ちます。「ネットワーク接続に失敗しました」と聞かえる場合は、Wi-Fiネットワーク名とパスワードを再確認してください。



**Add Device By Scanning Code**  
1. Select "Add device by scanning code".  
2. Enter your home Wi-Fi network name and password correctly.


**Ajouter un appareil en scannant le code**  
1. Sélectionnez « Ajouter un appareil en scannant le code ».  
2. Saisissez correctement le nom et le mot de passe de votre réseau Wi-Fi domestique.

**Gerät durch Scannen des Codes hinzufügen**  
1. Wählen Sie „Gerät durch Scannen des Codes hinzufügen“.  
2. Geben Sie den Namen und das Passwort Ihres WLAN-Netzwerks korrekt ein.

**Aggiungi dispositivo tramite la scansione del codice**  
1. Seleziona "Aggiungi dispositivo tramite scansione del codice".  
2. Inserisci correttamente il nome e la password della tua rete Wi-Fi domestica.

**Agregar dispositivo escaneando código**  
1. Seleccione "Agregar dispositivo escaneando código de escaneo".  
2. Ingrese correctamente el nombre y la contraseña de su red Wi-Fi doméstica.

**コードをスキャンしてデバイスを追加**  
1. 画面から「コードをスキャンしてデバイスを追加」を選択します。  
2. ホームWi-Fiネットワーク名とパスワードを正しく入力します。



**Add Device By Scanning Code**  
3. Place the QR code 4 to 12 inches in front of the device and move it back and forth slowly until you hear "beep-beep".


**Ajouter un appareil en scannant le code**  
3. Placez le code QR de 4 à 12 pouces devant l'appareil et déplacez-le lentement d'avant en arrière jusqu'à ce que vous entendiez un « bip-bip ».

**Gerät durch Scannen des Codes hinzufügen**  
3. Positionieren Sie den QR-Code 4 bis 12 Zoll vor dem Gerät und bewegen Sie ihn langsam hin und her, bis Sie ein „Piep-piep“ hören.

**Aggiungi dispositivo tramite la scansione del codice**  
3. Posizionare il codice QR a una distanza compresa tra 4 e 12 pollici davanti al dispositivo e muoverlo lentamente avanti e indietro finché non senti "beep-beep".

**Agregar dispositivo escaneando código**  
3. Coloque el código QR de 4 a 12 pulgadas frente al dispositivo y muévalo hacia adelante y hacia atrás lentamente hasta que escuche "beep-beep".

**コードをスキャンしてデバイスを追加**  
3. QRコードをデバイス(約4〜12インチ)の前に置き、ゆっくりと前後に動かすまで「ビープ」という音が聞かえるまでゆっくりと前後に動かします。



**Add Device By Scanning Code**  
4. Wait patiently for 1 to 2 minutes. If you hear "Network connection failed", please double-check your Wi-Fi network name and password.


**Ajouter un appareil en scannant le code**  
4. Attendez patiemment 1 à 2 minutes. Si vous entendez « Échec de la connexion réseau », veuillez vérifier le nom et le mot de passe de votre réseau Wi-Fi.

**Gerät durch Scannen des Codes hinzufügen**  
4. Warten Sie 1 bis 2 Minuten geduldig. Wenn Sie „Netzwerkverbindung fehlgeschlagen“ hören, überprüfen Sie bitte noch einmal den Namen und das Passwort Ihres WLAN-Netzwerks.

**Aggiungi dispositivo tramite la scansione del codice**  
4. Attendere pazientemente per 1 a 2 minuti. Se senti "Connessione di rete non riuscita", rivedi il nome e la password della tua rete Wi-Fi.

**Agregar dispositivo escaneando código**  
4. Espere pacientemente de 1 a 2 minutos. Si escucha "Error en la conexión de red", verifique nuevamente el nombre y la contraseña de su red Wi-Fi.

**コードをスキャンしてデバイスを追加**  
4. 1〜2分間静かに待ちます。「ネットワーク接続に失敗しました」と聞かえる場合は、Wi-Fiネットワーク名とパスワードを再確認してください。



**Features**  
1. Video preview and common functions.  
2. Live video streaming, playback and related functions.


**Caractéristiques**  
1. Aperçu vidéo et fonctions communes.  
2. Streaming vidéo en direct, lecture et fonctions associées.

**Merkmale**  
1. Videoansicht und allgemeine Funktionen.  
2. Live-Video-Streaming, Wiedergabe und verwandte Funktionen.

**Caratteristiche**  
1. Anteprima video e funzioni comuni.  
2. Streaming video in diretta, riproduzione e funzioni correlate.

**Características**  
1. Vista previa de video y funciones comunes.  
2. Transmisión de video en vivo, reproducción y funciones relacionadas.

**特徴**  
1. ビデオプレビューと共通機能。  
2. ライブビデオストリーミング、再生および関連機能。



**FAQs**  
1. The device frequently appears offline.  
Consider replacing the power adapter and positioning the device closer to the router.  
2. A memory card is inserted into the device but is not recognized.  
The device supports a memory card up to 128GB. Format the memory card into FAT32 on your computer.

**FAQs**  
1. L'appareil apparaît fréquemment hors ligne.  
Prenez à remplacer l'adaptateur secteur et à rapprocher l'appareil du routeur.  
2. Une carte mémoire est insérée dans l'appareil mais n'est pas reconnue.  
L'appareil prend en charge une carte mémoire jusqu'à 128 Go. Formatez la carte mémoire en FAT32 sur votre ordinateur.

**FAQs**  
1. Das Gerät erscheint häufig offline.  
Ergreifen Sie den Austausch des Netzteils und die Positionierung des Gerätes näher am Router.  
2. Eine Speicherkarte ist in das Gerät eingelegt, wird aber nicht erkannt.  
Das Gerät unterstützt eine Speicherkarte bis zu 128 GB. Formatieren Sie die Speicherkarte auf Ihrem Computer in FAT32.

**FAQs**  
1. Antepima video e funzioni comuni.  
2. Streaming video in diretta, riproduzione e funzioni correlate.

**FAQs**  
1. Vista previa de video y funciones comunes.  
2. Transmisión de video en vivo, reproducción y funciones relacionadas.

**FAQs**  
1. ビデオプレビューと共通機能。  
2. ライブビデオストリーミング、再生および関連機能。

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene riconosciuta.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene riconosciuta.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene riconosciuta.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene reconocida.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene reconocida.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Freguntas frecuentes**  
1. El dispositivo aparece frecuentemente desconectado.  
Considere reemplazar el adaptador de corriente y colocar al dispositivo más cerca del enrutador.  
2. Una scheda di memoria è inserita nel dispositivo ma non viene reconocida.  
Il dispositivo supporta una scheda di memoria fino a 128 GB. Formatta la scheda di memoria in FAT32 sul tuo computer.

**Notes**  
1. Please power off the device before inserting or removing the SD card.  
2. To enhance the success rate of scanning QR codes, ensure the lens is free of dust. Tap the QR code to enlarge it, and adjust the distance between the lens and screen (optimal distance: 4-12 inches).

**Remarques**  
1. Veuillez éteindre l'appareil avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de réussite de la numérisation des codes QR, assurez-vous que l'objectif est exempt de poussière. Appuyez sur le code QR pour l'agrandir et ajustez la distance entre l'objectif et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Bitte schalten Sie das Gerät aus, bevor Sie die SD-Karte einlegen oder entfernen.  
2. Um die Erfolgsrate beim Scannen von QR-Codes zu erhöhen, stellen Sie sicher, dass die Linse sauber ist. Tippen Sie auf den QR-Code, um ihn zu vergrößern, und passen Sie den Abstand zwischen Objektiv und Bildschirm an (optimaler Abstand: 4-12 Zoll).

**Anmerkungen**  
1. Attendere che la lente sia pulita prima di inserire o rimuovere la scheda SD.  
2. Per aumentare la percentuale di successo delle scansioni dei codici QR, assicurarsi che la lente sia priva di polvere. Tocca il codice QR per ingrandirlo e regola la distanza tra l'obiettivo e lo schermo (distanza ottimale: 4-12 pollici).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).

**Anmerkungen**  
1. Espere que la lentille soit propre avant d'insérer ou de retirer la carte SD.  
2. Pour améliorer le taux de succès de la numérisation des codes QR, assurez-vous que la lentille soit exempte de poussière. Touchez le code QR pour l'agrandir et ajustez la distance entre la lentille et l'écran (distance optimale: 4-12 pouces).



**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**FCC WARNING**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

**IC Caution:**  
-English:  
This